

**RPT091**  
**Remote Power**  
**Transducer**

**QUICK GUIDE**

BG0227 Rev. A2

**SATEC**  


# ***RPT091 Remote Power Transducer***

## **QUICK GUIDE**

The *RPT091* is a compact three-phase AC Remote Power Transducer. The unit operates with a remote master (computer or PLC), and with an optional Remote Display Module (*RDM091*) for local display/setup. The *RDM091* is stand-alone or operable with a remote master, and can be panel-mounted or hand-held. Communications are via an RS-422 or RS-485 line, operable in multi-drop mode for connection of up to 32 instruments to a single line.

### **IMPORTANT**

**Please read instructions contained in this manual before performing installation, and take note of the following precautions:**

1. **Ensure that all incoming AC power and other power sources are turned OFF** before performing any work on the instrument. Failure to do so may result in serious or even fatal injury and/or equipment damage.
2. **Before connecting the instrument to the power source, check the labels** on the side of the instrument to ensure that your instrument is equipped with the appropriate power supply voltage, input voltages, currents, analog output and communication protocol for your application. Also check the correctness of other ordering options.
3. **Under no circumstances should the instrument be connected to a power source if it is damaged.**
4. **To prevent potential fire or shock hazard, do not expose the instrument** to rain or moisture.
5. **Mount the instrument away from heat sources in a dirt-free environment.** Do not operate the instrument in direct sunlight.
6. **The secondary of an external current transformer must never be** allowed to be open circuit when the primary is energized. An open circuit can cause high voltages, possibly resulting in equipment damage, fire and even serious or fatal injury. Ensure that the current transformer wiring is made through shorting switches and is secured using an external strain relief to reduce mechanical strain on the screw terminals, if necessary.
7. **The *RPT091* relays should not be used for basic (primary) protection** of power lines, transformers or motors, or for protection of people from injury.
8. **Setup procedures must be performed only by qualified personnel** familiar with the instrument and its associated electrical equipment.

9. **DO NOT attempt to open the instrument under any circumstances.**
10. **Although designed to operate in an electrically noisy environment**, the instrument should not be placed near very high electric fields. In the event that the instrument is mounted in a harsh, noisy environment with high potential for electromagnetic impulses from heavy switch gears, motors or lightning, it is recommended to install appropriate protective devices such as lightning and over-voltage arresters to all incoming voltage inputs.

## **LIMITED WARRANTY**

The manufacturer offers the customer a 24-month functional warranty on the instrument for faulty workmanship or parts from date of dispatch from the distributor. In all cases, this warranty is valid for 36 months from the date of production. This warranty is on a return to factory basis.

The manufacturer does not accept liability for any damage caused by instrument malfunction. The manufacturer accepts no responsibility for the suitability of the instrument to the application for which it was purchased.

Failure to install, setup or operate the instrument according to the instructions herein will void the warranty.

Your instrument may be opened only by a duly authorized representative of the manufacturer. The unit should only be opened in a fully anti-static environment. Failure to do so may damage the electronic components and will void the warranty.

## **NOTE**

The greatest care has been taken to manufacture and calibrate your instrument. However, these instructions do not cover all possible contingencies that may arise during installation, operation or maintenance, and not all details and variations of this equipment are covered by these instructions.

For additional information regarding installation, operation or maintenance of this instrument, contact the manufacturer or your local representative or distributor.

## Table of Contents

1	Measured Parameters and Outputs	4
2	Mechanical Installation	5
3	Electrical Installation	7
3.1	Power Supply	7
3.2	Current Inputs	7
3.3	Ground	8
3.4	Voltage Inputs	8
3.5	Relays	12
3.6	Status Inputs	13
3.7	Analog Output	13
4	RDM Display	14
5	Setup on the RDM	18
5.1	Basic Setup Parameters	19
5.2	Communications Port Setup Parameters	21
6	Communications	22
7	Troubleshooting	24
	Appendix: Technical Specifications	27

## Instrument Dimensions

# 1 Measured Parameters and Outputs

'•' = averages of 8, 16, or 32 real-time values; '+' = real-time values, 1 frequency cycle

<b>Parameter</b>	<b>Commu- nication</b>	<b>Display RDM</b>	<b>Analog Output</b>	<b>Pulsing Relay</b>	<b>Alarm/Con- trol Relay</b>
<b>Voltages and Currents</b>					
Voltage (L-n/L-L) per phase	• +	•	• +		• +
Current per phase	• +	•	• +		• +
Neutral (unbalanced) current	• +	•	•		•
<b>Powers</b>					
kW per phase	• +	•			
kvar per phase	• +	•			
kVA per phase	• +	•			
Power factor per phase	• +	•			
kW total	• +	•	• +		•
kvar total	• +	•	• +		•
kVA total	• +	•	• +		•
Power factor total	• +	•	• +		•
Frequency	• +	•	• +		• +
<b>Demand</b>					
Ampere Demand per phase	•				•
Max. Amp. Demand per phase	•	•			
Accumulated kW Demand	•		•		•
Accumulated kVA Demand	•		•		•
kW Demand	•				•
KVA Demand	•				•
kW Sliding Demand	•				•
KVA Sliding Demand	•				•
kW Maximum Sliding Demand	•	•			
KVA Maximum Sliding Demand	•	•			
<b>Energy</b>					
kWh Import per phase	•	•			
kvarh Import per phase	•	•			
kVAh Import per phase	•	•			
kWh Total Import / Export	•	•		•	
kvarh Total Import / Export	•	•		•	
kvarh Total Absolute				•	
kVA Total	•	•		•	
kvarh net	•				
<b>Harmonic Distortion (RPT091H only)</b>					
Voltage THD per phase	• +	•			+
Current THD per phase	• +	•			+
Current TDD per phase	• +	•			+
K- Factor per phase	• +				
<b>Status</b>					
Digital Input Status	•	•			•
Relay Output Status	•	•			
Alarm Trigger Status	•				
Phase Rotation	•	•			•
Remote Control via Comm.	•				•

## 2 Mechanical Installation

Inspect the instrument for physical damage incurred in transit. If the instrument is damaged, inform your local distributor immediately.




Figure 2-1 RDM Cut-out Dimensions





Figure 2-2  
RDM Panel Mounting

STEP 1: Insert RDM into cut-out.  
STEP 2: Fasten washers and nut on screws




**Figure 2-3 Retrofit:  
Brackets Mounting**

**STEP 1:** Insert RDM into cutout.

**STEP 2:** Mount brackets on studs.

**STEP 3:** Fasten brackets; do not tighten nuts.



**Figure 2-4 Retrofit:  
RPT Mounting**

**STEP 4:** Mount RPT on studs.

**STEP 5:** Assemble 4 screws and washers.

**STEP 6:** Fasten RPT to brackets; tighten nuts.

**STEP 7:** Connect RDM to RPT via the 15-pin connectors using cable supplied.


# 3 Electrical Installation

## 3.1 Power Supply

The power source can be dedicated-fused, or from a monitored voltage if it is within the transducer power supply range.

AC power supply: line to terminal 12; neutral to terminal 10.

DC power supply: positive to terminal 12; negative to terminal 10.



c98-10019

Figure 3-1 Locations of Terminals: Front View

NOTE: Power source connection requires use of the suppression core provided with the instrument.

**IMPORTANT: It is recommended to solder the wire ends before attaching them to the connectors.**

## 3.2 Current Inputs

To ensure accurate readings, the input current should not exceed 1.2A RMS and 1.76A amplitude for the 1A CT secondary, or 6A RMS and 8.8A amplitude for the 5A CT secondary.



If copper wiring is used, its thickness should be 2.5 - 4 mm<sup>2</sup> (13 - 11 AWG).

### 3.3 Ground


Connect the chassis ground of the *RPT091* to the switchgear earth ground using dedicated wire greater than 2 mm<sup>2</sup>/14 AWG.

### 3.4 Voltage Inputs


**Input of 690V (Standard):** To ensure accurate readings, the measured voltage between terminals 2-5, 5-8 and 8-2 should not exceed 790V AC RMS, and the measured voltage between terminals 2-11, 5-11 and 8-11 should not exceed 460V AC RMS and 695V amplitude. Use any of the seven wiring configurations shown in *Figures 3-2* through *3-8*.

**Input of 120V (Option U):** To ensure accurate readings, the measured voltage between terminals 2-5, 5-8, 8-2, 2-11, 5-11 and 8-11 should not exceed 144V AC RMS and 225V amplitude. 120V input usually implies use of a potential transformer (PT). The PT requires use of any of the four wiring configurations shown in *Figures 3-4* through *3-7*.

<b>Wiring Configurations</b>	<b>‘Wiring Mode’ Definition</b>
(See parameter setup instructions in Section 5)	
3-wire direct connection using 2 CTs (2-element)	3dir2 (Figure 3-2)
4-wire WYE direct connection using 3 CTs (3-element)	4Ln3 or 4LL3 (Figure 3-3)
4-wire WYE connection using 3 PTs, 3 CTs (3-element)	4Ln3 or 4LL3 (Figure 3-4)
3-wire open delta connection using 2 PTs, 2 CTs (2-element)	3OP2 (Figure 3-5)
4-wire WYE connection using 2 PTs, 3 CTs (2½-element)	3Ln3 or 3LL3 (Figure 3-6)
3-wire open delta connection using 2 PTs, 3 CTs (2½-element)	3OP3 (Figure 3-7)
4-wire delta direct connection using 3 CTs (3-element)	4Ln3 or 4LL3 (Figure 3-8)




**Figure 3-2**  
**Three Wire Direct Connection Using 2 CTs (2-element)**  
**Wiring Mode = 3dir2**




**Figure 3-3**  
**Four Wire WYE Direct Connection using 3 CTs (3-element)**  
**Wiring Mode = 4LL3 or 4Ln3**





**Figure 3-6**  
**Four Wire Wye Connection Using 2 PTs, 3 CTs (2 1/2-element)**  
**Wiring Mode = 3LL3 or 3LN3**

**[Note: Use this configuration only if voltages are balanced]**



**Figure 3-7**  
**Three Wire Open Delta Connection Using 2 PTs, 3 CT**  
**(2 1/2-element)**  
**Wiring Mode = 3OP3**




Figure 3-8 Four Wire Delta Direct Connection Using 3 CTs (3 element) Wiring Mode = 4LL3 or 4Ln3

### 3.5 Relays

Two relays are provided for energy pulsing, alarms or remote control.




Figure 3-9 Relay Output Terminal

### 3.6 Status Inputs

Four status inputs are provided for status monitoring, external synchronization input for power demand period, or output selector for multiplexed analog output.




Figure 3-10 Status Inputs Connections

### 3.7 Analog Output

The RPT091 provides one optically isolated analog output with an internal power supply and current output options of 0-20 mA, 4-20 mA, 0-1 mA and  $\pm 1$  mA.




Figure 3-11 Analog Output

Stabilization of the analog output after an input change takes up to 250 ms for real time data, and 1 to 6 sec for average data, depending on how the buffer is defined in the setup (see Section 5.1, Basic Setup).


One or two AX-7 analog expanders, DIN-rail mounted and connected via an RS-422 line, can be used for extension of the internal analog output.

## 4 RDM Display

Upon power up, the RDM assumes the **display mode**. Displayed parameters are divided into 4 groups. Each group is accessible by pressing the appropriate key, as follows:

<i>Measurement Group:</i>		<i>To Display Parameters:</i>
Common		default - Press the key that has an illuminated arrow LED pointing to it (below the lower window). If no LED is lit up, this means that the RDM is displaying the common measurements parameters.
Maximum demands		press <b>MAX. DEMAND</b> key
Harmonic *		press <b>THD/TDD</b> key (RPT091H only)
Energy		press <b>ENERGY</b> key

\* Only the *RPT091H* provides harmonic measurements. The RDM is the same for both the *RPT091* and the *RPT091H*. In the case of the *RPT091*, the **THD/TDD** key is not used.



[Press both arrows simultaneously to return to page 1 of the display]

Table 4-1 Displayed Parameters

Page	Window	LED ▶	Parameter ①	Digits	Unit ②
<b>Common Measurement:</b>					
1	1	<b>V1/V1-2</b>	Voltage L1/L12	4	V/kV
1	2	<b>V2/V2-3</b>	Voltage L2/L23	4	V/kV
1	3	<b>V3/V3-1</b>	Voltage L3/L31	4	V/kV
2	1	<b>A1</b>	Current L1	4	A/kA
2	2	<b>A2</b>	Current L2	4	A/kA
2	3	<b>A3</b>	Current L3	4	A/kA
3	1	<b>kVA</b>	Total kVA	4	kVA/MVA
3	2	<b>PF</b>	Total power factor	4	
3	3	<b>kW</b>	Total kW	4	kW/MW
4	1	<b>A NEUT</b>	Neutral current	4	A/kA
4	2	<b>Hz</b>	Frequency	4	Hz
4	3	<b>kvar</b>	Total kvar	4	kvar/Mvar
5	1		<b>Ph.L1</b>		Label
5	2	<b>PF</b>	Power factor L1	4	
5	3	<b>kW</b>	kW L1	4	kW/MW
6	1	<b>kVA</b>	kVA L1	4	kVA/MVA
6	2		<b>Ph.L1</b>		Label
6	3	<b>kvar</b>	kvar L1	4	kvar/Mvar
7	1		<b>Ph.L2</b>		Label
7	2	<b>PF</b>	Power factor L2	4	
7	3	<b>kW</b>	kW L2	4	kW/MW
8	1	<b>kVA</b>	<b>kVA L2</b>	4	kVA/MVA
8	2		<b>Ph.L2</b>		Label
8	3	<b>kvar</b>	<b>kvar L2</b>	4	kvar/Mvar
9	1		<b>Ph.L3</b>		Label
9	2	<b>PF</b>	Power factor L3	4	
9	3	<b>kW</b>	kW L3	4	kW/MW
10	1	<b>kVA</b>	<b>kVA L3</b>	4	kVA/MVA
10	2		<b>Ph.L3</b>		Label
10	3	<b>kvar</b>	<b>kvar L3</b>	4	kvar/Mvar
11	1		<b>PHAS.</b>		Label
11	2		<b>rOt.</b>		Label
11	3		Phase rotation(POS/NEG/ERR)	4	
12	1		<b>StAt.</b>		Label
12	3		Status inputs #1-#4	4	
13	1		<b>rEL.</b>		Label
13	3		Relay status #1-#2	4	



Page	Window	LED ▶	Parameter ①	Digits	Unit ②
<b>Maximum Demands</b>					
<b>MAX. DEMAND</b>					
1	1	<b>A1</b>	Maximum ampere demand L1	4	A/kA
1	2	<b>A2</b>	Maximum ampere demand L2	4	A/kA
1	3	<b>A3</b>	Maximum ampere demand L3	4	A/kA
2	1	<b>kVA</b>	Max. sliding window kVA demand	4	kVA/MVA
2	3	<b>kW</b>	Max. sliding window kW demand	4	kW/MW
<b>Harmonic Measurements</b>					
<b>THD</b>					
1	1	<b>V1/V1-2</b>	Voltage THD L1/L12	4	%
1	2	<b>V2/V2-3</b>	Voltage THD L2/L23	4	%
1	3	<b>V3/V3-1</b>	Voltage THD L3	4	%
2	1	<b>A1</b>	Current THD L1	4	%
2	2	<b>A2</b>	Current THD L2	4	%
2	3	<b>A3</b>	Current THD L3	4	%
<b>TDD</b>					
3	1	<b>A1</b>	Current TDD L1	4	%
3	2	<b>A2</b>	Current TDD L2	4	%
3	3	<b>A3</b>	Current TDD L3	4	%
<b>Total Energies</b>					
1	1	<b>MWh</b>	<b>Ac.En.</b>		Label
1	2		<b>IP.</b>		Label
1	3		MWh import	6	MWh
2	1	<b>Mvarh</b>	<b>rE.En.</b>		Label
2	2		<b>IP.</b>		Label
2	3		Mvarh import	6	Mvarh
3	1	<b>MVAh</b>	<b>AP.En.</b>		Label
3	3		MVAh	6	MVAh
4	1	<b>MWh</b>	<b>Ac.En.</b>		Label
4	2		<b>EP.</b>		Label
4	3		MWh export	6	MWh
5	1	<b>Mvarh</b>	<b>rE.En.</b>		Label
5	2		<b>EP.</b>		Label
5	3		Mvarh export	6	Mvarh
<b>Phase Energies</b> (if enabled in the BASIC SETUP configuration)					
6	1	<b>MWh</b>	<b>Ac.En.</b>		Label
6	2		<b>IP.L1</b>		Label
6	3		MWh import L1	6	MWh
7	1	<b>Mvarh</b>	<b>rE.En.</b>		Label
7	2		<b>IP.L1</b>		Label
7	3		Mvarh import L1	6	Mvarh
8	1	<b>MVAh</b>	<b>AP.En.</b>		Label
8	2		<b>L1</b>		Label
8	3		MVAh L1	6	MVAh

Page	Window	LED ▶	Parameter ①	Digits	Unit ②
9	1	<b>MWh</b>	<b>Ac.En.</b>		Label
9	2		<b>IP.L2</b>		Label
9	3		MWh import L2	6	MWh
10	1	<b>Mvarh</b>	<b>rE.En.</b>		Label
10	2		<b>IP.L2</b>		Label
10	3		Mvarh import L2	6	Mvarh
11	1	<b>MVAh</b>	<b>AP.En.</b>		Label
11	2		<b>L2</b>		Label
11	3		MVAh L2	6	MVAh
12	1	<b>MWh</b>	<b>Ac.En.</b>		Label
12	2		<b>IP.L3</b>		Label
12	3		MWh import L3	6	MWh
13	1	<b>Mvarh</b>	<b>rE.En.</b>		Label
13	2		<b>IP.L3</b>		Label
13	3		Mvarh import L3	6	Mvarh
14	1	<b>MVAh</b>	<b>AP.En.</b>		Label
14	2		<b>L3</b>		Label
14	3		MVAh L3	6	MVAh

- ① Display readings for all electrical quantities are sliding average values.
- ② Voltage and current readings with a decimal point are displayed in kV and kA. Power readings with a decimal point are displayed in MW, Mvar, and MVA. When the value is wider than the window, the right-most digits are truncated.
- ③ The maximum range for energy readings is 999,999,999 kWh/kvarh/kVAh. Beyond this value, the reading will roll over to zero. Negative (exported) energy readings are displayed without a sign.

## 5 Setup on the RDM

Setup can be performed via the RDM or *PComTest* software. *PComTest* is supplied on a disk which includes setup instructions<sup>1</sup>.

The functions of the RDM keys in the **setup mode** are shown below:




Figure 5-1 RDM Panel - Setup Mode

### Setup Procedure

1. Press SELECT to enter **setup mode**.
- 2a. Press SELECT again to go to SEE (for viewing only), or
- 2b. Press SELECT again to go to CHG (for editing setup)
3. Press ENTER. If a password is required, use ▲ ▼ to input the first digit and press SELECT to advance to next digit. After all 4 digits are input, press ENTER.
4. Press SELECT to choose the menu; press ENTER.

<sup>1</sup> All parameters may be set up via either the RDM or *PComTest*. It is recommended to use the RDM for Basic and Communications parameters setup, and to use *PComTest* for setup of all other menus.

5. Press SELECT to activate the middle window; use ▲ ▼ to choose the parameter; press ENTER.
6. Press SELECT to activate the lower window; use ▲ ▼ to choose the value; press ENTER (or press ESC to leave value unchanged).

## Menus

Code	Full Name	Code	Full Name
<i>bASc</i>	Basic - see Section 5.1	<i>PulS</i>	Pulsing Relay *
<i>Port</i>	Communications Port - see Section 4.2	<i>SetP</i>	Alarm Setpoints *
<i>dinP</i>	Digital (Status) Inputs *	<i>rtc</i>	Real time Clock*
<i>Aout</i>	Analog Output *	<i>disp</i>	Display*
<i>AEPn</i>	Analog Expander *	<i>rSt</i>	Reset enable/disable *
		<i>AccS</i>	Password enable/disable *

\* For full setup instructions for these parameters, see the complete *RPT091 Installation and Operation Manual*.

## 5.1 Basic Setup Parameters

		<i>Options /</i>	
<i>Code</i>	<i>Parameter</i>	<i>Value Range</i>	<i>Description</i>
<i>ConF</i>	Wiring Mode	<i>3OP2</i>	3-wire open delta using 2 CTs (2 element)
		<i>3OP3</i>	3-wire open delta using 3 CTs (2½ element)
		<i>Default = 4Ln3</i>	4-wire Wye using 3 PTs (3 element), line to neutral voltage readings
		<i>3dir2</i>	3-wire direct connection using 2 CTs (2 element)
		<i>4LL3</i>	4-wire Wye using 3 PTs (3 element), line to line voltage readings
		<i>3Ln3</i>	4-wire Wye using 2 PTs (2 ½ element), line to neutral voltage readings
		<i>3LL3</i>	4-wire Wye using 2 PTs (2 ½ element), line to line voltage readings
<i>Pt</i>	PT Ratio	<i>1.0 to 6500.0</i>	The phase potential transformer ratio. If direct connection, set PT to 1; otherwise, PT= primary voltage/ secondary voltage  <i>Default = 1</i>


<i>Code</i>	<i>Parameter</i>	<i>Options / Value Range</i>	<i>Description</i>
<i>Ct</i>	CT Primary Current	1 to 50000	The primary current rating of the phase current transformer, in A <i>Default = 5</i>
<i>d.P</i>	Demand Period	1,2,5,10,15,20,30,60,E	The length of the demand period for power demand calculations, minutes. E = external synchronization <i>Default = 15 min</i>
<i>n.dp</i>	Number of Demand Periods	1-15	The number of demand periods to be averaged for sliding window demands. <i>Default = 1 = block interval demand calculation</i>
<i>A.dP</i>	Ampere Demand Period	0 to 1800	The length of the demand period for ampere demand calculations, in seconds. 0 = measuring peak currents <i>Default = 900 sec</i>
<i>buF</i>	Averaging Buffer Size	8,16,32	The number of measurements for RMS sliding averaging. <i>Default = 8</i>
<i>rSt</i>	RESET enable/disable	<i>diS, En</i>	Protects all reset functions either via the RDM or communications. When set to diS, these functions are disabled. <i>Default = En</i>
<i>Freq</i>	Nominal Frequency	50, 60	The nominal frequency of the monitored electrical network, in Hz. <i>Default = 50 Hz</i>  NOTE: When measured voltages exist, the nominal frequency is the measured frequency. This parameter is used when measuring currents in the absence of voltages.
<i>LoAd</i>	Maximum Demand Load Current	1-50,000	The maximum demand load current used in TDD calculations, in A. If value is unknown, set to CT Primary Current value. <i>Default = 5000</i>
<i>Ph.En</i>	Phase Energy Measurement	<i>dis, En</i>	Enables/disables measurements of energies per phase. <i>Default = En</i>

## 5.2 Communications Port Setup Parameters

<i>Code</i>	<i>Parameter</i>	<i>Options / Value Range</i>	<i>Description</i>
<i>Prot</i>	Communications Protocol *	<i>ASCII</i> <i>rtu</i> <i>dnP3</i>	<i>ASCII</i> protocol = <i>Default</i> non-ASCII protocol
<i>rS</i>	Interface Standard	<i>422</i> <i>485</i>	RS-422 (4 wires) RS-485 (2 wires)= <i>Default</i>
<i>Addr</i>	Address	<i>0-255</i>	Powermeter address: 1-99: ASCII; 1-247: Modbus 255: DNP 3.0, SPA <i>Default = 1</i>
<i>bAud</i>	Baud Rate	<i>110, 300,</i> <i>600, 1200,</i> <i>2400, 4800,</i> <i>9600, 19.2</i>	110 baud, 300 baud, 600 baud, 1200 baud, 2400 baud, 4800 baud, 9600 baud = <i>Default</i> , 19200 baud
<i>dAtA</i>	Data Format	<i>7E</i> <i>8n</i> <i>8E</i>	7 bits, even parity 8 bits, no parity = <i>Default</i> 8 bits, even parity


\* The communications protocol is selected by a short between terminals 13 and 14 on the RPT091 (see Section 6). The protocol may be modified after a cold restart of the RPT091.

## 6 Communications



c98-10013

Figure 6-1 Terminal Block - ASCII



c98-10014

Figure 6-2 Terminal Block - Non-ASCII

Both the RS-422 and RS-485 standards enable connection of up to 32 instruments on one multi-drop line for a distance of up to 1200 meters.

The *RPT091* provides two green LED indicators TXD and RXD, which show activity on the RS-422/RS-485 communication port. The TXD indicator flashes when the instrument sends out data. The RXD indicator flashes when the instrument receives data.

Figures 6-3 through 6-6 illustrate all RS-422 and RS-485 cable configurations and wiring connections.

A full description of the communications software is found in the *RPT091 Communications Manual*.

### NOTE

Where an RS-232/RS-422 converter is used, R1 is not applicable (see Figures 6-3 and 6-4) since it is built in to the converter.




Figure 6-3 RS-422 Multidrop Connection, 25-Pin PC Port




Figure 6-4 RS-422 Multidrop Connection, 9-Pin PC Port




Figure 6-5 RS-485 Multidrop Connection, 25-Pin PC Port




Figure 6-6 RS-485 Multidrop Connection, 9-Pin PC Port

Use a shielded, 0.33 mm<sup>2</sup>/22 AWG twisted pair cable for each communication link; terminate the ends of multi-drop line with 200-500 Ohm resistors. Connect the cable shield to the ground input.



## 7 Troubleshooting

<b><i>Problem</i></b>	<b><i>Probable Cause</i></b>	<b><i>What to do</i></b>
Code other than '8' on RDM panel LED	Self-diagnostic test negative result	Note the code and call your distributor
Power LED on RPT not lit	Insufficient power supply	Check voltage level on power supply inputs (10,12)
Display LED on RDM not lit	Faulty cable connection	Check RDM cable connections
Varying line-to-line voltages	Incorrect voltage inputs connections	Check voltage inputs connections
Non-positive phase rotation	<ol style="list-style-type: none"> <li>1. Concrete load has negative sequence</li> <li>2. Incorrect voltage inputs connections</li> <li>3. One or two phase voltages not connected</li> </ol>	Check voltage inputs connections
One or more phase currents not displayed	Incorrect current inputs connections	Check current inputs connections
Phase active powers or power factors unequal or values do not correspond to actual load	Incorrect voltage or current inputs connections	Check voltage and current inputs connections; check polarity of CT connections
Cannot proceed past the first RDM menu	Incorrect password	Check that your password is correct. If you cannot provide the correct password, call your distributor for instructions on overriding password protection.
RDM window continues to flash after pressing ENTER	Value has been entered incorrectly or is incompatible with other setup parameters.	Check that parameter definition is correct.

<b>Problem</b>	<b>Probable Cause</b>	<b>What to do</b>
Alarm setpoints or analog output channels disabled	Setup parameters that affect voltage/current/power were changed	Define these setup parameters (wiring mode, PT ratio, CT primary current) prior to setting up alarm setpoints/analog channels.
Status inputs setup not accepted	<ol style="list-style-type: none"> <li>1. The analog selector inputs and the external synchronization pulse input overlap.</li> <li>2. Allocated inputs for the analog output selector are not contiguous and do not start from input #1.</li> </ol>	Check that all inputs are allocated correctly
Cannot store pulsing output setup	<ol style="list-style-type: none"> <li>1. You assigned a parameter to a relay output with zero number of unit-hours per pulse</li> <li>2. You selected an output parameter already assigned to another relay output.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check that no. unit-hours is within allowed range (1-9999)</li> <li>2. Check that output parameters are assigned correctly.</li> </ol>
Cannot store setpoint setup	Setpoint action is directed to a relay already allocated for pulsing	Check definition of setpoint actions
Cannot enter <b>reset</b> menu	<ol style="list-style-type: none"> <li>1. Reset function disabled</li> <li>2. You are at SEE level (viewing only)</li> </ol>	<ol style="list-style-type: none"> <li>1. Enable reset function in BASIC setup</li> <li>2. Go to CHG (editing) level</li> </ol>
No phase energy readings displayed	Phase energy not enabled in BASIC setup	Enable phase energy measurement
TXD LED flashes continuously after turning on instrument	Analog expander AX-7 outputs are allocated	If analog expander not used, analog outputs must be cancelled

<b>Problem</b>	<b>Probable Cause</b>	<b>What to do</b>
PCOMTEST program works continuously but TXD LED of PC COMPORT does not flash	<ol style="list-style-type: none"> <li>1. PC COMPORT number is not correct</li> <li>2. PC COMPORT setting uncorrected</li> <li>3. PC COMPORT is damaged</li> </ol>	<p>Change COMPORT number (setup of PCOMTEST);</p> <p>Check COMPORT card setting;</p> <p>Change COMPORT card</p>
Instrument RXD LED does not flash	Communication cable not connected properly	Check cable
Instrument TXD LED does not flash	Instrument COMPORT setting is not correct	<p>Check that instrument &amp; PC COMPORT settings match:</p> <p>RS Standard Address</p> <p>Data Format</p> <p>Baud rate</p> <p>Protocol name (ASCII or non-ASCII)</p>
PC COMPORT RXD LED does not flash	Communication cable not connected properly	Check cable
Instrument does not respond more than 1% of sessions in the ASCII or non-ASCII test	<ol style="list-style-type: none"> <li>1. ON the communication line there are a few instruments with the same address or instruments with address zero</li> <li>2. Analog expander outputs are allocated on the one of the instruments</li> </ol>	<ol style="list-style-type: none"> <li>1. Check every instrument separately</li> <li>2. Cancel the analog outputs if analog expander is not used</li> </ol>
PCOMTEST receives reply from the instrument with an incorrect check sum	Problems with the communication lines	<p>Check the communication line:</p> <p>Wires must be more than 0.33 mm<sup>2</sup> / 22 AWG</p> <p>Grounded screen</p> <p>Terminated resistors</p> <p>Communication line</p> <p>Distance &lt; 1200 m</p>

# Appendix: Technical Specifications

## **Input and Output Ratings**

3 Galvanically Isolated Voltage inputs	120 V:	INPUT USING PT (up to 120V+20% line-to-line voltage) Burden: <0.15 VA
	690 V:	DIRECT INPUT (up to 690V +15% line-to-line voltage) Burden: <0.5 VA INPUT USING PT - Burden: <0.15 VA
3 Galvanically Isolated Current inputs	1 A:	INPUT VIA CT with 1A secondary output Burden: <0.02 VA Overload withstand: 2A RMS continuous, 50A RMS for 1 second
	5 A:	INPUT VIA CT with 5A secondary output Burden: <0.1 VA Overload withstand: 10A RMS continuous, 250A RMS for 1 second
Voltage and Current Input terminals		UL recognized Maximum wire section: 4 mm <sup>2</sup> (10 AWG)
Optically Isolated Communication Port		EIA RS-422 and RS-485 standards Maximum wire section: 2.5 mm <sup>2</sup> (12 AWG)
2 Relay Outputs		Relay rated at 5A, 250 VAC/ 5A, 30 VDC 2 contacts (SPST Form A)
4 Optically Isolated Digital Inputs		Dry Contact
Optically Isolated Analog Output	4-20 mA default 0-20 mA (option) ± 1 mA (option)	Accuracy 0.5%, Non-linearity 0.2% Load up to 510 Ohm for 20 mA Load up to 10kOhm for 1 mA

<b>Display</b> (optional)	3 high-brightness seven-segment digital LEDs
---------------------------	--

## **Power Supply**

Galvanically isolated Power supply (factory set) 120&230 V AC and 110&220 V DC option 12 V DC option 24 V DC option 48 V DC	85 - 265V AC 50/60 Hz and 88 - 290V DC Burden 10 W 9.6 - 19 VDC 19 - 37 VDC 37 - 72 VDC
--	---

## **Environmental Conditions**

<i>Operating temperature</i>	-20°C to +60°C (-4°F to +140°F)
<i>Storage temperature</i>	-25°C to +80°C (-13°F to +176°F)
<i>Humidity</i>	0 to 95% non-condensing

## **Construction**

<i>Instrument body</i>	Case enclosure: Aluminum, anodized Dimension: 186x75x109 mm (7.33 x 2.95 x 4.30 ") Mounting: 35 mm DIN rail or wall mount or 4-inch panel mount
<i>Instrument weight</i>	0.94 kg (2.1 lb.)
<i>Display body</i>	Display body: plastic Front Panel: plastic ABS/PC blend Dimension: 114.3x114.3x20.0 mm (4.5x4.5x .787") Mounting: wall mount
<i>Display weight</i>	0.2 kg (0.44 lb.)

## **Standards Compliance**

<i>Standards</i>	<p>UL File # E129258  CE-EMC: 89/336/EEC as amended by 92/31/EEC and 93/68/EEC  CE-SAFETY: 72/23/EEC as amended by 93/68/EEC and 93/465/EEC  Harmonized standards to which conformity is declared:  EN55011:1991; EN50082-1:1992; EN61010-1:1993; A2/1995  ANSI C37.90.1 1989 Surge Withstand Capability (SWC)  ANSI C62.41 - 1991 Standard Surge  EN50081-2 Generic Emission Standard - Industrial Environment  EN50082-2 Generic Immunity Standard - Industrial Environment  EN55022: 1994 Class A  EN61000-4-2  ENV50140: 1983  ENV50204: 1995 (900MHz)  ENV50141: 1993  EN61000-4-4:1995  EN61000-4-8: 1993</p>
------------------	---

## Measurement Specifications

Parameter	Full Scale		Accuracy, %			Range	Display Resolution (%Rdg) @ @ range
			Rdg	FS	Conditions		
Voltage	120V×PT @ 120V	or For Ln reading and for 3OP2/3OP3 wiring modes		0.25	10% to 120% FS	0 to 999,000 V	1 V @ 1V to 9,999 V ≤0.1% @ 10,000 V to 999,000 V Starting voltage 1.5% FS
	380V×PT @ 660V						
	208V×PT @ 120V	or For LL reading except 3OP2/3OP3 wiring modes					
	660V×PT @ 660V						
Line current	CT PRIMARY CURRENT			0.25	2% to 120% FS	0 to 60,000 A	1 A @ 1A to 9,999 A ≤0.1% @ 10,000 A to 60,000 A Starting current 0.5% FS
Active power	0.36×PT×CT @ 120V input 1.2×PT×CT @ 690V input			0.5	PF  ≥ 0.5 ①	-2,000,000 to +2,000,000 kW	1 kW @ 1kW to 9,999 kW ≤0.1% @ 10 MW to 2,000 MW
Reactive power	0.36×PT×CT @ 120V input 1.2×PT×CT @ 690V input			0.5	PF  ≤ 0.9 ①	-2,000,000 to +2,000,000 kvar	1 kvar @ 1kvar to 9,999 kvar ≤0.1% @ 10 Mvar to 2,000 Mvar
Apparent power	0.36×PT×CT @ 120V input 1.2×PT×CT @ 690V input			0.5	PF  ≥ 0.5 ①	0 to 2,000,000 kVA	1 kVA @ 1kVA to 9,999 kVA ≤0.1% @ 10 MVA to 2,000 MVA
Power factor	1			1	PF  ≥ 0.5	-0.999 to +1.000	0.001
Frequency			0.1			45.00 to 65.00 Hz	0.01 Hz

Parameter	Full Scale	Accuracy, %			Range	Display Resolution (%Rdg) ② @ range
		Rdg	FS	Conditions		
Neutral (unbalanced) current	CT PRIMARY CURRENT		0.5	2% to 120% FS	0 to 60,000 A	1 A @ 1A to 9,999 A ≤0.1% @ 10,000 A to 60,000 A
Ampere demand	<i>same as for current</i>					
kW demand (block & sliding)	<i>same as for kW</i>					
kVA demand (block & sliding)	<i>same as for kVA</i>					
K-Factor	999.9	5 typical			1.0 to 999.9	0.1 (via communication)
Total harmonic distortion THD U (I), % U <sub>1</sub> (I <sub>1</sub> )	100		1.5	≥ 1% FS @ U(I) ≥ 10% FSU (FSI)	0 to 100	0.1
Total Demand harmonic distortion TDD (I), %	100		1.5	≥ 1% FS @ I ≥ 10% FSI	0 to 100	0.1
Active energy Import & Export				<i>according to power accuracy</i> ③	0 to 999,999 MWh	1 kWh @ 1 to 999999 kWh 10 kWh @ 1000 to 9,999 MWh 100 kWh @ 10 to 99.999 GWh 1MWh @ 100 to 999.9 GWh
Reactive energy Import & Export				<i>according to power accuracy</i> ③	0 to 999,999 Mvarh	1 kvarh @ 1 to 999999 kvarh 10 kvarh @ 1000 to 9,999 Mvarh 100 kvarh @ 10 to 99.999 Gvarh 1Mvarh @ 100 to 999.9 Gvarh

<b>Parameter</b>	<b>Full Scale</b>	<b>Accuracy, % Rdg FS Conditions</b>	<b>Range</b>	<b>Display Resolution (%Rdg) ② @ range</b>
<i>Apparent energy</i>		<i>according to power accuracy ③</i>	0 to 999,999 MVAh	1 kVAh @ 1 to 999999 kVAh 10 kVAh @ 1000 to 9,999 MVAh 100 kVAh @ 10 to 99.999 GVAh 1MVAh @ 100 to 999.9 GVAh

PT = external potential transformer ratio CT, CT PRIMARY CURRENT = primary current rating of external current transformer  
 FSU = full scale voltage FSI = full scale current  $U_1$  = voltage fundamental  $I_1$  = current fundamental

- ① @ 10% to 120% of voltage FS and 2% to 120% of current FS
- ② Higher resolution is achievable via communications
- ③ Where the current is > 10% FS, the energy accuracy is better than 1.5% Rdg.

### **Additional Notes**

1. Accuracy is expressed as  $\pm$  (percentage of reading + percentage of full scale)  $\pm$  1 digit. This does not include inaccuracies introduced by the user's potential and current transformers.
2. Specifications assume: voltage and current waveforms with THD  $\leq$  5% for kvar, kVA and PF; reference operating temperature: 20 - 26 °C.
3. Ordinary measurement error is considerably less than the specified accuracy which indicates maximum error.