



ezPAC™

Substation Automation Unit
SA310/SA320/SA330

Modbus Communications Protocol

Reference Guide

Every effort has been made to ensure that the material herein is complete and accurate. However, the manufacturer is not responsible for any mistakes in printing or faulty instructions contained in this book. Notification of any errors or misprints will be received with appreciation.

For further information regarding a particular installation, operation or maintenance of equipment, contact the manufacturer or your local representative or distributor.

This document is applicable to devices with firmware versions:

SA310N/SA320N/SA300N:

20.4.XX - Basic Fault + IEEE 1159 + IEC 61000-4-15 Flicker

20.5.XX - Basic Fault + EN 50160 + IEC 61000-4-15 Flicker + IEC 61000-4-7 Harmonics

XX.1X.XX + IEC 61850

REVISION HISTORY

A5	May 2007	F/W versions 10.3.20 or later, 10.4.XX, 10.5.XX, 10.6.XX. Added 0-50mA and $\pm 10V$ AI modules identification. Added cross-triggering setpoints via the Ethernet (UDP broadcast). Added Flicker registers. Added EN50160 setup registers and compliance statistics files. Added fast AI waveform channels.
A6	June 2008	Fixed EN50160 harmonic and interharmonic voltage compliance record structure.
A7	July 2009	F/W versions 10.XX.11 or later. Added support for 96 DI and 64 RO. Added relay blocking setup and status indication. Added SNTP client setup. Added 1PPS clock synchronization. Added a selectable EN 50160 transient overvoltage detection method option.
A8	Dec 2009	Added IEC 61850 GOOSE publisher and subscriber setup.
A9	Jan 2011	Added direct control ports blocking setup. Added IEC 61850 GOOSE subscriber update status register. Added TCP notification client. Added communication counters.
A10	Feb 2013	Applicable to F/W versions 20.XX.07 or later: Added IEC 61850 IED properties setup registers. Added bay controller configuration, monitoring and control registers. Applicable to F/W versions 20.XX.10 or later: Added AI 1/2 cycle, 1 sec, demand and Min/Max log registers. Added incremental/decremental delta and relative delta triggers.

Modbus is a trademark of Schneider Electric.

Table of Contents

1 GENERAL	10
2 MODBUS PROTOCOL IMPLEMENTATION.....	11
2.1 Transmission Modes	11
2.2 Address Field.....	11
2.3 Function Field	11
2.4 Exception Responses.....	11
2.5 Modbus Register Addresses	11
2.6 Data Formats.....	12
2.6.1 16-bit Scaled Integer Format	12
2.6.2 32-bit Long Integer Format	13
2.6.3 32-bit Modulo-10000 Format	14
2.7 User Assignable Registers	14
2.8 Password Protection.....	15
2.9 Data Recording and File Transfers	15
2.9.1 Log File Organization.....	15
2.9.2 File Transfers.....	17
2.10 TCP Notification Client	19
3 MODBUS REGISTER MAP	21
3.1 Modbus Setup Registers	21
Modbus Assignable Registers.....	21
Assignable Registers Map	21
Modbus Conversion Scales	21
3.2 16-bit Scaled Analog Values - Basic Register Set	22
3.3 16-bit Scaled Analog Values	24
1/2-Cycle Values	24
1-Cycle Phase Values.....	24
1-Cycle Low Phase Values	25
1/2-Cycle Analog Inputs.....	25
1-Cycle High Phase Values	26
1-Second Analog Inputs.....	26
1-Cycle Total Values.....	26
1-Cycle Auxiliary Values	26
Fundamental Phasor Values.....	27
1-Second Phase Values.....	27
1-Second Low Phase Values.....	28
1-Second High Phase Values	28
1-Second Total Values.....	29
1-Second Auxiliary Values	29
Present Harmonic Demands	29
Present Demands	29
Symmetrical Components	30
V1 Harmonics	30
V2 Harmonics	31
V3 Harmonics	31
I1 Harmonics.....	31
I2 Harmonics.....	31
I3 Harmonics.....	31
V1 Harmonic Voltages (odd numbers)	31
V2 Harmonic Voltages (odd numbers)	31
V3 Harmonic Voltages (odd numbers)	31
I1 Harmonic Currents (odd numbers).....	32
I2 Harmonic Currents (odd numbers).....	32
I3 Harmonic Currents (odd numbers).....	32
Total Harmonic kW (odd numbers)	32

Total Harmonic kvar (odd numbers).....	32
Total Harmonic Power Factor (odd numbers).....	32
V4 Harmonics	32
Flicker	32
I4 Harmonics.....	33
Minimum 1-Cycle Phase Values	33
Minimum 1-Cycle Total Values	34
Minimum 1-Cycle Auxiliary Values.....	34
Minimum Analog Inputs.....	34
Programmable Min/Max Minimum Values.....	34
V4 Harmonic Voltages (odd numbers).....	34
I4 Harmonic Currents (odd numbers).....	34
Maximum 1-Cycle Phase Values	35
Maximum 1-Cycle Total Values	35
Maximum 1-Cycle Auxiliary Values.....	36
Maximum Analog Inputs.....	36
Maximum Demands	36
Programmable Min/Max Maximum Values.....	36
Maximum Harmonic Demands.....	37
Maximum Analog Input Demands	37
Present Analog Input Demands	37
1-Cycle Analog Inputs	37
Raw Analog Inputs.....	37
Scaled Analog Outputs	38
Billing Summary Accumulated Demands	38
Billing Summary Block Demands	38
Billing Summary Sliding Window Demands	38
Billing Summary Maximum Demands	38
Billing TOU Maximum Demand Register #1.....	38
Billing TOU Maximum Demand Register #4.....	38
Billing TOU Maximum Demand Register #2.....	38
Billing TOU Maximum Demand Register #5.....	39
Billing TOU Maximum Demand Register #3.....	39
Billing TOU Maximum Demand Register #6.....	39
Billing TOU Maximum Demand Register #7.....	39
Billing TOU Maximum Demand Register #8.....	39
Billing TOU Maximum Demand Register #9.....	39
Billing TOU Maximum Demand Register #10.....	39
Billing TOU Maximum Demand Register #11.....	39
Billing TOU Maximum Demand Register #12.....	40
Billing TOU Maximum Demand Register #13.....	40
Billing TOU Maximum Demand Register #14.....	40
Billing TOU Maximum Demand Register #15.....	40
Billing TOU Maximum Demand Register #16.....	40
0.2-Second RMS and Auxiliary Values	40
3-Second RMS and Auxiliary Values	41
10-Minute RMS and Auxiliary Values.....	41
2-Hour RMS and Auxiliary Values.....	42
0.2-Second Harmonics.....	43
3-Second Harmonics.....	43
10-Minute Harmonics	44
2-Hour Harmonics.....	45
3.4 32-bit Binary and Analog Values	47
Setpoint Status.....	47
Special Inputs	47
Event Flags	47
Internal Pulsed Events	47
External Triggers (UDP).....	47
Periodic Timers	47
Digital Inputs	48
Pulse Inputs	48
Relay Outputs	48
Static Event Flags	48

Counters	49
Time/Date	49
1/2-Cycle Values	49
1-Cycle Phase Values	50
1-Cycle Low Phase Values	50
1/2-Cycle Analog Inputs	51
1-Cycle High Phase Values	51
1-Second Analog Inputs	51
1-Cycle Total Values	51
1-Cycle Auxiliary Values	52
Fundamental Phasor Values	52
1-Second Phase Values	52
1-Second Low Phase Values	53
1-Second High Phase Values	53
1-Second Total Values	54
1-Second Auxiliary Values	54
Present Harmonic Demands	54
Present Demands	55
Total Energies	56
Billing Summary Registers	56
Symmetrical Components	56
V1 Harmonics	56
V2 Harmonics	56
V3 Harmonics	56
I1 Harmonics	57
I2 Harmonics	57
I3 Harmonics	57
V1 Harmonic Voltages (odd numbers)	57
V2 Harmonic Voltages (odd numbers)	57
V3 Harmonic Voltages (odd numbers)	57
I1 Harmonic Currents (odd numbers)	57
I2 Harmonic Currents (odd numbers)	57
I3 Harmonic Currents (odd numbers)	58
Total Harmonic kW (odd numbers)	58
Total Harmonic kvar (odd numbers)	58
Total Harmonic Power Factor (odd numbers)	58
V4 Harmonics	58
Flicker	58
I4 Harmonics	58
Minimum 1-Cycle Phase Values	58
Minimum 1-Cycle Total Values	59
Minimum 1-Cycle Auxiliary Values	59
Minimum Analog Inputs	60
Programmable Min/Max Minimum Values	60
V4 Harmonic Voltages (odd numbers)	60
I4 Harmonic Currents (odd numbers)	60
Maximum 1-Cycle Phase Values	60
Maximum 1-Cycle Total Values	61
Maximum 1-Cycle Auxiliary Values	61
Maximum Analog Inputs	62
Maximum Demands	62
Programmable Min/Max Maximum Values	62
Maximum Harmonic Demands	62
Maximum Analog Input Demands	63
Present Analog Input Demands	63
1-Cycle Analog Inputs	63
Raw Analog Inputs	63
TOU Parameters	63
Scaled Analog Outputs	63
Billing TOU Register #1	63
Billing TOU Register #2	64
Billing TOU Register #3	64
Billing TOU Register #4	64

Billing TOU Register #5.....	64
Billing TOU Register #6.....	64
Billing TOU Register #7.....	64
Billing TOU Register #8.....	64
Billing TOU Register #9.....	64
Billing TOU Register #10.....	65
Billing TOU Register #11.....	65
Billing TOU Register #12.....	65
Billing TOU Register #13.....	65
Billing TOU Register #14.....	65
Billing TOU Register #15.....	65
Billing TOU Register #16.....	65
Billing Summary Accumulated Demands.....	65
Billing Summary Block Demands.....	66
Billing Summary Sliding Window Demands.....	66
Billing Summary Maximum Demands.....	66
Billing TOU Maximum Demand Register #1.....	66
Billing TOU Maximum Demand Register #4.....	66
Billing TOU Maximum Demand Register #2.....	66
Billing TOU Maximum Demand Register #5.....	66
Billing TOU Maximum Demand Register #3.....	66
Billing TOU Maximum Demand Register #6.....	67
Billing TOU Maximum Demand Register #7.....	67
Billing TOU Maximum Demand Register #8.....	67
Billing TOU Maximum Demand Register #9.....	67
Billing TOU Maximum Demand Register #10.....	67
Billing TOU Maximum Demand Register #11.....	67
Billing TOU Maximum Demand Register #12.....	67
Billing TOU Maximum Demand Register #13.....	67
Billing TOU Maximum Demand Register #14.....	68
Billing TOU Maximum Demand Register #15.....	68
Billing TOU Maximum Demand Register #16.....	68
0.2-Second RMS and Auxiliary Values.....	68
3-Second RMS and Auxiliary Values.....	69
10-Minute RMS and Auxiliary Values.....	69
2-Hour RMS and Auxiliary Values.....	70
0.2-Second Harmonics.....	70
3-Second Harmonics.....	71
10-Minute Harmonics.....	72
2-Hour Harmonics.....	73
Present EN50160 PQ Values.....	73
External Integer Measured Values.....	74
External Float Measured Values.....	74
External Indication.....	75
Switch Position Indication.....	75
Switch Operation-Open Indication.....	75
Switch Operation-Close Indication.....	75
Switch Operation Counters (resettable).....	76
Generic TOU Energy Registers.....	76
Generic TOU Maximum Demand Registers.....	76
Generic Data.....	76
3.5 Minimum/Maximum Log Registers.....	80
Minimum Phase Values.....	80
Minimum Total Values.....	81
Minimum Analog Inputs.....	82
Minimum Auxiliary Values.....	82
Programmable Min/Max Minimum Values.....	82
Maximum Analog Inputs.....	82
Maximum Phase Values.....	83
Maximum Total Values.....	84
Maximum Analog Input Demands.....	85
Maximum Auxiliary Values.....	85
Billing Summary Maximum Demands.....	85

Maximum Demands	86
Programmable Min/Max Maximum Values.....	87
Maximum Harmonic Demands	87
Billing TOU Maximum Demand Register #1	87
Billing TOU Maximum Demand Register #4.....	88
Billing TOU Maximum Demand Register #2.....	88
Billing TOU Maximum Demand Register #5.....	88
Billing TOU Maximum Demand Register #3.....	88
Billing TOU Maximum Demand Register #6.....	88
Billing TOU Maximum Demand Register #7.....	89
Billing TOU Maximum Demand Register #8.....	89
Billing TOU Maximum Demand Register #9.....	89
Billing TOU Maximum Demand Register #10.....	89
Billing TOU Maximum Demand Register #11.....	89
Billing TOU Maximum Demand Register #12.....	90
Billing TOU Maximum Demand Register #13.....	90
Billing TOU Maximum Demand Register #14.....	90
Billing TOU Maximum Demand Register #15.....	90
Billing TOU Maximum Demand Register #16.....	90
3.6 Device Control and Status Registers	92
Event Flags Registers (bitmap).....	92
Remote Relay Control Registers (bitmap).....	92
Reset/Clear Registers	93
Device Mode Control Registers	93
UDP Cross-trigger Register	93
Memory Status Registers.....	93
Log Notification Registers (bitmap)	93
Setpoint Status Registers (bitmap)	93
Setpoint Alarm Latch Registers (bitmap).....	93
Device Diagnostics Register (bitmap)	94
GOOSE Subscriber Status Register (bitmap)	94
Port Identification	94
Current Network Settings	94
Device Authorization Register.....	94
Communication Counters.....	94
Switch Remote Control Registers	94
Switch Status Registers	95
Factory Diagnostic Registers	96
3.7 Device Setup Registers	97
Device Identification.....	97
Factory Device Settings	97
Basic Setup.....	97
Demands Setup	98
Device Options Setup	98
Time/Date Setup	99
Clock Setup and Status.....	99
Communication Ports Setup	99
Network Setup	100
Password Setup.....	100
IEC 61850 License Setup	101
Expert Power Service Setup	101
Internet Service Provider (ISP) account.....	101
SNTP Client Setup.....	101
TCP Notification Client Setup.....	101
GOOSE Subscriber Setup	101
GOOSE Publisher Setup.....	102
IEC 61850 IED Setup.....	102
IEC 61850 Dataset Setup	103
IEC 61850 RCB Setup	103
IEC 61850 Report Deadbands	104
EN50160 PQ Recorder Triggers Setup (EN50160 voltage characteristics)	104
Advanced EN50160 Setup.....	104
EN50160 Harmonic Voltage Limits	105

EN50160 Interharmonic Voltage Limits.....	106
DNP Options Setup.....	106
DNP Events Setup.....	106
DNP Class 0 Point Assignment.....	107
SOE Log Labels.....	107
Fault Log Triggers Setup.....	108
Fault Log Recording Setup.....	108
IEEE 1159 PQ Log Triggers Setup (IEEE 1159 disturbance categories).....	108
File Setup.....	109
Waveform Recorder Setup.....	110
Data Log Setup.....	110
Programmable Min/Max Log Setup.....	111
TOU Daily Profile Setup.....	112
TOU Calendar Years Setup.....	112
TOU Calendar Setup.....	113
Billing/TOU Registers Setup.....	115
Billing/TOU Registers Source Setup.....	116
Control Setpoints Setup (SP1-SP32).....	116
Control Setpoints Setup (SP1-SP64).....	117
Switching Device Setup.....	118
Periodic Timers Setup.....	120
Energy Pulse Source Setup.....	120
Counters Setup.....	120
Counter Source Setup.....	121
Digital Inputs Setup DI1-DI64.....	121
Digital Inputs Setup DI65-DI128.....	121
Relay Outputs Setup.....	121
Analog Inputs Setup.....	122
Analog Outputs Setup.....	122
3.8 Expansion I/O Slots Configuration.....	123
Expansion I/O Slots Configuration Info.....	123
Expansion I/O Modules Type Info.....	123
3.9 File Transfer Blocks.....	125
File Transfer Control Blocks.....	125
File Info Response Block (Variation 0 – File info).....	126
File Info Response Block (Variation 1 – Current record info).....	127
File Info Response Block (Variation 2 – Data log record structure).....	127
Event Log Response Block.....	128
Data Log Response Block.....	128
Waveform Log Response Block.....	129
Sequence of Events (SOE) Log Response Block.....	129
Power Quality (PQ) Log Response Block.....	130
Fault Log Response Block.....	131
File Response Block Alias.....	132
Power Quality (PQ) Log Response Block Alias.....	132
3.10 EN 50160 Compliance Statistics Data Log.....	134
3.11 EN 50160 Harmonics Survey Statistics Data Log.....	140
3.12 Billing/TOU Daily and Monthly Profile Data Logs.....	141
4 DATA SCALES AND UNITS.....	143
Data Scales.....	143
Data Units.....	143
5 DATA FORMATS.....	144
Timestamp.....	144
File ID.....	144
File Attributes.....	144
File Status Word (bitmap).....	144
File Record Status Word (bitmap).....	144
Billing/TOU Profile Log Channel ID.....	144
Waveform Log Channel ID.....	144
Billing/TOU Profile Log Channel Mask (bitmap).....	145

Waveform Log Channel Mask (bitmap).....	145
TOU Tariff Change Time.....	145
Billing Register Source ID	145
Setpoint Trigger Parameters ID	146
Setpoint Relational Operator.....	146
Setpoint Action ID	146
Energy Pulse Source ID.....	146
Counter Source ID	147
Relay Output Pulse Source ID	147
AO Parameters ID (see Section 3.4 for data scales)	147
Event Source/Point ID.....	148
Event Effect ID.....	148
Data/Function Point ID.....	149
Event Type ID	150
Device Diagnostics (bitmap)	150
DNP Object Types	151
DNP Class 0 Objects	151
Wiring Mode.....	152
IEC 61850 Measured Value Indices.....	152

1 General

This document specifies a subset of the Modbus communications protocol used to transfer data between a master computer station and the SA300. The document provides the complete information necessary to develop third-party communications software capable of communication with the SA300. Refer to the SA300 Installation Manual and SA300 Operation Manual for more information on communication connections and configuring communication parameters in your device.

2 Modbus Protocol Implementation

For detailed information on the Modbus protocol, message framing and error checking, refer to the Modbus Protocol Reference Guide. It can be downloaded from the Modbus-IDA Website at <http://www.modbus.org/>. The following paragraphs outline some issues concerning the implementation of the Modbus protocol in the SA300.

2.1 Transmission Modes

The SA300 can be set up to communicate on a serial Modbus network using either RTU, or ASCII serial transmission mode, and via the Internet using Modbus/TCP mode. Refer to the SA300 Operation Manual for information on selecting the transmission mode in your device.

2.2 Address Field

The address field contains a user assigned address of the instrument (1-247) on a Modbus network. Broadcast mode using address 0 is not supported.

When communicating via the Internet, the address field is not checked and is returned in the response message header.

2.3 Function Field

The Modbus functions implemented in the SA300 are shown in Table 2-1. Function 04 can be used in the same context as function 03.

Table 2-1 Modbus Function Codes

Code (decimal)	Meaning in Modbus	Action
03	Read holding registers	Read multiple registers
04	Read input registers	Read multiple registers
06	Preset single register	Write single register
16	Preset multiple registers	Write multiple registers
22	Mask write	Set or clear individual bits
08 ¹	Loop-back test	Communications test

¹ The SA300 supports only diagnostic code 0 - return query data.

2.4 Exception Responses

The instrument sends an exception response when an error is detected in the received message. To indicate that the response is notification of an error, the high order bit of the function code is set to 1.

Implemented exception response codes:

- 01** - Illegal function
- 02** - Illegal data address
- 03** - Illegal data value
- 04** - Device failure

When the character framing, parity, or redundancy check detects a communication error, processing of the master's request stops. The instrument will not act on or respond to the message.

2.5 Modbus Register Addresses

The SA300 Modbus registers are numbered in the range of 0 to 65535. From the Modbus applications, the SA300 Modbus registers can be accessed by simulating

holding registers of the Modicon 584, 884 or 984 Programmable Controller, using a 5-digit "4XXXX" or 6-digit "4XXXXX" addressing scheme. To map the SA300 register address to the range of the Modbus holding registers, add a value of 40001 to the SA300 register address. When a register address exceeds 9999, use a 6-digit addressing scheme by adding 400001 to the SA300 register address.

2.6 Data Formats

The SA300 uses three data formats to pass data between a master application and the instrument: 16-bit short integer, 32-bit long integer and 32-bit modulo-10000 formats. Binary values and counters are always transmitted in 32-bit registers, while analog values can be read both in 32-bit and in 16-bit scaled registers.

Analog registers 256 through 308 and 4320 through 10751 contain scaled 16-bit values.

2.6.1 16-bit Scaled Integer Format

16-bit scaled data is transmitted in a single 16-bit Modbus register as unsigned (UINT16) integer (whole) numbers using the linear conversion to accommodate large-scale and fractional numbers to a 16-bit register format. The linear conversion uses two scales to read the raw data from the device and convert it into engineering units: the device original engineering scale and the Modbus conversion scale.

When transmitting measured data, the device scales it into the range of Modbus Low and High conversion scales. To reconstruct data in the original engineering units, perform the reverse conversion according to the following formula:

$$\text{Engineering_Units} = \frac{\text{Raw_Data} \times (\text{ENG_HI} - \text{ENG_LO})}{\text{RAW_HI} - \text{RAW_LO}} + \text{ENG_LO}$$

where:

ENG_LO and ENG_HI	-	reading low and high scales in engineering units
RAW_LO and RAW_HI	-	raw data low and high scales (by default, 0 and 9999)
Raw_Data	-	raw input data in the range of RAW_LO to RAW_HI
Engineering_Units	-	true value in engineering units

The default Modbus conversion scales are 0 for the low scale and 9999 for the high scale. This means that the scaled analog data is always transmitted in the range of 0 to 9999. The Modbus conversion scales can be changed through communications via registers 240 and 241.

The engineering scales are separately indicated for each scaled 16-bit register. For data scales and measurement units that depend on the device input scales (such as volts, amps and powers), refer to Chapter 4 "Data Scales and Units".

Conversion Examples

1. Voltage readings

a) Assume device settings (direct wiring): PT ratio = 1.

Voltage engineering scales (see Chapter 4):

$$\begin{aligned} \text{HI_ENG} &= V_{\text{max}} = 828.0 \times \text{PT ratio} = 828.0 \times 1 = 828.0\text{V} \\ \text{LO_ENG} &= 0\text{V} \end{aligned}$$

If the raw data reading is 1449 then the voltage reading in engineering units will be as follows:

$$\text{Volts reading} = 1449 \times (828.0 - 0) / (9999 - 0) + 0 = 120.0\text{V}$$

b) Assume device settings (wiring via PT): PT ratio = 14,400V : 120V = 120.

Voltage engineering scales (see Chapter 4):

$$\begin{aligned} \text{HI_ENG} &= V_{\text{max}} = 828.0 \times \text{PT ratio} = 828 \times 120 = 99,360\text{V} \\ \text{LO_ENG} &= 0\text{V} \end{aligned}$$

If the raw data reading is 1449 then the voltage reading in engineering units will be as follows:

$$\text{Volts reading} = 1449 \times (99360 - 0)/(9999 - 0) + 0 = 14,399V$$

2. Current readings

Assume device settings: CT primary current = 200A; current input overload = 400% (20A).

Current engineering scales (see Chapter 4):

$$\begin{aligned} \text{HI_ENG} &= I_{\text{max}} = \text{CT primary current} \times 4 = 200.00 \times 4 = 800.00A \\ \text{LO_ENG} &= 0A \end{aligned}$$

If the raw data reading is 250 then the current reading in engineering units will be as follows:

$$\text{Amps reading} = 250 \times (800.00 - 0)/(9999 - 0) + 0 = 20.00A$$

3. Power readings

a) Assume device settings (direct wiring): PT = 1; CT primary current = 200A; current input overload = 400% (20A).

Active Power engineering scales (rounded to whole kW, see Chapter 4):

$$\begin{aligned} \text{HI_ENG} &= P_{\text{max}} = V_{\text{max}} \times I_{\text{max}} \times 2 = (828.0 \times 1) \times (200.00 \times 4) \times 2 = 1,324,800 \text{ W} = 1325 \text{ kW} \\ \text{LO_ENG} &= -P_{\text{max}} = -1325 \text{ kW} \end{aligned}$$

If the raw data reading is 5500 then the power reading in engineering units will be as follows:

$$\text{Watts reading} = 5500 \times (1325 - (-1325))/(9999 - 0) + (-1325) = 132.6 \text{ kW}$$

If the raw data reading is 500 then the power reading in engineering units will be as follows:

$$\text{Watts reading} = 500 \times (1325 - (-1325))/(9999 - 0) + (-1325) = -1192.5 \text{ kW}$$

b) Assume device settings (wiring via PT): PT = 120; CT primary current = 200A; current input overload = 400% (20A).

Active Power engineering scales (rounded to whole kW, see Chapter 4):

$$\begin{aligned} \text{HI_ENG} &= P_{\text{max}} = V_{\text{max}} \times I_{\text{max}} \times 2 = (828 \times 120) \times (200.00 \times 4) \times 2/1000 = 158976 \text{ kW} \\ \text{LO_ENG} &= -P_{\text{max}} = -158976 \text{ kW} \end{aligned}$$

If the raw data reading is 5500 then the power reading in engineering units will be as follows:

$$\text{Watts reading} = 5500 \times (158976 - (-158976))/(9999 - 0) + (-158976) = 15915 \text{ kW}$$

If the raw data reading is 500 then the power reading in engineering units will be as follows:

$$\text{Watts reading} = 500 \times (158976 - (-158976))/(9999 - 0) + (-158976) = -143077 \text{ kW}$$

4. Power Factor readings

Power factor engineering scales (see Chapter 4):

$$\begin{aligned} \text{HI_ENG} &= 1.000. \\ \text{LO_ENG} &= -1.000. \end{aligned}$$

If the raw data reading is 8900 then the power factor in engineering units will be as follows:

$$\text{Power factor reading} = 8900 \times (1.000 - (-1.000))/(9999 - 0) + (-1.000) = 0.78$$

2.6.2 32-bit Long Integer Format

32-bit long integer data is transmitted in two adjacent 16-bit Modbus registers as unsigned (UINT32) or signed (INT32) whole numbers. The first register contains the low-order word (lower 16 bits) and the second register contains the high order word (higher 16 bits). The low-order word always starts at an even Modbus address. The value range for unsigned data is 0 to 4,294,967,295; for signed data the range is -2,147,483,648 to 2,147,483,647.

If your Modbus driver does not support a 32-bit long integer format, you can read the two 16-bit registers separately, and then convert them into a 32-bit value as follows (using C notation):

$$\text{32-bit value} = (\text{signed short})\text{high_order_register} \times 65536L + (\text{unsigned short})\text{low_order_register}$$

Examples

1. Unsigned 32-bit Values

If you read unsigned Voltage V1 of 69,000V from registers 13952-13953, then the register readings will be as follows:

$$\begin{aligned}(13952) &= 3464 \\ (13953) &= 1\end{aligned}$$

The 32-bit value is $(1 \times 65536 + 3464) = 69000V$.

2. Signed 32-bit Values

If you read signed kW of -789kW from registers 14336-14337, then the register readings will be:

$$\begin{aligned}(14336) &= 64747 \text{ (unsigned)} \\ (14337) &= 65535 \text{ (unsigned) or } -1 \text{ (signed value)}.\end{aligned}$$

To take the high order register as a signed value, compare it with 32767. If the value is less or equal to 32767, use it as is. If it is greater than 32767, then this is a negative number in a two's complement code (like in our example) - just subtract it from 65536 to get the original negative value.

The 32-bit reading is $(-1 \times 65536 + 64747) = -789kW$.

Fractional 32-bit data is transmitted using decimal scaling to pass fractional numbers in integer format. Fractional numbers are pre-multiplied by 10 to the power N, where N is the number of digits in the fractional part. For example, the frequency reading of 50.01 Hz is transmitted as 5001, having been pre-multiplied by 100.

Whenever a data register contains a fractional number, the register measurement unit is given with a multiplier $\times 0.1$, $\times 0.01$ or $\times 0.001$, showing the weight of the least significant decimal digit. To get an actual fractional number with specified precision, multiply the register value by the given multiplier. To write a fractional number into the register, divide the number by the given multiplier.

2.6.3 32-bit Modulo-10000 Format

Energy counters 287-294 and 301-302 are read in two contiguous 16-bit registers in a modulo-10000 format. The first (low order) register contains the value mod 10000, and the second (high order) register contains the value/10000. To get the true energy reading, the high order register value should be multiplied by 10,000 and added to the low order register.

2.7 User Assignable Registers

The SA300 provides 120 user assignable registers in the address range of 0 to 119. You can re-map any register available in the device to any assignable register so that Modbus registers that reside at different locations may be simply accessed using a single request by re-mapping them to adjacent addresses.

The actual addresses of the assignable registers, which are accessed via addresses 0 through 119, are specified in the register map (registers 120 through 239), where register 120 contains the actual address of the register accessed via register 0, register 121 contains the actual address of the register accessed via register 1, and so on. The assignable registers and the map registers themselves may not be re-mapped.

Initially these registers are reserved and none of them points to an actual register address. To build your own register map, write to map registers 120 to 239 the actual addresses you want to read from or write to via the assignable area (registers 0 to 119). 32-bit long registers should always be aligned at even addresses. For example, to read registers 4672 (1-second V1 voltage, scaled short integer) and 14720-14721 (kWh Import, long integer) via registers 0-2, do the following:

- write 14720 to register 120
- write 14721 to register 121
- write 4672 to register 122

Reading from registers 0-2 will return the kWh reading in registers 0 (low 16 bits) and 1 (high 16 bits), and the voltage reading in register 2.

2.8 Password Protection

The SA300 has a password protection option allowing you to protect your setups, cumulative registers and logs from being changed or cleared through communications. You can disable or enable password protection through communications, the RDM or via the Terminal. For details, refer to your instrument Operation Manual.

A user password must be written into the device authorization register (44378-44379) before another write request is issued. If the correct password is not supplied while password protection is enabled, the device will respond to all write requests with the exception code 01 (illegal operation). It is recommended to clear the password register after you have completed your changes in order to activate password protection.

2.9 Data Recording and File Transfers

2.9.1 Log File Organization

Historical files are stored to the non-volatile memory with battery backup. Memory is allocated for each file statically when you set up your files and will not change unless you re-organize the files. The SA300 automatically performs de-fragmentation of the memory each time you re-organize your files. This prevents possible leakage of memory caused by fragmentation.

Data records in a file are arranged in the order of their recording. Each record has a unique 16-bit sequence number that is incremented modulo 65536 with each new record. The sequence number can be used to point to a particular record in the file, or to check the sequence of records when uploading files from the device.

Each file has a write position pointer that indicates the place where the next record will be recorded, and a read position pointer that indicates the place from where the current record will be read. Both pointers show sequence numbers of the records they point to rather than record offsets in the file.

After acknowledging a record you have read, the read pointer automatically advances to the next record in the file. When the read pointer gets to the record to which the file write pointer points, the end-of-file (EOF) flag is set. It is automatically cleared when a new record is added to the file, or when you explicitly move the read pointer to any record within a file.

If a file has a wrap-around attribute (circular file), the most recent records can overwrite the oldest records. When this happens at the current read position, the read pointer automatically advances forward in order to point to the oldest record in the file.

The SA300 keeps a separate read pointer for each communication port so that access to the same file through a different port will not affect current active sessions for other ports.

Multi-section Files

Log files can have one or more (up to 32) sections for multi-channel recording. An ordinal file consists of a single section. Some files, such as TOU profile log files and waveform log files, are arranged as multi-section files.

A multi-section file is subdivided into multiple sections of the same structure, one section per recording channel. The number of sections in each file is defined at the time you set up your files and may not change unless you re-organize the file. Sections within a multi-section file can be addressed by a section number, or by a section channel ID.

A multi-section file has a single write position pointer for all sections and stores data in all sections simultaneously. This means that records with the same sequence number in all sections are associated with the same event. A multi-section file has also a single read position pointer for all sections.

Data Log Files

Conventional data log files can store up to 16 measured parameters per a record. Any data measured by the device can be stored in the log file. The number of parameters that each record will hold and the list of parameters you want to be recorded in the file can be selected through the Data log setup registers for a particular file.

Recording data to data log files can be triggered through the setpoints, either on a time basis, or upon any event detected by the setpoints.

TOU Profile Log Files

Data log files #15 and #16 can be configured for monthly and daily profile logs of the energy usage and maximum demand registers. A profile log file is organized as a multi-section file that has a separate section for each energy and maximum demand register. See Section 3.12 for more information on the file record structure. A file record stores all tariff data for each configured Billing/TOU register.

The number of sections is taken automatically from the Billing/TOU Registers setup. In order to correctly allocate memory space, configure your TOU registers before you set up TOU profile files.

Since each Billing/TOU energy register has a shadow maximum demand register, the number of sections in the file will be twice the number of the allocated Billing/TOU registers.

Power Quality Statistics Log Files

Data log files #9 and #10 are configured to store the power quality statistics data on a daily or weekly basis. They are organized as multi-section files. See Sections 3.10-3.11 for more information on the file record structure. You can review the list of parameters recorded to the files through the file info request/response blocks using info requests with variation 2 (see Section 3.9).

Waveform Log Files

Waveform log files are organized as multi-section files that store data for each recording channel in a separate section. A waveform log file can record up to 12 channels simultaneously: eight AC channels (four voltages and four currents), a VDC channel, and 3x16 digital inputs DI1:16, DI17:32, DI33:48 that are recorded as three 16-bit analog channels. In devices with a fast AI option, a file can additionally record 16 analog input channels.

The number of sections, or channels, that a file can store, is defined in the file setup. The waveform log setup allows selecting channels that a file will record. All selected channels are recorded in successive file sections.

A waveform file has a single read pointer for all sections, so that data from all channels of a single record can be read together without repositioning the file pointer. When you point to a particular file record, data from all sections related to the same event are all available for a read. Moreover, the SA300 takes all channel data for the currently accessed record to a separate buffer, so that even when the record is overwritten at the time of reading, you are still prevented from receiving partially updated data. You can also read a file in a common sequential manner section-by-section.

A single waveform record for a channel can contain up to 512 points of the sampled input signal. VDC, DI and AI channels are sampled at different rates than AC channels and may contain fewer points than the corresponding AC records. Refer to the sampling rate field in the channel records to correctly set up the time scale for the VDC, DI and AI waveforms. If the record contains less than 512 points, the value of unused points is unpredictable.

If a waveform log is configured to record more samples per event than a single record can hold, the waveform recorder will store as many records per event as required to record the entire event. All waveform records related to the event are merged in a series and have the same series number, so that they can all be plotted together. Each record within a series has a unique serial number that allows tracking the sequence of records in the series. A single waveform series can hold up to 347,136 points (10,848 cycles at a rate of 32 samples per cycle) of a sampled AC signal.

2.9.2 File Transfers

File transfer protocol provides both data transfer and information services. File transfer is performed through two blocks of registers: a 32-word master request block and a 1792-word read-only file response block. After a master application has written the request into the file request block, the requested data is available for a read through the file response block registers. File transfer functions allow changing the file or section position in order to point to the desired record.

The information service uses separate 8-word file info request and 200-word file info response blocks. The extended file information is available including current file pointers' positions, file contents, the number of records in the file, allocated file size, time of file creation, time of the last file update and reset, and more.

Common File Transfer

Log files can be read either in a sequence record-by-record, or in a random order. Each Read-File request fills the file response block with the data of the record pointed to by the file (or section) read pointer. If you want to begin reading a file from a particular record, which sequence number is known, you can change the pointer position by issuing the Set-File-Position request with the desired sequence number. If you want to read a file from the beginning, send the Reset-File-Position request that moves the pointer to the oldest file record. If you do not change the file position, then you will continue reading the file from the record following the one you have read the last time you accessed the file.

You need not explicitly move the file position to the following record if you want to continue reading a file in sequence after you have uploaded the current record. Instead, issue an acknowledgment request that automatically advances the file pointer to the next record, and then read the record data through the file response block.

The file response block can contain more than one record. The number of records available in the block and the file record size in words are always reported in the block heading. There are no special rules on how to read records from the file transfer block. You can read a single record or all records together, or begin reading from the last record and end with the first record. However, you should remember: 1) after an acknowledgment, the file position moves to the record following the last one you have accessed in the file transfer block; and 2) data in the file transfer block does not change until you either issue an acknowledgment, or explicitly change the file position by the Set-File-Position or Reset-File-Position requests.

The file transfer is completed after you have read the last record of the file. Before storing a file record to your database, always check bit 9 in the record status word, which contains the end-of-file (EOF) flag. This bit set to 1 indicates that the file read pointer does not point to any record within the file, and you should not store any record that has this bit set. The EOF flag is set only after you have acknowledged the last record of the file, so that testing for end-of-file requires one extra read. If you wish to stop the transfer just after storing the last file record, acknowledge the record and check bit 0 in the record status word. Bit 0 is set to 1 only once when you read the last record of the file.

The following gives a summary of steps you should do to read an ordinal log file:

1. If you want to begin reading a file from a particular record or from the first record, use either the Set-File-Position request with the desired record sequence number, or the Reset-File-Position request. Preset a section number and channel ID to zero.
2. Write the Read-File request with a section number and channel ID set to zero.
3. Read the record data from the file response block.
4. Write an acknowledgment for the file. You need not fill all the request fields: only the file function is required. The file pointer will be moved to the next file record.

Repeat steps 3-4 until all the file records are read.

Reading Multi-section Data Log Files

In a multi-section data log file, all user requests including an acknowledgment, the Read-File, Set-File-Position and Reset-File-Position requests, relate to a particular file

section rather than to the file itself. The only request that affects the entire file is the Erase-File that clears all the file sections together.

A file section can be requested either by a section number, or by a section channel ID. If you use a channel ID, preset the section number field to 0xFFFF. If a section number is specified, the channel ID field will not be checked. The device returns both fields in the response block heading, so you can always identify what channel data is being read from the present file section. If you want to know which channels are recorded to the file sections, check the file channel mask in the file info block. This is a bitmap that contains one in a bit position if a channel with an ID equal to the bit number is recorded to the file, and contains zero if it is not.

The following gives a summary of steps for reading a multi-section data log file:

5. If you wish to begin reading a file section from a particular record or from the first record, use either the Set-File-Position request with the desired record sequence number, or the Reset-File-Position request. Specify either a section number, or the channel ID for the section from where you want to read data. If you use a channel ID, preset the section number field to 0xFFFF.
6. Write the Read-File request with the section number and channel ID as shown in the previous step.
7. Read the record data from the file response block.
8. Write an acknowledgment for the file. The file section pointer will be moved to the next record.

Repeat steps 3-4 until all the section records are read.

Reading Multi-section Waveform Files

Waveform files can be read as conventional multi-section files in the order described above. Another way is to take advantage of the fact that waveform files have a single read pointer for all file sections, so you can read records of all the channels related to the same event at once without repositioning the file pointer. The following gives a summary of steps for reading waveform files:

1. If you want to begin reading a file from a particular record or from the first record, use either the Set-File-Position request with the desired record sequence number, or the Reset-File-Position request. Preset the section field to zero.
2. Write the Read-File request. Address your request to the first file section (its number is always zero), or to the first file channel (if you know channel's ID). If you use a channel ID, preset the section number field to 0xFFFF.
3. Read the channel's data from the file response block. Store the received record's sequence number.
4. Write the Read-File request for the next file section or channel using the stored record sequence number. The file response block will be refilled with the data for the requested channel that is related to the record with the same sequence number.
5. Repeat steps 3, 4 until all the channel records with the current sequence number are read.
6. Write an acknowledgment. The file pointer will be moved to the next record.

Repeat steps 2-6 until all the file records are read.

Reading Real-time Waveforms

Real-time waveforms are accessed through the same transfer blocks just like the waveform log files by addressing file 128. Writing the Read-File request for file 128 provides a simultaneous capture of 6 real-time waveform records – three voltage and three current waveforms – into a communication buffer that can be read through the common file response block. The following gives a summary of steps for reading real-time waveforms:

1. Write the Read-File request for file 128. Address you request to the first file section (its number is always zero), or to the first file channel (if you know channel's ID). If you use a channel ID, preset the section number field to 0xFFFF.
2. Read the channel's data from the file response block.
3. Write the Read-File request for the next file section or channel. The file response block will be refilled with the data for the requested channel.
4. Repeat steps 3, 4 until all the channel records are read.

Write an acknowledgment to release the buffer.

2.10 TCP Notification Client

The TCP notification client can establish connections with a remote Modbus/TCP server and send notification messages either on events, or periodically on a time basis.

Notification messages are sent via a block of 24 Modbus registers using write function 16. The following table shows the message exchange structure.

Modbus Register Offset	Description	Type	Comment
+0-1	Device serial number	UINT32	
+2-4	Device MAC address	CHAR6	
+5	Device address	UINT16	1 for Ethernet
+6-7	Device IP address	UINT32	Network byte order
+8	Event type	UINT16	See F22 in Section 5
+9	Event sequence number	UINT16	
+10-11	Start event timestamp, seconds	UINT32	Local time since Jan 1, 1970
+12-13	Start event timestamp, seconds fraction, in microseconds	UINT32	
+14-15	End event timestamp, seconds	UINT32	Local time since Jan 1, 1970
+16-17	End event timestamp, seconds fraction, in microseconds	UINT32	
+18	Not used	UINT16	Written as 0
+19	Critical trigger ID	UINT16	See Table below
+20-21	Critical trigger value	UINT32	See Table below
+22-23	Reserved	UINT32	Written as 0

The reported trigger type and value depend on the event source and are described in the following table.

Event Source	Trigger Type	Trigger Value
Setpoint events	Critical setpoint trigger caused setpoint operation or release (see F12 in Section 5)	Trigger entering or return value
PQ events	PQ event trigger. For polyphase events, the worst phase is reported (see Generic Data in Section 3.4)	Maximum fault magnitude on the reported phase
Fault events	Current phase with highest recorded fault current (see Generic Data in Section 3.4)	Maximum fault current magnitude on the reported phase

After receiving a write acknowledgement from a server, a TCP connection is still open for 10 seconds to give the server an opportunity to access meter registers through an open socket. It may help you access the meter from outside your local network when the server is located on another network. The notification client will respond to all server requests as if it were a regular incoming connection.

In case a client connection is not used for following data transfers, it is recommended for the server to close the connection immediately after sending a write acknowledgement; otherwise there will be a 10-second delay before the next notification may be sent.

If there is no activity on the connection socket, it will be closed in 10 seconds. In the event a connection attempt was unsuccessful, the notification client retries two more times before announcing a connection failure.

The server's IP address, port number and starting Modbus register address are programmable in the meter. To configure and enable the notification client in your meter via PAS, select Communication Setup in the Meter Setup menu, and click on the TCP Notification Client Setup tab.

Client connections are triggered via programmable setpoints. To send event notifications to a server, configure a setpoint to respond to desired triggers or to periodic time events and add the "Send notification" action to the end of the setpoint actions list.

Setpoint operation events triggered by regular analog and digital triggers are reported twice - when the event starts and when it ends, except of the pulsed events and time triggers that will be reported once. In the start notification message, the event end timestamp is zeroed, and the critical trigger value indicates its entering value, while the second notification message gives both the event start and end time and shows the trigger return value.

In case of triggering notifications with events generated by the PQ and Fault recorders, like the PQ EVENT, FAULT EVENT, EXTERNAL TRIGGER or FAULT DETECTED triggers, the recorded power quality or/and corresponding fault events are reported instead of setpoint-triggered notifications. Notification messages contain the fault event start and end time, a critical phase and the maximum fault magnitude on the reported phase. If regular triggers are added to the setpoint triggers list, then the setpoint operation events will also be reported.

3 Modbus Register Map

3.1 Modbus Setup Registers

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
Modbus Assignable Registers							
0-119							
+0		Register 0 contents	0-65535		UINT16	R/W	
+1		Register 1 contents	0-65535		UINT16	R/W	
		...					
+119		Register 119 contents	0-65535		UINT16	R/W	
Assignable Registers Map							
120-239							
+0		Register 0 address	0-65535		UINT16	R/W	
+1		Register 1 address	0-65535		UINT16	R/W	
+119		Register 119 address	0-65535		UINT16	R/W	
Modbus Conversion Scales							
240		Low raw scale	0-65535 (default 0)		UINT16	R/W	
241		High raw scale	1023-65535 (default 9999)		UINT16	R/W	
242		Voltage scale, secondary volts	60-828 (default 828V)	1V	UINT16	R/W	
243		Current scale, secondary amps	10-200 (default CT secondary current x Current Overload)	×0.1A	UINT16	R/W	

3.2 16-bit Scaled Analog Values - Basic Register Set

Address	Point ID	Description	Low and High Scales ²	Units ²	Type	R/W	Notes
256-308		1-Second Values					
+0	0x1100	V1/V12 voltage	0-Vmax	U1	UINT16	R	1
+1	0x1101	V2/V23 voltage	0-Vmax	U1	UINT16	R	1
+2	0x1102	V3/V31 voltage	0-Vmax	U1	UINT16	R	1
+3	0x1103	I1 current	0-Imax	U2	UINT16	R	
+4	0x1104	I2 current	0-Imax	U2	UINT16	R	
+5	0x1105	I3 current	0-Imax	U2	UINT16	R	
+6	0x1106	kW L1	-Pmax-Pmax	U3	INT16	R	
+7	0x1107	kW L2	-Pmax-Pmax	U3	INT16	R	
+8	0x1108	kW L3	-Pmax-Pmax	U3	INT16	R	
+9	0x1109	kvar L1	-Pmax-Pmax	U3	INT16	R	
+10	0x110A	kvar L2	-Pmax-Pmax	U3	INT16	R	
+11	0x110B	kvar L3	-Pmax-Pmax	U3	INT16	R	
+12	0x110C	kVA L1	-Pmax-Pmax	U3	UINT16	R	
+13	0x110D	kVA L2	-Pmax-Pmax	U3	UINT16	R	
+14	0x110E	kVA L3	-Pmax-Pmax	U3	UINT16	R	
+15	0x110F	Power factor L1	-1.000-1.000	0.001	INT16	R	
+16	0x1110	Power factor L2	-1.000-1.000	0.001	INT16	R	
+17	0x1111	Power factor L3	-1.000-1.000	0.001	INT16	R	
+18	0x1403	Total PF	-1.000-1.000	0.001	INT16	R	
+19	0x1400	Total kW	-Pmax-Pmax	U3	INT16	R	
+20	0x1401	Total kvar	-Pmax-Pmax	U3	INT16	R	
+21	0x1402	Total kVA	-Pmax-Pmax	U3	UINT16	R	
+22	0x1501	In current	0-Imax	U2	UINT16	R	
+23	0x1502	Frequency	45.00-65.00	0.01Hz	UINT16	R	
+24	0x3709	Maximum kW import sliding window demand	-Pmax-Pmax	U3	UINT16	R	
+25	0x160F	kW import accumulated demand	-Pmax-Pmax	U3	UINT16	R	
+26	0x370B	Maximum kVA sliding window demand	-Pmax-Pmax	U3	UINT16	R	
+27	0x1611	kVA accumulated demand	-Pmax-Pmax	U3	UINT16	R	
+28	0x3703	I1 Maximum ampere demand	-Pmax-Pmax	U2	UINT16	R	
+29	0x3704	I2 Maximum ampere demand	-Pmax-Pmax	U2	UINT16	R	
+30	0x3705	I3 Maximum ampere demand	-Pmax-Pmax	U2	UINT16	R	
+31		kWh import (low)	0-9999	×0.1 kWh	UINT16	R	6
+32		kWh import (high)	0-9999	×1 MWh	UINT16	R	6
+33		kWh export (low)	0-9999	×0.1 kWh	UINT16	R	6
+34		kWh export (high)	0-9999	×1 MWh	UINT16	R	6
+35		+kvarh net (low)	0-9999	×0.1 kvarh	UINT16	R	4, 6
+36		+kvarh net (high)	0-9999	×1 Mvarh	UINT16	R	4, 6
+37		-kvarh net (low)	0-9999	×0.1 kvarh	UINT16	R	5, 6

Address	Point ID	Description	Low and High Scales ²	Units ²	Type	R/W	Notes
+38		-kvarh net (high)	0-9999	×1 Mvarh	UINT16	R	5, 6
+39	0x1112	V1/V12 voltage THD	0-999.9	0.1%	UINT16	R	3
+40	0x1113	V2/V23 voltage THD	0-999.9	0.1%	UINT16	R	3
+41	0x1114	V3/V31 voltage THD	0-999.9	0.1%	UINT16	R	3
+42	0x1115	I1 current THD	0-999.9	0.1%	UINT16	R	3
+43	0x1116	I2 current THD	0-999.9	0.1%	UINT16	R	3
+44	0x1117	I3 current THD	0-999.9	0.1%	UINT16	R	3
+45		kVAh (low)	0-9999	×0.1 kVAh	UINT16	R	6
+46		kVAh (high)	0-9999	×1 MVAh	UINT16	R	6
+47	0x1609	Present kW import sliding window demand	-Pmax-Pmax	U3	UINT16	R	
+48	0x160B	Present kVA sliding window demand	-Pmax-Pmax	U3	UINT16	R	
+49	0x1615	PF (import) at Max. kVA sliding window demand	0-1.000	0.001	UINT16	R	
+50	0x111B	I1 current TDD	0-100.0	0.1%	UINT16	R	3
+51	0x111C	I2 current TDD	0-100.0	0.1%	UINT16	R	3
+52	0x111D	I3 current TDD	0-100.0	0.1%	UINT16	R	3

NOTES:

- 1 When the 4LN3, 3LN3 or 3BLN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.
- 2 For volts, amps and power scales refer to Chapter 4 "Data Scales and Units".
- 3 On a 3-s interval.
- 4 Positive readings of kvarh net
- 5 Negative readings of kvarh net
- 6 If you use these energy registers instead of 32-bit registers, limit the energy roll value to 8 digits (see Advanced Device Setup) to avoid early overflow.

3.3 16-bit Scaled Analog Values

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
4320-4344		1/2-Cycle Values					
+0	0x0B80	V1 voltage	0-Vmax	U1	UINT16	R	1
+1	0x0B81	V2 voltage	0-Vmax	U1	UINT16	R	1
+2	0x0B82	V3 voltage	0-Vmax	U1	UINT16	R	1
+3	0x0B83	V4 voltage	0-V4max	U4	UINT16	R	
+4	0x0B84	V12 voltage	0-Vmax	U1	UINT16	R	
+5	0x0B85	V23 voltage	0-Vmax	U1	UINT16	R	
+5	0x0B86	V31 voltage	0-Vmax	U1	UINT16	R	
+7	0x0B87	I1 current	0-Imax	U2	UINT16	R	
+8	0x0B88	I2 current	0-Imax	U2	UINT16	R	
+9	0x0B89	I3 current	0-Imax	U2	UINT16	R	
+10	0x0B8A	I4 current	0-I4max	U2	UINT16	R	
+11	0x0B8B	In current	0-Imax	U2	UINT16	R	
+12	0x0B8C	I1x current	0-Ixmax	U2	UINT16	R	
+13	0x0B8D	I2x current	0-Ixmax	U2	UINT16	R	
+14	0x0B8E	I3x current	0-Ixmax	U2	UINT16	R	
+15	0x0B8F	I4x current	0-I4xmax	U2	UINT16	R	
+16	0x0B90	Inx current	0-Ixmax	U2	UINT16	R	
+17	0x0B91	Zero-sequence voltage	0-Vmax	U1	UINT16	R	
+18	0x0B92	Zero-sequence current	0-Imax	U2	UINT16	R	
+19	0x0B93	Ix Zero-sequence current	0-Ixmax	U2	UINT16	R	
+20	0x0B94	Voltage unbalance	0-300.0	0.1%	UINT16	R	
+21	0x0B95	Current unbalance	0-300.0	0.1%	UINT16	R	
+22	0x0B96	Ix current unbalance	0-300.0	0.1%	UINT16	R	
+23	0x0B97	DC voltage	0-9999.00	0.01V	UINT16	R	
+24	0x0B98	Frequency (1-cycle)	0-100.00	0.01Hz	UINT16	R	
4352-4387		1-Cycle Phase Values					
+0	0x0C00	V1 voltage	0-Vmax	U1	UINT16	R	1
+1	0x0C01	V2 voltage	0-Vmax	U1	UINT16	R	1
+2	0x0C02	V3 voltage	0-Vmax	U1	UINT16	R	1
+3	0x0C03	I1 current	0-Imax	U2	UINT16	R	
+4	0x0C04	I2 current	0-Imax	U2	UINT16	R	
+5	0x0C05	I3 current	0-Imax	U2	UINT16	R	
+6	0x0C06	kW L1	-Pmax-Pmax	U3	INT16	R	
+7	0x0C07	kW L2	-Pmax-Pmax	U3	INT16	R	
+8	0x0C08	kW L3	-Pmax-Pmax	U3	INT16	R	
+9	0x0C09	kvar L1	-Pmax-Pmax	U3	INT16	R	
+10	0x0C0A	kvar L2	-Pmax-Pmax	U3	INT16	R	
+11	0x0C0B	kvar L3	-Pmax-Pmax	U3	INT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+12	0x0C0C	kVA L1	0-Pmax	U3	UINT16	R	
+13	0x0C0D	kVA L2	0-Pmax	U3	UINT16	R	
+14	0x0C0E	kVA L3	0-Pmax	U3	UINT16	R	
+15	0x0C0F	Power factor L1	-1.000-1.000	0.001	INT16	R	
+16	0x0C10	Power factor L2	-1.000-1.000	0.001	INT16	R	
+17	0x0C11	Power factor L3	-1.000-1.000	0.001	INT16	R	
+18	0x0C12	V1 voltage THD	0-999.9	0.1%	UINT16	R	2, 4
+19	0x0C13	V2 voltage THD	0-999.9	0.1%	UINT16	R	2, 4
+20	0x0C14	V3 voltage THD	0-999.9	0.1%	UINT16	R	2, 4
+21	0x0C15	I1 current THD	0-999.9	0.1%	UINT16	R	4
+22	0x0C16	I2 current THD	0-999.9	0.1%	UINT16	R	4
+23	0x0C17	I3 current THD	0-999.9	0.1%	UINT16	R	4
+24	0x0C18	I1 K-Factor	1.0-999.9	0.1	UINT16	R	4
+25	0x0C19	I2 K-Factor	1.0-999.9	0.1	UINT16	R	4
+26	0x0C1A	I3 K-Factor	1.0-999.9	0.1	UINT16	R	4
+27	0x0C1B	I1 current TDD	0-100.0	0.1%	UINT16	R	4
+28	0x0C1C	I2 current TDD	0-100.0	0.1%	UINT16	R	4
+29	0x0C1D	I3 current TDD	0-100.0	0.1%	UINT16	R	4
+30	0x0C1E	V12 voltage	0-Vmax	U1	UINT16	R	
+31	0x0C1F	V23 voltage	0-Vmax	U1	UINT16	R	
+32	0x0C20	V31 voltage	0-Vmax	U1	UINT16	R	
+33	0x0C21	I1x current	0-Ixmax	U2	UINT16	R	
+34	0x0C22	I2x current	0-Ixmax	U2	UINT16	R	
+35	0x0C23	I3x current	0-Ixmax	U2	UINT16	R	
4416-4429		1-Cycle Low Phase Values					
+0	0x0D00	Low L-N voltage	0-Vmax	U1	UINT16	R	
+1	0x0D01	Low current	0-Imax	U2	UINT16	R	
+2	0x0D02	Low kW	-Pmax-Pmax	U3	INT16	R	
+3	0x0D03	Low kvar	-Pmax-Pmax	U3	INT16	R	
+4	0x0D04	Low kVA	0-Pmax	U3	UINT16	R	
+5	0x0D05	Low PF Lag	0-1.000	0.001	UINT16	R	
+5	0x0D06	Low PF Lead	0-1.000	0.001	UINT16	R	
+7	0x0D07	Low voltage THD	0-999.9	0.1%	UINT16	R	2, 4
+8	0x0D08	Low current THD	0-999.9	0.1%	UINT16	R	4
+9	0x0D09	Low K-Factor	1.0-999.9	0.1	UINT16	R	4
+10	0x0D0A	Low current TDD	0-100.0	0.1%	UINT16	R	4
+11	0x0D0B	Low L-L voltage	0-Vmax	U1	UINT16	R	
+12	0x0D0C	Low voltage interharmonics THD	0-999.9	0.1%	UINT16	R	2, 4
+13	0x0D0D	Low current interharmonics THD	0-999.9	0.1%	UINT16	R	4
4448-4463		1/2-Cycle Analog Inputs					
+0	0x0D80	Analog input AI1	AI1min-AI1max		UINT16	R	
+1	0x0D81	Analog input AI2	AI2min-AI2max		UINT16	R	
		...					

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+15	0x0D8F	Analog input AI16	AI16min-AI16max		UINT16	R	
4480-4493		1-Cycle High Phase Values					
+0	0x0E00	High L-N voltage	0-Vmax	U1	UINT16	R	
+1	0x0E01	High current	0-Imax	U2	UINT16	R	
+2	0x0E02	High kW	-Pmax-Pmax	U3	INT16	R	
+3	0x0E03	High kvar	-Pmax-Pmax	U3	INT16	R	
+4	0x0E04	High kVA	0-Pmax	U3	UINT16	R	
+5	0x0E05	High PF Lag	0-1.000	0.001	UINT16	R	
+5	0x0E06	High PF Lead	0-1.000	0.001	UINT16	R	
+7	0x0E07	High voltage THD	0-999.9	0.1%	UINT16	R	2, 4
+8	0x0E08	High current THD	0-999.9	0.1%	UINT16	R	4
+9	0x0E09	High K-Factor	1.0-999.9	0.1	UINT16	R	4
+10	0x0E0A	High current TDD	0-100.0	0.1%	UINT16	R	4
+11	0x0E0B	High L-L voltage	0-Vmax	U1	UINT16	R	
+12	0x0E0C	High voltage interharmonics THD	0-999.9	0.1%	UINT16	R	2, 4
+13	0x0E0D	High current interharmonics THD	0-999.9	0.1%	UINT16	R	4
4512-4527		1-Second Analog Inputs					
+0	0x0E80	Analog input AI1	AI1min-AI1max		UINT16	R	
+1	0x0E81	Analog input AI2	AI2min-AI2max		UINT16	R	
		...					
+15	0x0E8F	Analog input AI16	AI16min-AI16max		UINT16	R	
4544-4557		1-Cycle Total Values					
+0	0x0F00	Total kW	-Pmax-Pmax	U3	INT16	R	
+1	0x0F01	Total kvar	-Pmax-Pmax	U3	INT16	R	
+2	0x0F02	Total kVA	0-Pmax	U3	UINT16	R	
+3	0x0F03	Total PF	-1.000-1.000	0.001	INT16	R	
+4	0x0F04	Total PF lag	0-1.000	0.001	UINT16	R	
+5	0x0F05	Total PF lead	0-1.000	0.001	UINT16		
+5	0x0F06	Total kW import	0-Pmax	U3	UINT16		
+7	0x0F07	Total kW export	0-Pmax	U3	UINT16	R	
+8	0x0F08	Total kvar import	0-Pmax	U3	UINT16	R	
+9	0x0F09	Total kvar export	0-Pmax	U3	UINT16	R	
+10	0x0FOA	3-phase average L-N voltage	0-Vmax	U1	UINT16	R	
+11	0x0FOB	3-phase average L-L voltage	0-Vmax	U1	UINT16	R	
+12	0x0FOC	3-phase average current	0-Imax	U2	UINT16	R	
+13	0x0F0D	3-phase average current, extended inputs I1x-I3x	0-Ixmax	U2	UINT16	R	
4608-4556		1-Cycle Auxiliary Values					
+0	0x1000	I4 current	0-I4max	U2	UINT16	R	
+1	0x1001	In current	0-Imax	U2	UINT16	R	
+2	0x1002	Frequency	0-100.00	0.01Hz	UINT16	R	
+3	0x1003	Voltage unbalance	0-300.0	0.1%	UINT16	R	
+4	0x1004	Current unbalance	0-300.0	0.1%	UINT16	R	
+5	0x1005	DC voltage	0-9999.00	0.01V	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+5	0x1006	V4 voltage	0-V4max	U4	UINT16	R	
+7	0x1007	I4x current	0-I4xmax	U2	UINT16	R	
4640-4655		Fundamental Phasor Values					
+0	0x1080	V1 voltage magnitude	0-Vmax	U1	UINT16	R	2
+1	0x1081	V2 voltage magnitude	0-Vmax	U1	UINT16	R	2
+2	0x1082	V3 voltage magnitude	0-Vmax	U1	UINT16	R	2
+3	0x1083	V4 voltage magnitude	0-V4max	U1	UINT16	R	
+4	0x1084	I1 current magnitude	0-Imax	U2	UINT16	R	
+5	0x1085	I2 current magnitude	0-Imax	U2	UINT16	R	
+5	0x1086	I3 current magnitude	0-Imax	U2	UINT16	R	
+7	0x1087	I4 current magnitude	0-Imax	U2	UINT16	R	
+8	0x1088	V1 voltage angle	-180.0-180.0	0.1°	INT16	R	2
+9	0x1089	V2 voltage angle	-180.0-180.0	0.1°	INT16	R	2
+10	0x108A	V3 voltage angle	-180.0-180.0	0.1°	INT16	R	2
+11	0x108B	V4 voltage angle	-180.0-180.0	0.1°	INT16	R	
+12	0x108C	I1 current angle	-180.0-180.0	0.1°	INT16	R	
+13	0x108D	I2 current angle	-180.0-180.0	0.1°	INT16	R	
+14	0x108E	I3 current angle	-180.0-180.0	0.1°	INT16	R	
+15	0x108F	I4 current angle	-180.0-180.0	0.1°	INT16	R	
4672-4707		1-Second Phase Values					
+0	0x1100	V1 voltage	0-Vmax	U1	UINT16	R	1
+1	0x1101	V2 voltage	0-Vmax	U1	UINT16	R	1
+2	0x1102	V3 voltage	0-Vmax	U1	UINT16	R	1
+3	0x1103	I1 current	0-Imax	U2	UINT16	R	
+4	0x1104	I2 current	0-Imax	U2	UINT16	R	
+5	0x1105	I3 current	0-Imax	U2	UINT16	R	
+6	0x1106	kW L1	-Pmax-Pmax	U3	INT16	R	
+7	0x1107	kW L2	-Pmax-Pmax	U3	INT16	R	
+8	0x1108	kW L3	-Pmax-Pmax	U3	INT16	R	
+9	0x1109	kvar L1	-Pmax-Pmax	U3	INT16	R	
+10	0x110A	kvar L2	-Pmax-Pmax	U3	INT16	R	
+11	0x110B	kvar L3	-Pmax-Pmax	U3	INT16	R	
+12	0x110C	kVA L1	0-Pmax	U3	UINT16	R	
+13	0x110D	kVA L2	0-Pmax	U3	UINT16	R	
+14	0x110E	kVA L3	0-Pmax	U3	UINT16	R	
+15	0x110F	Power factor L1	-1.000-1.000	0.001	INT16	R	
+16	0x1110	Power factor L2	-1.000-1.000	0.001	INT16	R	
+17	0x1111	Power factor L3	-1.000-1.000	0.001	INT16	R	
+18	0x1112	V1 voltage THD	0-999.9	0.1%	UINT16	R	2, 5
+19	0x1113	V2 voltage THD	0-999.9	0.1%	UINT16	R	2, 5
+20	0x1114	V3 voltage THD	0-999.9	0.1%	UINT16	R	2, 5
+21	0x1115	I1 current THD	0-999.9	0.1%	UINT16	R	5
+22	0x1116	I2 current THD	0-999.9	0.1%	UINT16	R	5

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+23	0x1117	I3 current THD	0-999.9	0.1%	UINT16	R	5
+24	0x1118	I1 K-Factor	1.0-999.9	0.1	UINT16	R	5
+25	0x1119	I2 K-Factor	1.0-999.9	0.1	UINT16	R	5
+26	0x111A	I3 K-Factor	1.0-999.9	0.1	UINT16	R	5
+27	0x111B	I1 current TDD	0-100.0	0.1%	UINT16	R	5
+28	0x111C	I2 current TDD	0-100.0	0.1%	UINT16	R	5
+29	0x111D	I3 current TDD	0-100.0	0.1%	UINT16	R	5
+30	0x111E	V12 voltage	0-Vmax	U1	UINT16	R	
+31	0x111F	V23 voltage	0-Vmax	U1	UINT16	R	
+32	0x1120	V31 voltage	0-Vmax	U1	UINT16	R	
+33	0x1121	I1x current	0-Ixmax	U2	UINT16	R	
+34	0x1122	I2x current	0-Ixmax	U2	UINT16	R	
+35	0x1123	I3x current	0-Ixmax	U2	UINT16	R	
4736-4749		1-Second Low Phase Values					
+0	0x1200	Low L-N voltage	0-Vmax	U1	UINT16	R	
+1	0x1201	Low current	0-Imax	U2	UINT16	R	
+2	0x1202	Low kW	-Pmax-Pmax	U3	INT16	R	
+3	0x1203	Low kvar	-Pmax-Pmax	U3	INT16	R	
+4	0x1204	Low kVA	0-Pmax	U3	UINT16	R	
+5	0x1205	Low PF Lag	0-1.000	0.001	UINT16	R	
+5	0x1206	Low PF Lead	0-1.000	0.001	UINT16	R	
+7	0x1207	Low voltage THD	0-999.9	0.1%	UINT16	R	2, 5
+8	0x1208	Low current THD	0-999.9	0.1%	UINT16	R	5
+9	0x1209	Low K-Factor	1.0-999.9	0.1	UINT16	R	5
+10	0x120A	Low current TDD	0-100.0	0.1%	UINT16	R	5
+11	0x120B	Low L-L voltage	0-Vmax	U1	UINT16	R	
+12	0x120C	Low voltage interharmonics THD	0-999.9	0.1%	UINT16	R	2, 5
+13	0x120D	Low current interharmonics THD	0-999.9	0.1%	UINT16	R	5
4800-4813		1-Second High Phase Values					
+0	0x1300	High L-N voltage	0-Vmax	U1	UINT16	R	
+1	0x1301	High current	0-Imax	U2	UINT16	R	
+2	0x1302	High kW	-Pmax-Pmax	U3	INT16	R	
+3	0x1303	High kvar	-Pmax-Pmax	U3	INT16	R	
+4	0x1304	High kVA	0-Pmax	U3	UINT16	R	
+5	0x1305	High PF Lag	0-1.000	0.001	UINT16	R	
+5	0x1306	High PF Lead	0-1.000	0.001	UINT16	R	
+7	0x1307	High voltage THD	0-999.9	0.1%	UINT16	R	2, 5
+8	0x1308	High current THD	0-999.9	0.1%	UINT16	R	5
+9	0x1309	High K-Factor	1.0-999.9	0.1	UINT16	R	5
+10	0x130A	High current TDD	0-100.0	0.1%	UINT16	R	5
+11	0x130B	High L-L voltage	0-Vmax	U1	UINT16	R	
+12	0x130C	High voltage interharmonics THD	0-999.9	0.1%	UINT16	R	2, 5
+13	0x130D	High current interharmonics THD	0-999.9	0.1%	UINT16	R	5

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
4864-4877		1-Second Total Values					
+0	0x1400	Total kW	-Pmax-Pmax	U3	UINT16	R	
+1	0x1401	Total kvar	-Pmax-Pmax	U3	UINT16	R	
+2	0x1402	Total kVA	0-Pmax	U3	UINT16	R	
+3	0x1403	Total PF	-1.000-1.000	0.001	UINT16	R	
+4	0x1404	Total PF lag	0-1.000	0.001	UINT16	R	
+5	0x1405	Total PF lead	0-1.000	0.001	UINT16		
+5	0x1406	Total kW import	0-Pmax	U3	UINT16		
+7	0x1407	Total kW export	0-Pmax	U3	UINT16	R	
+8	0x1408	Total kvar import	0-Pmax	U3	UINT16	R	
+9	0x1409	Total kvar export	0-Pmax	U3	UINT16	R	
+10	0x140A	3-phase average L-N voltage	0-Vmax	U1	UINT16	R	
+11	0x140B	3-phase average L-L voltage	0-Vmax	U1	UINT16	R	
+12	0x140C	3-phase average current	0-Imax	U2	UINT16	R	
+13	0x140D	3-phase average current, extended inputs I1x-I3x	0-Ixmax	U2	UINT16	R	
4928-4935		1-Second Auxiliary Values					
+0	0x1500	I4 current	0-I4max	U2	UINT16	R	
+1	0x1501	In current	0-Imax	U2	UINT16	R	
+2	0x1502	Frequency	0-100.00	0.01Hz	UINT16	R	
+3	0x1503	Voltage unbalance	0-300.0	0.1%	UINT16	R	
+4	0x1504	Current unbalance	0-300.0	0.1%	UINT16	R	
+5	0x1505	DC voltage	0-9999.00	0.01V	UINT16	R	
+5	0x1506	V4 voltage	0-V4max	U4	UINT16	R	
+7	0x1507	I4x current	0-I4xmax	U2	UINT16	R	
4960-4971		Present Harmonic Demands					
+0	0x1580	V1 THD demand	0-999.9	0.1%	UINT16	R	2
+1	0x1581	V2 THD demand	0-999.9	0.1%	UINT16	R	2
+2	0x1582	V3 THD demand	0-999.9	0.1%	UINT16	R	2
+3	0x1583	V4 THD demand	0-999.9	0.1%	UINT16	R	
+4	0x1584	I1 THD demand	0-999.9	0.1%	UINT16	R	
+5	0x1585	I2 THD demand	0-999.9	0.1%	UINT16	R	
+5	0x1586	I3 THD demand	0-999.9	0.1%	UINT16	R	
+7	0x1587	I4 THD demand	0-999.9	0.1%	UINT16	R	
+8	0x1588	I1 TDD demand	0-100.0	0.1%	UINT16	R	
+9	0x1589	I2 TDD demand	0-100.0	0.1%	UINT16	R	
+10	0x158A	I3 TDD demand	0-100.0	0.1%	UINT16	R	
+11	0x158B	I4 TDD demand	0-100.0	0.1%	UINT16	R	
4992-5026		Present Demands					
+0	0x1600	V1 Volt demand	0-Vmax	U1	UINT16	R	2
+1	0x1601	V2 Volt demand	0-Vmax	U1	UINT16	R	2
+2	0x1602	V3 Volt demand	0-Vmax	U1	UINT16	R	2
+3	0x1603	I1 Ampere demand	0-Imax	U2	UINT16	R	
+4	0x1604	I2 Ampere demand	0-Imax	U2	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+5	0x1605	I3 Ampere demand	0-Imax	U2	UINT16	R	
+6	0x1606	kW import block demand	0-Pmax	U3	UINT16	R	
+7	0x1607	kvar import block demand	0-Pmax	U3	UINT16	R	
+8	0x1608	kVA block demand	0-Pmax	U3	UINT16	R	
+9	0x1609	kW import sliding window demand	0-Pmax	U3	UINT16	R	
+10	0x160A	kvar import sliding window demand	0-Pmax	U3	UINT16	R	
+11	0x160B	kVA sliding window demand	0-Pmax	U3	UINT16	R	
+12	0x160C	Not used	0		UINT16	R	
+13	0x160D	Not used	0		UINT16	R	
+14	0x160E	Not used	0		UINT16	R	
+15	0x160F	kW import accumulated demand	0-Pmax	U3	UINT16	R	
+16	0x1610	kvar import accumulated demand	0-Pmax	U3	UINT16	R	
+17	0x1611	kVA accumulated demand	0-Pmax	U3	UINT16	R	
+18	0x1612	kW import predicted sliding window demand	0-Pmax	U3	UINT16	R	
+19	0x1613	kvar import predicted sliding window demand	0-Pmax	U3	UINT16	R	
+20	0x1614	kVA predicted sliding window demand	0-Pmax	U3	UINT16	R	
+21	0x1615	PF (import) at Max. kVA sliding window demand	0-1.000	0.001	UINT16	R	
+22	0x1616	kW export block demand	0-Pmax	U3	UINT16	R	
+23	0x1617	kvar export block demand	0-Pmax	U3	UINT16	R	
+24	0x1618	kW export sliding window demand	0-Pmax	U3	UINT16	R	
+25	0x1619	kvar export sliding window demand	0-Pmax	U3	UINT16	R	
+26	0x161A	kW export accumulated demand	0-Pmax	U3	UINT16	R	
+27	0x161B	kvar export accumulated demand	0-Pmax	U3	UINT16	R	
+28	0x161C	kW export predicted sliding window demand	0-Pmax	U3	UINT16	R	
+29	0x161D	kvar export predicted sliding window demand	0-Pmax	U3	UINT16	R	
+30	0x161E	Not used	0		UINT16	R	
+31	0x161F	Not used	0		UINT16	R	
+32	0x1620	V4 volt demand	0-Vmax	U4	UINT16	R	
+33	0x1621	I4 ampere demand	0-Imax	U2	UINT16	R	
+34	0x1622	In ampere demand	0-Imax	U2	UINT16	R	
5152-5161		Symmetrical Components					
+0	0x1880	Positive-sequence voltage	0-Vmax	U1	UINT16	R	
+1	0x1881	Negative-sequence voltage	0-Vmax	U1	UINT16	R	
+2	0x1882	Zero-sequence voltage	0-Vmax	U1	UINT16	R	
+3	0x1883	Negative-sequence voltage unbalance	0-300.0	0.1%	UINT16	R	
+4	0x1884	Zero-sequence voltage unbalance	0-300.0	0.1%	UINT16	R	
+5	0x1885	Positive-sequence current	0-Imax	U2	UINT16	R	
+6	0x1886	Negative-sequence current	0-Imax	U2	UINT16	R	
+7	0x1887	Zero-sequence current	0-Imax	U2	UINT16	R	
+8	0x1888	Negative-sequence current unbalance	0-300.0	0.1%	UINT16	R	
+9	0x1889	Zero-sequence current unbalance	0-300.0	0.1%	UINT16	R	
5184-5246		V1 Harmonics					2
+0	0x1900	H01 Harmonic magnitude	0-100.00	0.01%	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+1	0x1901	H02 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
		...					
+62	0x193E	H63 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
5248-5310		V2 Harmonics					2
+0	0x1A00	H01 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
+1	0x1A01	H02 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
		...					
+62	0x1A3E	H63 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
5312-5374		V3 Harmonics					2
+0	0x1B00	H01 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
+1	0x1B01	H02 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
		...					
+62	0x1B3E	H63 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
5376-5438		I1 Harmonics					
+0	0x1C00	H01 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
+1	0x1C01	H02 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
		...					
+62	0x1C3E	H63 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
5440-5502		I2 Harmonics					
+0	0x1D00	H01 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
+1	0x1D01	H02 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
		...					
+62	0x1D3E	H63 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
5504-5566		I3 Harmonics					
+0	0x1E00	H01 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
+1	0x1E01	H02 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
		...					
+62	0x1E3E	H63 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
5568-5599		V1 Harmonic Voltages (odd numbers)					2
+0	0x1F00	H01 Harmonic voltage	0-Vmax	U1	UINT16	R	
+1	0x1F01	H03 Harmonic voltage	0-Vmax	U1	UINT16	R	
		...					
+31	0x1F3E	H63 Harmonic voltage	0-Vmax	U1	UINT16	R	
5632-5663		V2 Harmonic Voltages (odd numbers)					2
+0	0x2000	H01 Harmonic voltage	0-Vmax	U1	UINT16	R	
+1	0x2001	H03 Harmonic voltage	0-Vmax	U1	UINT16	R	
		...					
+31	0x203E	H63 Harmonic voltage	0-Vmax	U1	UINT16	R	
5696-5727		V3 Harmonic Voltages (odd numbers)					2
+0	0x2100	H01 Harmonic voltage	0-Vmax	U1	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+1	0x2101	H03 Harmonic voltage	0-Vmax	U1	UINT16	R	
		...					
+31	0x213E	H63 Harmonic voltage	0-Vmax	U1	UINT16	R	
5760-5791		I1 Harmonic Currents (odd numbers)					
+0	0x2200	H01 Harmonic current	0-Imax	U2	UINT16	R	
+1	0x2201	H03 Harmonic current	0-Imax	U2	UINT16	R	
		...					
+31	0x223E	H63 Harmonic current	0-Imax	U2	UINT16	R	
5824-5855		I2 Harmonic Currents (odd numbers)					
+0	0x2300	H01 Harmonic current	0-Imax	U2	UINT16	R	
+1	0x2301	H03 Harmonic current	0-Imax	U2	UINT16	R	
		...					
+31	0x233E	H63 Harmonic current	0-Imax	U2	UINT16	R	
5888-5919		I3 Harmonic Currents (odd numbers)					
+0	0x2400	H01 Harmonic current	0-Imax	U2	UINT16	R	
+1	0x2401	H03 Harmonic current	0-Imax	U2	UINT16	R	
		...					
+31	0x243E	H63 Harmonic current	0-Imax	U2	UINT16	R	
5952-5983		Total Harmonic kW (odd numbers)					
+0	0x2500	H01 Harmonic kW	-Pmax -Pmax	U3	INT16	R	
+1	0x2501	H03 Harmonic kW	-Pmax -Pmax	U3	INT16	R	
		...					
+31	0x253E	H63 Harmonic kW	-Pmax -Pmax	U3	INT16	R	
6016-6047		Total Harmonic kvar (odd numbers)					
+0	0x2600	H01 Harmonic kvar	-Pmax -Pmax	U3	INT16	R	
+1	0x2601	H03 Harmonic kvar	-Pmax -Pmax	U3	INT16	R	
		...					
+31	0x263E	H63 Harmonic kvar	-Pmax -Pmax	U3	INT16	R	
6080-6111		Total Harmonic Power Factor (odd numbers)					
+0	0x2700	H01 Harmonic PF	-1.000-1.000	0.001	INT16	R	
+1	0x2701	H03 Harmonic PF	-1.000-1.000	0.001	INT16	R	
		...					
+31	0x273E	H63 Harmonic PF	-1.000-1.000	0.001	INT16	R	
6144-6206		V4 Harmonics					
+0	0x2800	H01 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
+1	0x2801	H02 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
		...					
+62	0x283E	H63 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
6240-6245		Flicker					
+0	0x2980	V1 Pst	0-100.00	0.01	UINT16	R	2
+1	0x2981	V2 Pst	0-100.00	0.01	UINT16	R	2

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+2	0x2982	V3 Pst	0-100.00	0.01	UINT16	R	2
+3	0x2983	V1 Plt	0-100.00	0.01	UINT16	R	2
+4	0x2984	V2 Plt	0-100.00	0.01	UINT16	R	2
+5	0x2985	V3 Plt	0-100.00	0.01	UINT16	R	2
6336-6398		I4 Harmonics					
+0	0x2B00	H01 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
+1	0x2B01	H02 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
		...					
+62	0x2B3E	H63 Harmonic magnitude	0-100.00	0.01%	UINT16	R	
6400-6435		Minimum 1-Cycle Phase Values					
+0	0x2C00	V1 voltage	0-Vmax	U1	UINT16	R	1
+1	0x2C01	V2 voltage	0-Vmax	U1	UINT16	R	1
+2	0x2C02	V3 voltage	0-Vmax	U1	UINT16	R	1
+3	0x2C03	I1 current	0-Imax	U2	UINT16	R	
+4	0x2C04	I2 current	0-Imax	U2	UINT16	R	
+5	0x2C05	I3 current	0-Imax	U2	UINT16	R	
+6	0x2C06	kW L1	-Pmax-Pmax	U3	INT16	R	
+7	0x2C07	kW L2	-Pmax-Pmax	U3	INT16	R	
+8	0x2C08	kW L3	-Pmax-Pmax	U3	INT16	R	
+9	0x2C09	kvar L1	-Pmax-Pmax	U3	INT16	R	
+10	0x2C0A	kvar L2	-Pmax-Pmax	U3	INT16	R	
+11	0x2C0B	kvar L3	-Pmax-Pmax	U3	INT16	R	
+12	0x2C0C	kVA L1	0-Pmax	U3	UINT16	R	
+13	0x2C0D	kVA L2	0-Pmax	U3	UINT16	R	
+14	0x2C0E	kVA L3	0-Pmax	U3	UINT16	R	
+15	0x2C0F	Power factor L1	0-1.000	0.001	UINT16	R	Absolute value
+16	0x2C10	Power factor L2	0-1.000	0.001	UINT16	R	Absolute value
+17	0x2C11	Power factor L3	0-1.000	0.001	UINT16	R	Absolute value
+18	0x2C12	V1 voltage THD	0-9999	0.1%	UINT16	R	2, 4
+19	0x2C13	V2 voltage THD	0-9999	0.1%	UINT16	R	2, 4
+20	0x2C14	V3 voltage THD	0-999.9	0.1%	UINT16	R	2, 4
+21	0x2C15	I1 current THD	0-999.9	0.1%	UINT16	R	4
+22	0x2C16	I2 current THD	0-999.9	0.1%	UINT16	R	4
+23	0x2C17	I3 current THD	0-999.9	0.1%	UINT16	R	4
+24	0x2C18	I1 K-Factor	1.0-999.9	0.1	UINT16	R	4
+25	0x2C19	I2 K-Factor	1.0-999.9	0.1	UINT16	R	4
+26	0x2C1A	I3 K-Factor	1.0-999.9	0.1	UINT16	R	4
+27	0x2C1B	I1 current TDD	0-100.0	0.1%	UINT16	R	4
+28	0x2C1C	I2 current TDD	0-100.0	0.1%	UINT16	R	4
+29	0x2C1D	I3 current TDD	0-100.0	0.1%	UINT16	R	4
+30	0x2C1E	V12 voltage	0-Vmax	U1	UINT16	R	
+31	0x2C1F	V23 voltage	0-Vmax	U1	UINT16	R	
+32	0x2C20	V31 voltage	0-Vmax	U1	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+33	0x2C21	I1x current	0-Ixmax	U2	UINT16	R	
+34	0x2C22	I2x current	0-Ixmax	U2	UINT16	R	
+35	0x2C23	I3x current	0-Ixmax	U2	UINT16	R	
6464-6469		Minimum 1-Cycle Total Values					
+0	0x2D00	Total kW	-Pmax-Pmax	U3	INT16	R	
+1	0x2D01	Total kvar	-Pmax-Pmax	U3	INT16	R	
+2	0x2D02	Total kVA	0-Pmax	U3	UINT16	R	
+3	0x2D03	Total PF	0-1.000	0.001	UINT16	R	Absolute value
+4	0x2D04	Total PF lag	0-1.000	0.001	UINT16	R	
+5	0x2D05	Total PF lead	0-1.000	0.001	UINT16	R	
6528-6538		Minimum 1-Cycle Auxiliary Values					
+0	0x2E00	I4 current	0-I4max	U2	UINT16	R	
+1	0x2E01	In current	0-Imax	U2	UINT16	R	
+2	0x2E02	Frequency	0-100.00	0.01Hz	UINT16	R	
+3	0x2E03	Voltage unbalance	0-300.0	0.1%	UINT16	R	
+4	0x2E04	Current unbalance	0-300.0	0.1%	UINT16	R	
+5	0x2E05	DC voltage	0-9999.00	0.01V	UINT16	R	
+6	0x2E06	V4 voltage	0-V4max	U4	UINT16	R	
+7	0x2E07	I4x current	0-I4xmax	U2	UINT16	R	
+8	0x2E08	V4 THD	0-999.9	0.1%	UINT16	R	4
+9	0x2E09	I4x THD	0-999.9	0.1%	UINT16	R	4
+10	0x2E0A	I4x TDD	0-100.0	0.1%	UINT16	R	4
6560-6575		Minimum Analog Inputs					
+0	0x2E80	Analog input A11	A11min-A11max		UINT16	R	
+1	0x2E81	Analog input A12	A12min-A12max		UINT16	R	
		...					
+15	0x2E8F	Analog input A116	A116min-A116max		UINT16	R	
6656-6671		Programmable Min/Max Minimum Values					
+0	0x3000	Min/Max Register #1			UINT16	R	
+1	0x3001	Min/Max Register #2			UINT16	R	
		...					
+15	0x300F	Min/Max Register #16			UINT16	R	
6720-6751		V4 Harmonic Voltages (odd numbers)					
+0	0x3100	H01 Harmonic voltage	0-Vmax	U1	UINT16	R	
+1	0x3101	H03 Harmonic voltage	0-Vmax	U1	UINT16	R	
		...					
+31	0x313E	H63 Harmonic voltage	0-Vmax	U1	UINT16	R	
6784-6815		I4 Harmonic Currents (odd numbers)					
+0	0x3200	H01 Harmonic current	0-Imax	U2	UINT16	R	
+1	0x3201	H03 Harmonic current	0-Imax	U2	UINT16	R	
		...					
+31	0x323E	H63 Harmonic current	0-Imax	U2	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
6912-6947		Maximum 1-Cycle Phase Values					
+0	0x3400	V1 voltage	0-Vmax	U1	UINT16	R	1
+1	0x3401	V2 voltage	0-Vmax	U1	UINT16	R	1
+2	0x3402	V3 voltage	0-Vmax	U1	UINT16	R	1
+3	0x3403	I1 current	0-Imax	U2	UINT16	R	
+4	0x3404	I2 current	0-Imax	U2	UINT16	R	
+5	0x3405	I3 current	0-Imax	U2	UINT16	R	
+6	0x3406	kW L1	-Pmax-Pmax	U3	INT16	R	
+7	0x3407	kW L2	-Pmax-Pmax	U3	INT16	R	
+8	0x3408	kW L3	-Pmax-Pmax	U3	INT16	R	
+9	0x3409	kvar L1	-Pmax-Pmax	U3	INT16	R	
+10	0x340A	kvar L2	-Pmax-Pmax	U3	INT16	R	
+11	0x340B	kvar L3	-Pmax-Pmax	U3	INT16	R	
+12	0x340C	kVA L1	0-Pmax	U3	UINT16	R	
+13	0x340D	kVA L2	0-Pmax	U3	UINT16	R	
+14	0x340E	kVA L3	0-Pmax	U3	UINT16	R	
+15	0x340F	Power factor L1	0-1.000	0.001	UINT16	R	Absolute value
+16	0x3410	Power factor L2	0-1.000	0.001	UINT16	R	Absolute value
+17	0x3411	Power factor L3	0-1.000	0.001	UINT16	R	Absolute value
+18	0x3412	V1 voltage THD	0-999.9	0.1%	UINT16	R	2, 4
+19	0x3413	V2 voltage THD	0-999.9	0.1%	UINT16	R	2, 4
+20	0x3414	V3 voltage THD	0-999.9	0.1%	UINT16	R	2, 4
+21	0x3415	I1 current THD	0-999.9	0.1%	UINT16	R	4
+22	0x3416	I2 current THD	0-999.9	0.1%	UINT16	R	4
+23	0x3417	I3 current THD	0-999.9	0.1%	UINT16	R	4
+24	0x3418	I1 K-Factor	1.0-999.9	0.1	UINT16	R	4
+25	0x3419	I2 K-Factor	1.0-999.9	0.1	UINT16	R	4
+26	0x341A	I3 K-Factor	1.0-999.9	0.1	UINT16	R	4
+27	0x341B	I1 current TDD	0-100.0	0.1%	UINT16	R	4
+28	0x341C	I2 current TDD	0-100.0	0.1%	UINT16	R	4
+29	0x341D	I3 current TDD	0-100.0	0.1%	UINT16	R	4
+30	0x341E	V12 voltage	0-Vmax	U1	UINT16	R	
+31	0x341F	V23 voltage	0-Vmax	U1	UINT16	R	
+32	0x3420	V31 voltage	0-Vmax	U1	UINT16	R	
+33	0x3421	I1x current	0-Ixmax	U2	UINT16	R	
+34	0x3422	I2x current	0-Ixmax	U2	UINT16	R	
+35	0x3423	I3x current	0-Ixmax	U2	UINT16	R	
6976-6981		Maximum 1-Cycle Total Values					
+0	0x3500	Total kW	-Pmax-Pmax	U3	INT16	R	
+1	0x3501	Total kvar	-Pmax-Pmax	U3	INT16	R	
+2	0x3502	Total kVA	0-Pmax	U3	UINT16	R	
+3	0x3503	Total PF	0-1.000	0.001	UINT16	R	Absolute value
+4	0x3504	Total PF lag	0-1.000	0.001	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+5	0x3505	Total PF lead	0-1.000	0.001	UINT16	R	
7040-7050		Maximum 1-Cycle Auxiliary Values					
+0	0x3600	I4 current	0-I4max	U2	UINT16	R	
+1	0x3601	In current	0-Imax	U2	UINT16	R	
+2	0x3602	Frequency	0-100.00	0.01Hz	UINT16	R	
+3	0x3603	Voltage unbalance	0-300.0	0.1%	UINT16	R	
+4	0x3604	Current unbalance	0-300.0	0.1%	UINT16	R	
+5	0x3605	DC voltage	0-9999.00	0.01V	UINT16	R	
+6	0x3606	V4 voltage	0-V4max	U4	UINT16	R	
+7	0x3607	I4x current	0-I4xmax	U2	UINT16	R	
+8	0x3608	V4 THD	0-999.9	0.1%	UINT16	R	4
+9	0x3609	I4x THD	0-999.9	0.1%	UINT16	R	4
+10	0x360A	I4x TDD	0-100.0	0.1%	UINT16	R	4
7072-7087		Maximum Analog Inputs					
+0	0x3680	Analog input AI1	AI1min-AI1max		UINT16	R	
+1	0x3681	Analog input AI2	AI2min-AI2max		UINT16	R	
		...					
+15	0x368F	Analog input AI16	AI16min-AI16max		UINT16	R	
7104-71025		Maximum Demands					
+0	0x3700	V1 Maximum volt demand	0-Vmax	U1	UINT16	R	2
+1	0x3701	V2 Maximum volt demand	0-Vmax	U1	UINT16	R	2
+2	0x3702	V3 Maximum volt demand	0-Vmax	U1	UINT16	R	2
+3	0x3703	I1 Maximum ampere demand	0-Imax	U2	UINT16	R	
+4	0x3704	I2 Maximum ampere demand	0-Imax	U2	UINT16	R	
+5	0x3705	I3 Maximum ampere demand	0-Imax	U2	UINT16	R	
+6	0x3706	Not used	0		UINT16	R	
+7	0x3707	Not used	0		UINT16	R	
+8	0x3708	Not used	0		UINT16	R	
+9	0x3709	Maximum kW import sliding window demand	0-Pmax	U3	UINT16	R	
+10	0x370A	Maximum kvar import sliding window demand	0-Pmax	U3	UINT16	R	
+11	0x370B	Maximum kVA sliding window demand	0-Pmax	U3	UINT16	R	
+12	0x370C	Not used	0		UINT16	R	
+13	0x370D	Not used	0		UINT16	R	
+14	0x370E	Not used	0		UINT16	R	
+15	0x370F	Maximum kW export sliding window demand	0-Pmax	U3	UINT16	R	
+16	0x3710	Maximum kvar export sliding window demand	0-Pmax	U3	UINT16	R	
+17	0x3711	Not used	0		UINT16	R	
+18	0x3712	Not used	0		UINT16	R	
+19	0x3713	V4 Maximum volt demand	0-Vmax	U4	UINT16	R	
+20	0x3714	I4 Maximum ampere demand	0-I4max	U2	UINT16	R	
+21	0x3715	In Maximum ampere demand	0-Imax	U2	UINT16	R	
7168-7183		Programmable Min/Max Maximum Values					
+0	0x3800	Min/Max Register #1			UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+1	0x3801	Min/Max Register #2			UINT16	R	
		...					
+15	0x380F	Min/Max Register #16			UINT16	R	
7200-7211		Maximum Harmonic Demands					
+0	0x3880	V1 THD demand	0-999.9	0.1%	UINT16	R	2
+1	0x3881	V2 THD demand	0-999.9	0.1%	UINT16	R	2
+2	0x3882	V3 THD demand	0-999.9	0.1%	UINT16	R	2
+3	0x3883	V4 THD demand	0-999.9	0.1%	UINT16	R	
+4	0x3884	I1 THD demand	0-999.9	0.1%	UINT16	R	
+5	0x3885	I2 THD demand	0-999.9	0.1%	UINT16	R	
+6	0x3886	I3 THD demand	0-999.9	0.1%	UINT16	R	
+7	0x3887	I4 THD demand	0-999.9	0.1%	UINT16	R	
+8	0x3888	I1 TDD demand	0-100.0	0.1%	UINT16	R	
+9	0x3889	I2 TDD demand	0-100.0	0.1%	UINT16	R	
+10	0x388A	I3 TDD demand	0-100.0	0.1%	UINT16	R	
+11	0x388B	I4 TDD demand	0-100.0	0.1%	UINT16	R	
7232-7263		Maximum Analog Input Demands					
+0	0x3900	Analog input AI1+	AI1min-AI1max		UINT16	R	Positive AI readings demand
+1	0x3901	Analog input AI2+	AI2min-AI2max		UINT16	R	
		...					
+15	0x390F	Analog input AI16+	AI16min-AI16max		UINT16	R	
+16	0x3910	Analog input AI1-	AI1min-AI1max		UINT16	R	Negative AI readings demand
+17	0x3911	Analog input AI2-	AI2min-AI2max		UINT16	R	
		...					
+31	0x391F	Analog input AI16-	AI16min-AI16max		UINT16	R	
7296-7327		Present Analog Input Demands					
+0	0x3A00	Analog input AI1+	AI1min-AI1max		UINT16	R	Positive AI readings demand
+1	0x3A01	Analog input AI2+	AI2min-AI2max		UINT16	R	
		...					
+15	0x3A0F	Analog input AI16+	AI16min-AI16max		UINT16	R	
+16	0x3A10	Analog input AI1-	AI1min-AI1max		UINT16	R	Negative AI readings demand
+17	0x3A11	Analog input AI2-	AI2min-AI2max		UINT16	R	
		...					
+31	0x3A1F	Analog input AI16-	AI16min-AI16max		UINT16	R	
7360-7375		1-Cycle Analog Inputs					
+0	0x3B00	Analog input AI1	AI1min-AI1max		UINT16	R	
+1	0x3B01	Analog input AI2	AI2min-AI2max		UINT16	R	
		...					
+15	0x3B0F	Analog input AI16	AI16min-AI16max		UINT16	R	
7392-7407		Raw Analog Inputs					
+0	0x3B80	Analog input AI1	0-4095		UINT16	R	
+1	0x3B81	Analog input AI2	0-4095		UINT16	R	
		...					

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+15	0x3B8F	Analog input AI16	0-4095		UINT16	R	
7456-7471		Scaled Analog Outputs					
+0	0x3C80	Analog input AO1	0-4095		UINT16	R/W	
+1	0x3C81	Analog input AO2	0-4095		UINT16	R/W	
		...					
+15	0x3C8F	Analog input AO16	0-4095		UINT16	R/W	
8000-8015		Billing Summary Accumulated Demands					
+0	0x4500	Summary register #1	0-Pmax	U3	UINT16	R	
+1	0x4501	Summary register #2	0-Pmax	U3	UINT16	R	
		...					
+15	0x4503	Summary register #16	0-Pmax	U3	UINT16	R	
8032-8047		Billing Summary Block Demands					
+0	0x4580	Summary register #1	0-Pmax	U3	UINT16	R	
+1	0x4581	Summary register #2	0-Pmax	U3	UINT16	R	
		...					
+15	0x4583	Summary register #16	0-Pmax	U3	UINT16	R	
8064-8079		Billing Summary Sliding Window Demands					
+0	0x4600	Summary register #1	0-Pmax	U3	UINT16	R	
+1	0x4601	Summary register #2	0-Pmax	U3	UINT16	R	
		...					
+15	0x4603	Summary register #16	0-Pmax	U3	UINT16	R	
8160-8175		Billing Summary Maximum Demands					
+0	0x4780	Summary register #1	0-Pmax	U3	UINT16	R	
+1	0x4781	Summary register #2	0-Pmax	U3	UINT16	R	
		...					
+15	0x4783	Summary register #16	0-Pmax	U3	UINT16	R	
8192-8207		Billing TOU Maximum Demand Register #1					
+0	0x4800	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x4801	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x480F	Tariff #16 register	0-Pmax	U3	UINT16	R	
8224-8239		Billing TOU Maximum Demand Register #4					
+0	0x4880	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x4881	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x488F	Tariff #16 register	0-Pmax	U3	UINT16	R	
8256-8271		Billing TOU Maximum Demand Register #2					
+0	0x4900	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x4901	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x490F	Tariff #16 register	0-Pmax	U3	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
8288-8303		Billing TOU Maximum Demand Register #5					
+0	0x4980	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x4981	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x498F	Tariff #16 register	0-Pmax	U3	UINT16	R	
8320-8335		Billing TOU Maximum Demand Register #3					
+0	0x4A00	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x4A01	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x4A0F	Tariff #16 register	0-Pmax	U3	UINT16	R	
8352-8367		Billing TOU Maximum Demand Register #6					
+0	0x4A80	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x4A81	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x4A8F	Tariff #16 register	0-Pmax	U3	UINT16	R	
8896-8911		Billing TOU Maximum Demand Register #7					
+0	0x5300	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x5301	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x530F	Tariff #16 register	0-Pmax	U3	UINT16	R	
8928-8943		Billing TOU Maximum Demand Register #8					
+0	0x5380	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x5381	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x538F	Tariff #16 register	0-Pmax	U3	UINT16	R	
8960-8975		Billing TOU Maximum Demand Register #9					
+0	0x5400	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x5401	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x540F	Tariff #16 register	0-Pmax	U3	UINT16	R	
8992-9007		Billing TOU Maximum Demand Register #10					
+0	0x5480	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x5481	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x548F	Tariff #16 register	0-Pmax	U3	UINT16	R	
9024-9039		Billing TOU Maximum Demand Register #11					
+0	0x5500	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x5501	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x550F	Tariff #16 register	0-Pmax	U3	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
9056-9071		Billing TOU Maximum Demand Register #12					
+0	0x5580	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x5581	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x558F	Tariff #16 register	0-Pmax	U3	UINT16	R	
9088-9103		Billing TOU Maximum Demand Register #13					
+0	0x5600	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x5601	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x560F	Tariff #16 register	0-Pmax	U3	UINT16	R	
9120-9135		Billing TOU Maximum Demand Register #14					
+0	0x5680	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x5681	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x568F	Tariff #16 register	0-Pmax	U3	UINT16	R	
9152-9167		Billing TOU Maximum Demand Register #15					
+0	0x5700	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x5701	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x570F	Tariff #16 register	0-Pmax	U3	UINT16	R	
9184-9199		Billing TOU Maximum Demand Register #16					
+0	0x5780	Tariff #1 register	0-Pmax	U3	UINT16	R	
+1	0x5781	Tariff #2 register	0-Pmax	U3	UINT16	R	
		...				R	
+15	0x578F	Tariff #16 register	0-Pmax	U3	UINT16	R	
10496-10520		0.2-Second RMS and Auxiliary Values					
+0	0x6C00	V1 voltage	0-Vmax	U1	UINT16	R	1
+1	0x6C01	V2 voltage	0-Vmax	U1	UINT16	R	1
+2	0x6C02	V3 voltage	0-Vmax	U1	UINT16	R	1
+3	0x6C03	V4 voltage	0-V4max	U4	UINT16	R	
+4	0x6C04	V12 voltage	0-Vmax	U1	UINT16	R	
+5	0x6C05	V23 voltage	0-Vmax	U1	UINT16	R	
+6	0x6C06	V31 voltage	0-Vmax	U1	UINT16	R	
+7	0x6C07	I1 current	0-Imax	U2	UINT16	R	
+8	0x6C08	I2 current	0-Imax	U2	UINT16	R	
+9	0x6C09	I3 current	0-Imax	U2	UINT16	R	
+10	0x6C0A	I4 current	0-I4max	U2	UINT16	R	
+11	0x6C0B	In current	0-Imax	U2	UINT16	R	
+12	0x6C0C	I1x current	0-Ixmax	U2	UINT16	R	
+13	0x6C0D	I2x current	0-Ixmax	U2	UINT16	R	
+14	0x6C0E	I3x current	0-Ixmax	U2	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+15	0x6C0F	I4x current	0-I4xmax	U2	UINT16	R	
+16	0x6C10	Inx current	0-Ixmax	U2	UINT16	R	
+17	0x6C11	Zero-sequence voltage	0-Vmax	U1	UINT16	R	
+18	0x6C12	Zero-sequence current	0-Imax	U2	UINT16	R	
+19	0x6C13	Ix Zero-sequence current	0-Ixmax	U2	UINT16	R	
+20	0x6C14	Voltage unbalance	0-300.0	0.1%	UINT16	R	
+21	0x6C15	Current unbalance	0-300.0	0.1%	UINT16	R	
+22	0x6C16	Ix current unbalance	0-300.0	0.1%	UINT16	R	
+23	0x6C17	DC voltage	0-9999.00	0.01V	UINT16	R	
+24	0x6C18	Frequency	0-100.00	0.01Hz	UINT16	R	
10528-10552		3-Second RMS and Auxiliary Values					
+0	0x6C80	V1 voltage	0-Vmax	U1	UINT16	R	1
+1	0x6C81	V2 voltage	0-Vmax	U1	UINT16	R	1
+2	0x6C82	V3 voltage	0-Vmax	U1	UINT16	R	1
+3	0x6C83	V4 voltage	0-V4max	U4	UINT16	R	
+4	0x6C84	V12 voltage	0-Vmax	U1	UINT16	R	
+5	0x6C85	V23 voltage	0-Vmax	U1	UINT16	R	
+6	0x6C86	V31 voltage	0-Vmax	U1	UINT16	R	
+7	0x6C87	I1 current	0-Imax	U2	UINT16	R	
+8	0x6C88	I2 current	0-Imax	U2	UINT16	R	
+9	0x6C89	I3 current	0-Imax	U2	UINT16	R	
+10	0x6C8A	I4 current	0-I4max	U2	UINT16	R	
+11	0x6C8B	In current	0-Imax	U2	UINT16	R	
+12	0x6C8C	I1x current	0-Ixmax	U2	UINT16	R	
+13	0x6C8D	I2x current	0-Ixmax	U2	UINT16	R	
+14	0x6C8E	I3x current	0-Ixmax	U2	UINT16	R	
+15	0x6C8F	I4x current	0-I4xmax	U2	UINT16	R	
+16	0x6C90	Inx current	0-Ixmax	U2	UINT16	R	
+17	0x6C91	Zero-sequence voltage	0-Vmax	U1	UINT16	R	
+18	0x6C92	Zero-sequence current	0-Imax	U2	UINT16	R	
+19	0x6C93	Ix Zero-sequence current	0-Ixmax	U2	UINT16	R	
+20	0x6C94	Voltage unbalance	0-300.0	0.1%	UINT16	R	
+21	0x6C95	Current unbalance	0-300.0	0.1%	UINT16	R	
+22	0x6C96	Ix current unbalance	0-300.0	0.1%	UINT16	R	
+23	0x6C97	DC voltage	0-9999.00	0.01V	UINT16	R	
+24	0x6C98	Frequency	0-100.00	0.01Hz	UINT16	R	
10560-10584		10-Minute RMS and Auxiliary Values					
+0	0x6D00	V1 voltage	0-Vmax	U1	UINT16	R	1
+1	0x6D01	V2 voltage	0-Vmax	U1	UINT16	R	1
+2	0x6D02	V3 voltage	0-Vmax	U1	UINT16	R	1
+3	0x6D03	V4 voltage	0-V4max	U4	UINT16	R	
+4	0x6D04	V12 voltage	0-Vmax	U1	UINT16	R	
+5	0x6D05	V23 voltage	0-Vmax	U1	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+6	0x6D06	V31 voltage	0-Vmax	U1	UINT16	R	
+7	0x6D07	I1 current	0-Imax	U2	UINT16	R	
+8	0x6D08	I2 current	0-Imax	U2	UINT16	R	
+9	0x6D09	I3 current	0-Imax	U2	UINT16	R	
+10	0x6D0A	I4 current	0-I4max	U2	UINT16	R	
+11	0x6D0B	In current	0-Imax	U2	UINT16	R	
+12	0x6D0C	I1x current	0-Ixmax	U2	UINT16	R	
+13	0x6D0D	I2x current	0-Ixmax	U2	UINT16	R	
+14	0x6D0E	I3x current	0-Ixmax	U2	UINT16	R	
+15	0x6D0F	I4x current	0-I4xmax	U2	UINT16	R	
+16	0x6D10	Inx current	0-Ixmax	U2	UINT16	R	
+17	0x6D11	Zero-sequence voltage	0-Vmax	U1	UINT16	R	
+18	0x6D12	Zero-sequence current	0-Imax	U2	UINT16	R	
+19	0x6D13	Ix Zero-sequence current	0-Ixmax	U2	UINT16	R	
+20	0x6D14	Voltage unbalance	0-300.0	0.1%	UINT16	R	
+21	0x6D15	Current unbalance	0-300.0	0.1%	UINT16	R	
+22	0x6D16	Ix current unbalance	0-300.0	0.1%	UINT16	R	
+23	0x6D17	DC voltage	0-9999.00	0.01V	UINT16	R	
+24	0x6D18	Frequency	0-100.00	0.01Hz	UINT16	R	
10592-10616		2-Hour RMS and Auxiliary Values					
+0	0x6D80	V1 voltage	0-Vmax	U1	UINT16	R	1
+1	0x6D81	V2 voltage	0-Vmax	U1	UINT16	R	1
+2	0x6D82	V3 voltage	0-Vmax	U1	UINT16	R	1
+3	0x6D83	V4 voltage	0-V4max	U4	UINT16	R	
+4	0x6D84	V12 voltage	0-Vmax	U1	UINT16	R	
+5	0x6D85	V23 voltage	0-Vmax	U1	UINT16	R	
+6	0x6D86	V31 voltage	0-Vmax	U1	UINT16	R	
+7	0x6D87	I1 current	0-Imax	U2	UINT16	R	
+8	0x6D88	I2 current	0-Imax	U2	UINT16	R	
+9	0x6D89	I3 current	0-Imax	U2	UINT16	R	
+10	0x6D8A	I4 current	0-I4max	U2	UINT16	R	
+11	0x6D8B	In current	0-Imax	U2	UINT16	R	
+12	0x6D8C	I1x current	0-Ixmax	U2	UINT16	R	
+13	0x6D8D	I2x current	0-Ixmax	U2	UINT16	R	
+14	0x6D8E	I3x current	0-Ixmax	U2	UINT16	R	
+15	0x6D8F	I4x current	0-I4xmax	U2	UINT16	R	
+16	0x6D90	Inx current	0-Ixmax	U2	UINT16	R	
+17	0x6D91	Zero-sequence voltage	0-Vmax	U1	UINT16	R	
+18	0x6D92	Zero-sequence current	0-Imax	U2	UINT16	R	
+19	0x6D93	Ix Zero-sequence current	0-Ixmax	U2	UINT16	R	
+20	0x6D94	Voltage unbalance	0-300.0	0.1%	UINT16	R	
+21	0x6D95	Current unbalance	0-300.0	0.1%	UINT16	R	
+22	0x6D96	Ix current unbalance	0-300.0	0.1%	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+23	0x6D97	DC voltage	0-9999.00	0.01V	UINT16	R	
+24	0x6D98	Frequency	0-100.00	0.01Hz	UINT16	R	
10624-10655		0.2-Second Harmonics					
+0	0x6E00	V1 THD	0-999.9	0.1%	UINT16	R	2
+1	0x6E01	V2 THD	0-999.9	0.1%	UINT16	R	2
+2	0x6E02	V3 THD	0-999.9	0.1%	UINT16	R	2
+3	0x6E03	V4 THD	0-999.9	0.1%	UINT16	R	
+4	0x6E04	I1 THD	0-999.9	0.1%	UINT16	R	
+5	0x6E05	I2 THD	0-999.9	0.1%	UINT16	R	
+6	0x6E06	I3 THD	0-999.9	0.1%	UINT16	R	
+7	0x6E07	I4 THD	0-999.9	0.1%	UINT16	R	
+8	0x6E08	V1 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+9	0x6E09	V2 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+10	0x6E0A	V3 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+11	0x6E0B	V4 interharmonics THD	0-999.9	0.1%	UINT16	R	
+12	0x6E0C	I1 interharmonics THD	0-999.9	0.1%	UINT16	R	
+13	0x6E0D	I2 interharmonics THD	0-999.9	0.1%	UINT16	R	
+14	0x6E0E	I3 interharmonics THD	0-999.9	0.1%	UINT16	R	
+15	0x6E0F	I4 interharmonics THD	0-999.9	0.1%	UINT16	R	
+16	0x6E10	I1 TDD	0-100.0	0.1%	UINT16	R	
+17	0x6E11	I2 TDD	0-100.0	0.1%	UINT16	R	
+18	0x6E12	I3 TDD	0-100.0	0.1%	UINT16	R	
+19	0x6E13	I4 TDD	0-100.0	0.1%	UINT16	R	
+20	0x6E14	I1 K-Factor	1.0-999.9	0.1	UINT16	R	
+21	0x6E15	I2 K-Factor	1.0-999.9	0.1	UINT16	R	
+22	0x6E16	I3 K-Factor	1.0-999.9	0.1	UINT16	R	
+23	0x6E17	I4 K-Factor	1.0-999.9	0.1	UINT16	R	
+24	0x6E18	V1 Crest Factor	0-100.00	0.01	UINT16	R	2
+25	0x6E19	V2 Crest Factor	0-100.00	0.01	UINT16	R	2
+26	0x6E1A	V3 Crest Factor	0-100.00	0.01	UINT16	R	2
+27	0x6E1B	V4 Crest Factor	0-100.00	0.01	UINT16	R	
+28	0x6E1C	I1 Crest Factor	0-100.00	0.01	UINT16	R	
+29	0x6E1D	I2 Crest Factor	0-100.00	0.01	UINT16	R	
+30	0x6E1E	I3 Crest Factor	0-100.00	0.01	UINT16	R	
+31	0x6E1F	I4 Crest Factor	0-100.00	0.01	UINT16	R	
10656-10687		3-Second Harmonics					
+0	0x6E80	V1 THD	0-999.9	0.1%	UINT16	R	2
+1	0x6E81	V2 THD	0-999.9	0.1%	UINT16	R	2
+2	0x6E82	V3 THD	0-999.9	0.1%	UINT16	R	2
+3	0x6E83	V4 THD	0-999.9	0.1%	UINT16	R	
+4	0x6E84	I1 THD	0-999.9	0.1%	UINT16	R	
+5	0x6E85	I2 THD	0-999.9	0.1%	UINT16	R	
+6	0x6E86	I3 THD	0-999.9	0.1%	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+7	0x6E87	I4 THD	0-999.9	0.1%	UINT16	R	
+8	0x6E88	V1 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+9	0x6E89	V2 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+10	0x6E8A	V3 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+11	0x6E8B	V4 interharmonics THD	0-999.9	0.1%	UINT16	R	
+12	0x6E6E	I1 interharmonics THD	0-999.9	0.1%	UINT16	R	
+13	0x6E8D	I2 interharmonics THD	0-999.9	0.1%	UINT16	R	
+14	0x6E8E	I3 interharmonics THD	0-999.9	0.1%	UINT16	R	
+15	0x6E8F	I4 interharmonics THD	0-999.9	0.1%	UINT16	R	
+16	0x6E90	I1 TDD	0-100.0	0.1%	UINT16	R	
+17	0x6E91	I2 TDD	0-100.0	0.1%	UINT16	R	
+18	0x6E92	I3 TDD	0-100.0	0.1%	UINT16	R	
+19	0x6E93	I4 TDD	0-100.0	0.1%	UINT16	R	
+20	0x6E94	I1 K-Factor	1.0-999.9	0.1	UINT16	R	
+21	0x6E95	I2 K-Factor	1.0-999.9	0.1	UINT16	R	
+22	0x6E96	I3 K-Factor	1.0-999.9	0.1	UINT16	R	
+23	0x6E97	I4 K-Factor	1.0-999.9	0.1	UINT16	R	
+24	0x6E98	V1 Crest Factor	0-100.00	0.01	UINT16	R	2
+25	0x6E99	V2 Crest Factor	0-100.00	0.01	UINT16	R	2
+26	0x6E9A	V3 Crest Factor	0-100.00	0.01	UINT16	R	2
+27	0x6E9B	V4 Crest Factor	0-100.00	0.01	UINT16	R	
+28	0x6E9C	I1 Crest Factor	0-100.00	0.01	UINT16	R	
+29	0x6E9D	I2 Crest Factor	0-100.00	0.01	UINT16	R	
+30	0x6E9E	I3 Crest Factor	0-100.00	0.01	UINT16	R	
+31	0x6E9F	I4 Crest Factor	0-100.00	0.01	UINT16	R	
10688-10719		10-Minute Harmonics					
+0	0x6F00	V1 THD	0-999.9	0.1%	UINT16	R	2
+1	0x6F01	V2 THD	0-999.9	0.1%	UINT16	R	2
+2	0x6F02	V3 THD	0-999.9	0.1%	UINT16	R	2
+3	0x6F03	V4 THD	0-999.9	0.1%	UINT16	R	
+4	0x6F04	I1 THD	0-999.9	0.1%	UINT16	R	
+5	0x6F05	I2 THD	0-999.9	0.1%	UINT16	R	
+6	0x6F06	I3 THD	0-999.9	0.1%	UINT16	R	
+7	0x6F07	I4 THD	0-999.9	0.1%	UINT16	R	
+8	0x6F08	V1 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+9	0x6F09	V2 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+10	0x6FOA	V3 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+11	0x6FOB	V4 interharmonics THD	0-999.9	0.1%	UINT16	R	
+12	0x6FOC	I1 interharmonics THD	0-999.9	0.1%	UINT16	R	
+13	0x6FOD	I2 interharmonics THD	0-999.9	0.1%	UINT16	R	
+14	0x6FOE	I3 interharmonics THD	0-999.9	0.1%	UINT16	R	
+15	0x6FOF	I4 interharmonics THD	0-999.9	0.1%	UINT16	R	
+16	0x6F10	I1 TDD	0-100.0	0.1%	UINT16	R	

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+17	0x6F11	I2 TDD	0-100.0	0.1%	UINT16	R	
+18	0x6F12	I3 TDD	0-100.0	0.1%	UINT16	R	
+19	0x6F13	I4 TDD	0-100.0	0.1%	UINT16	R	
+20	0x6F14	I1 K-Factor	1.0-999.9	0.1	UINT16	R	
+21	0x6F15	I2 K-Factor	1.0-999.9	0.1	UINT16	R	
+22	0x6F16	I3 K-Factor	1.0-999.9	0.1	UINT16	R	
+23	0x6F17	I4 K-Factor	1.0-999.9	0.1	UINT16	R	
+24	0x6F18	V1 Crest Factor	0-100.00	0.01	UINT16	R	2
+25	0x6F19	V2 Crest Factor	0-100.00	0.01	UINT16	R	2
+26	0x6F1A	V3 Crest Factor	0-100.00	0.01	UINT16	R	2
+27	0x6F1B	V4 Crest Factor	0-100.00	0.01	UINT16	R	
+28	0x6F1C	I1 Crest Factor	0-100.00	0.01	UINT16	R	
+29	0x6F1D	I2 Crest Factor	0-100.00	0.01	UINT16	R	
+30	0x6F1E	I3 Crest Factor	0-100.00	0.01	UINT16	R	
+31	0x6F1F	I4 Crest Factor	0-100.00	0.01	UINT16	R	
10720-10751		2-Hour Harmonics					
+0	0x6F80	V1 THD	0-999.9	0.1%	UINT16	R	2
+1	0x6F81	V2 THD	0-999.9	0.1%	UINT16	R	2
+2	0x6F82	V3 THD	0-999.9	0.1%	UINT16	R	2
+3	0x6F83	V4 THD	0-999.9	0.1%	UINT16	R	
+4	0x6F84	I1 THD	0-999.9	0.1%	UINT16	R	
+5	0x6F85	I2 THD	0-999.9	0.1%	UINT16	R	
+6	0x6F86	I3 THD	0-999.9	0.1%	UINT16	R	
+7	0x6F87	I4 THD	0-999.9	0.1%	UINT16	R	
+8	0x6F88	V1 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+9	0x6F89	V2 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+10	0x6F8A	V3 interharmonics THD	0-999.9	0.1%	UINT16	R	2
+11	0x6F8B	V4 interharmonics THD	0-999.9	0.1%	UINT16	R	
+12	0x6F8C	I1 interharmonics THD	0-999.9	0.1%	UINT16	R	
+13	0x6F8D	I2 interharmonics THD	0-999.9	0.1%	UINT16	R	
+14	0x6F8E	I3 interharmonics THD	0-999.9	0.1%	UINT16	R	
+15	0x6F8F	I4 interharmonics THD	0-999.9	0.1%	UINT16	R	
+16	0x6F90	I1 TDD	0-100.0	0.1%	UINT16	R	
+17	0x6F91	I2 TDD	0-100.0	0.1%	UINT16	R	
+18	0x6F92	I3 TDD	0-100.0	0.1%	UINT16	R	
+19	0x6F93	I4 TDD	0-100.0	0.1%	UINT16	R	
+20	0x6F94	I1 K-Factor	1.0-999.9	0.1	UINT16	R	
+21	0x6F95	I2 K-Factor	1.0-999.9	0.1	UINT16	R	
+22	0x6F96	I3 K-Factor	1.0-999.9	0.1	UINT16	R	
+23	0x6F97	I4 K-Factor	1.0-999.9	0.1	UINT16	R	
+24	0x6F98	V1 Crest Factor	0-100.00	0.01	UINT16	R	2
+25	0x6F99	V2 Crest Factor	0-100.00	0.01	UINT16	R	2
+26	0x6F9A	V3 Crest Factor	0-100.00	0.01	UINT16	R	2

Address	Point ID	Description	Low and High Scales ³	Units ³	Type	R/W	Notes
+27	0x6F9B	V4 Crest Factor	0-100.00	0.01	UINT16	R	
+28	0x6F9C	I1 Crest Factor	0-100.00	0.01	UINT16	R	
+29	0x6F9D	I2 Crest Factor	0-100.00	0.01	UINT16	R	
+30	0x6F9E	I3 Crest Factor	0-100.00	0.01	UINT16	R	
+31	0x6F9F	I4 Crest Factor	0-100.00	0.01	UINT16	R	

NOTES:

- ¹ When the 4LN3, 4LL3, 3LN3, 3LL3, 3BLN3 or 3BLL3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line.
- ² When the 4LN3, 3LN3 or 3BLN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.
- ³ For volts, amps, power and frequency scales and units, refer to Section 4 "Data Scales and Units".
- ⁴ On a 0.2-s interval.
- ⁵ On a 3-s interval.

3.4 32-bit Binary and Analog Values

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
11776-11777	0x0000	None	0		UINT32	R	
		Setpoint Status	0x00000000 - 0xFFFFFFFF				
11840-11841		Setpoints 1-32 (alias)	0x00000000 - 0xFFFFFFFF		UINT32	R	
27648-27649		Setpoints 1-32	0x00000000 - 0xFFFFFFFF		UINT32	R	
27712-27713		Setpoints 33-64	0x00000000 - 0xFFFFFFFF		UINT32	R	
	0x0080	Setpoint #1	0/1			TRG	
	0x0081	Setpoint #2	0/1			TRG	
		...					
	0x00BF	Setpoint #64	0/1			TRG	
11904-11907		Special Inputs					
	+0,1 0x0100	Voltage disturbance	0-100	%	UINT32	R	
	+2,3 0x0101	Phase rotation order	0 = error, 1 = positive (ABC), 2 = negative (CBA)		UINT32	R	
		Event Flags					
12160-12161		Event flags 1-32	0x00000000 - 0xFFFFFFFF		UINT32	R	
12224-12225		Event flags 33-64	0x00000000 - 0xFFFFFFFF		UINT32	R	
	0x0300	Event flag #1	0/1			TRG	
	0x0301	Event flag #2	0/1			TRG	
		...					
	0x033F	Event flag #64	0/1			TRG	
		Internal Pulsed Events					
	0x0400	kWh Import pulse	0/1			TRG	
	0x0401	kWh Export pulse	0/1			TRG	
	0x0402	kWh Total pulse	0/1			TRG	
	0x0403	kvarh Import pulse	0/1			TRG	
	0x0404	kvarh Export pulse	0/1			TRG	
	0x0405	kvarh Total pulse	0/1			TRG	
	0x0406	kVAh pulse	0/1			TRG	
	0x0407	Start of power demand interval pulse	0/1			TRG	
	0x0408	Start of tariff interval pulse	0/1			TRG	
		External Triggers (UDP)					
	0x0480	External trigger #1	0/1			TRG	
	0x0481	External trigger #2	0/1			TRG	
		...					
	0x048F	External trigger #16	0/1			TRG	
		Periodic Timers					
	0x0500	Timer #1	0/1			TRG	
	0x0501	Timer #2	0/1			TRG	
		...					

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
	0x050F	Timer #16	0/1			TRG	
		Digital Inputs					6
12544-12545		Digital inputs DI1–DI32	0x00000000 - 0xFFFFFFFF		UINT32	R	
12608-12609		Digital inputs DI33–DI64	0x00000000 - 0xFFFFFFFF		UINT32	R	
12672-12673		Digital inputs DI65–DI96	0x00000000 - 0xFFFFFFFF		UINT32	R	
12736-12737		Digital inputs DI97–DI128	0x00000000 - 0xFFFFFFFF		UINT32	R	
	0x0600	Digital input DI1	0/1			TRG	
	0x0601	Digital input DI2	0/1			TRG	
		...					
	0x067F	Digital input DI128	0/1			TRG	
		Pulse Inputs					7
	0x0700	Digital input DI1	0/1			TRG	
	0x0701	Digital input DI2	0/1			TRG	
		...					
	0x077F	Digital input DI128	0/1			TRG	
		Relay Outputs					
12800-12801		Relay outputs RO1–RO32	0x00000000 - 0xFFFFFFFF		UINT32	R	
12864-12865		Relay outputs RO33–RO64	0x00000000 - 0xFFFFFFFF		UINT32	R	
	0x0800	Relay output RO1	0/1			TRG	
	0x0801	Relay output RO2	0/1			TRG	
		...					
	0x083F	Relay output RO64	0/1			TRG	
		Static Event Flags					
12928-12929		Static event flags: Bit 0: Phase order error Bit 1: Positive phase order Bit 2: Negative phase order Bit 3: PQ event Bit 4: General fault event Bit 5: Fault detected Bit 6: External fault trigger Bit 7: Device fault (non-critical error) Bit 8: No voltage Bit 9: Remote control	0x00000000 - 0xFFFFFFFF		UINT32	R	
	0x0900	Phase order error	0/1			TRG	
	0x0901	Positive phase order	0/1			TRG	
	0x0902	Negative phase order	0/1			TRG	
	0x0903	PQ event	0/1			TRG	
	0x0904	General fault event	0/1			TRG	
	0x0905	Fault detected	0/1			TRG	
	0x0906	External fault trigger	0/1			TRG	
	0x0907	Device fault (non-critical error)	0/1			TRG	
	0x0908	No voltage	0/1			TRG	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
	0x0909	Remote control	0/1			TRG	
13056-13119		Counters					
+0,1	0x0A00	Counter #1	0 - 999,999,999		UINT32	R/W	
+2,3	0x0A01	Counter #2	0 - 999,999,999		UINT32	R/W	
		...					
+62,63	0x0A1F	Counter #32	0 - 999,999,999		UINT32	R/W	
		Time/Date					
	0x0B00	Packed date	YYMMDD		UINT32	TRG	
	0x0B01	Packed time	hhmmss		UINT32	TRG	
	0x0B02	Day of week	1-7, 1 = Sun, 7 = Sat		UINT32	TRG	
	0x0B03	Year	0-99		UINT32	TRG	
	0x0B04	Month	1-12		UINT32	TRG	
	0x0B05	Day of month	1-31		UINT32	TRG	
	0x0B06	Hours	0-23		UINT32	TRG	
	0x0B07	Minutes	0-59		UINT32	TRG	
	0x0B08	Seconds	0-59		UINT32	TRG	
13248-13297		1/2-Cycle Values					
+0,1	0x0B80	V1 voltage	0-Vmax	U1	UINT32	R	¹
+2,3	0x0B81	V2 voltage	0-Vmax	U1	UINT32	R	¹
+4,5	0x0B82	V3 voltage	0-Vmax	U1	UINT32	R	¹
+6,7	0x0B83	V4 voltage	0-V4max	U4	UINT32	R	
+8,9	0x0B84	V12 voltage	0-Vmax	U1	UINT32	R	
+10,11	0x0B85	V23 voltage	0-Vmax	U1	UINT32	R	
+12,13	0x0B86	V31 voltage	0-Vmax	U1	UINT32	R	
+14,15	0x0B87	I1 current	0-Imax	U2	UINT32	R	
+16,17	0x0B88	I2 current	0-Imax	U2	UINT32	R	
+18,19	0x0B89	I3 current	0-Imax	U2	UINT32	R	
+20,21	0x0B8A	I4 current	0-I4max	U2	UINT32	R	
+22,23	0x0B8B	In current	0-Imax	U2	UINT32	R	
+24,25	0x0B8C	I1x current	0-Ixmax	U2	UINT32	R	
+26,27	0x0B8D	I2x current	0-Ixmax	U2	UINT32	R	
+28,29	0x0B8E	I3x current	0-Ixmax	U2	UINT32	R	
+30,31	0x0B8F	I4x current	0-I4xmax	U2	UINT32	R	
+32,33	0x0B90	Irx current	0-Ixmax	U2	UINT32	R	
+34,35	0x0B91	Zero-sequence voltage	0-Vmax	U1	UINT32	R	
+36,37	0x0B92	Zero-sequence current	0-Imax	U2	UINT32	R	
+38,39	0x0B93	Ix Zero-sequence current	0-Ixmax	U2	UINT32	R	
+40,41	0x0B94	Voltage unbalance	0-3000	×0.1%	UINT32	R	
+42,43	0x0B95	Current unbalance	0-3000	×0.1%	UINT32	R	
+44,45	0x0B96	Ix current unbalance	0-3000	×0.1%	UINT32	R	
+46,47	0x0B97	DC voltage	0-999900	×0.01V	UINT32	R	
+48,49	0x0B98	Frequency (1-cycle)	0-10000	×0.01Hz	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
13312-13383		1-Cycle Phase Values					
+0,1	0x0C00	V1 voltage	0-Vmax	U1	UINT32	R	1
+2,3	0x0C01	V2 voltage	0-Vmax	U1	UINT32	R	1
+4,5	0x0C02	V3 voltage	0-Vmax	U1	UINT32	R	1
+6,7	0x0C03	I1 current	0-Imax	U2	UINT32	R	
+8,9	0x0C04	I2 current	0-Imax	U2	UINT32	R	
+10,11	0x0C05	I3 current	0-Imax	U2	UINT32	R	
+12,13	0x0C06	kW L1	-Pmax-Pmax	U3	INT32	R	
+14,15	0x0C07	kW L2	-Pmax-Pmax	U3	INT32	R	
+16,17	0x0C08	kW L3	-Pmax-Pmax	U3	INT32	R	
+18,19	0x0C09	kvar L1	-Pmax-Pmax	U3	INT32	R	
+20,21	0x0C0A	kvar L2	-Pmax-Pmax	U3	INT32	R	
+22,23	0x0C0B	kvar L3	-Pmax-Pmax	U3	INT32	R	
+24,25	0x0C0C	kVA L1	0-Pmax	U3	UINT32	R	
+26,27	0x0C0D	kVA L2	0-Pmax	U3	UINT32	R	
+28,29	0x0C0E	kVA L3	0-Pmax	U3	UINT32	R	
+30,31	0x0C0F	Power factor L1	-1000-1000	×0.001	INT32	R	
+32,33	0x0C10	Power factor L2	-1000-1000	×0.001	INT32	R	
+34,35	0x0C11	Power factor L3	-1000-1000	×0.001	INT32	R	
+36,37	0x0C12	V1 voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+38,39	0x0C13	V2 voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+40,41	0x0C14	V3 voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+42,43	0x0C15	I1 current THD	0-9999	×0.1%	UINT32	R	4
+44,45	0x0C16	I2 current THD	0-9999	×0.1%	UINT32	R	4
+46,47	0x0C17	I3 current THD	0-9999	×0.1%	UINT32	R	4
+48,49	0x0C18	I1 K-Factor	10-9999	×0.1	UINT32	R	4
+50,51	0x0C19	I2 K-Factor	10-9999	×0.1	UINT32	R	4
+52,53	0x0C1A	I3 K-Factor	10-9999	×0.1	UINT32	R	4
+54,55	0x0C1B	I1 current TDD	0-1000	×0.1%	UINT32	R	4
+56,57	0x0C1C	I2 current TDD	0-1000	×0.1%	UINT32	R	4
+58,59	0x0C1D	I3 current TDD	0-1000	×0.1%	UINT32	R	4
+60,61	0x0C1E	V12 voltage	0-Vmax	U1	UINT32	R	
+62,63	0x0C1F	V23 voltage	0-Vmax	U1	UINT32	R	
+64,65	0x0C20	V31 voltage	0-Vmax	U1	UINT32	R	
+66,67	0x0C21	I1x current	0-Ixmax	U2	UINT32	R	
+68,69	0x0C22	I2x current	0-Ixmax	U2	UINT32	R	
+70,71	0x0C23	I3x current	0-Ixmax	U2	UINT32	R	
13440-13467		1-Cycle Low Phase Values					
+0,1	0x0D00	Low L-N voltage	0-Vmax	U1	UINT32	R	
+2,3	0x0D01	Low current	0-Imax	U2	UINT32	R	
+4,5	0x0D02	Low kW	-Pmax-Pmax	U3	INT32	R	
+6,7	0x0D03	Low kvar	-Pmax-Pmax	U3	INT32	R	
+8,9	0x0D04	Low kVA	0-Pmax	U3	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+10,11	0x0D05	Low PF Lag	0-1000	×0.001	UINT32	R	
+12,13	0x0D06	Low PF Lead	0-1000	×0.001	UINT32	R	
+14,15	0x0D07	Low voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+16,17	0x0D08	Low current THD	0-9999	×0.1%	UINT32	R	4
+18,19	0x0D09	Low K-Factor	10-9999	×0.1	UINT32	R	4
+20,21	0x0D0A	Low current TDD	0-1000	×0.1%	UINT32	R	4
+22,23	0x0D0B	Low L-L voltage	0-Vmax	U1	UINT32	R	
+24,25	0x0D0C	Low voltage interharmonics THD	0-9999	×0.1%	UINT32	R	2, 4
+26,27	0x0D0D	Low current interharmonics THD	0-9999	×0.1%	UINT32	R	4
13504-13535		1/2-Cycle Analog Inputs					
+0,1	0x0D80	Analog input AI1	AI1min-AI1max		INT32	R	
+2,3	0x0D81	Analog input AI2	AI2min-AI2max		INT32	R	
		...					
+30,31	0x0D8F	Analog input AI16	AI16min-AI16max		INT32	R	
13568-13595		1-Cycle High Phase Values					
+0,1	0x0E00	High L-N voltage	0-Vmax	U1	UINT32	R	
+2,3	0x0E01	High current	0-Imax	U2	UINT32	R	
+4,5	0x0E02	High kW	-Pmax-Pmax	U3	INT32	R	
+6,7	0x0E03	High kvar	-Pmax-Pmax	U3	INT32	R	
+8,9	0x0E04	High kVA	0-Pmax	U3	UINT32	R	
+10,11	0x0E05	High PF Lag	0-1000	×0.001	UINT32	R	
+12,13	0x0E06	High PF Lead	0-1000	×0.001	UINT32	R	
+14,15	0x0E07	High voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+16,17	0x0E08	High current THD	0-9999	×0.1%	UINT32	R	4
+18,19	0x0E09	High K-Factor	10-9999	×0.1	UINT32	R	4
+20,21	0x0E0A	High current TDD	0-1000	×0.1%	UINT32	R	4
+22,23	0x0E0B	High L-L voltage	0-Vmax	U1	UINT32	R	
+24,25	0x0E0C	High voltage interharmonics THD	0-9999	×0.1%	UINT32	R	2, 4
+26,27	0x0E0D	High current interharmonics THD	0-9999	×0.1%	UINT32	R	4
13632-13663		1-Second Analog Inputs					
+0,1	0x0E80	Analog input AI1	AI1min-AI1max		INT32	R	
+2,3	0x0E81	Analog input AI2	AI2min-AI2max		INT32	R	
		...					
+30,31	0x0E8F	Analog input AI16	AI16min-AI16max		INT32	R	
13696-13723		1-Cycle Total Values					
+0,1	0x0F00	Total kW	-Pmax-Pmax	U3	INT32	R	
+2,3	0x0F01	Total kvar	-Pmax-Pmax	U3	INT32	R	
+4,5	0x0F02	Total kVA	0-Pmax	U3	UINT32	R	
+6,7	0x0F03	Total PF	-1000-1000	×0.001	INT32	R	
+8,9	0x0F04	Total PF lag	0-1000	×0.001	UINT32	R	
+10,11	0x0F05	Total PF lead	0-1000	×0.001	UINT32	R	
+12,13	0x0F06	Total kW import	0-Pmax	U3	UINT32	R	
+14,15	0x0F07	Total kW export	0-Pmax	U3	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+16,17	0x0F08	Total kvar import	0-Pmax	U3	UINT32	R	
+18,19	0x0F09	Total kvar export	0-Pmax	U3	UINT32	R	
+20,21	0x0F0A	3-phase average L-N voltage	0-Vmax	U1	UINT32	R	
+22,23	0x0F0B	3-phase average L-L voltage	0-Vmax	U1	UINT32	R	
+24,25	0x0F0C	3-phase average current	0-Imax	U2	UINT32	R	
+26,27	0x0F0D	3-phase average current, extended inputs I1x-I3x	0-Ixmax	U2	UINT32	R	
13824-13839		1-Cycle Auxiliary Values					
+0,1	0x1000	I4 current	0-Imax	U2	UINT32	R	
+2,3	0x1001	In current	0-Imax	U2	UINT32	R	
+4,5	0x1002	Frequency	0-10000	×0.01Hz	UINT32	R	
+6,7	0x1003	Voltage unbalance	0-3000	×0.1%	UINT32	R	
+8,9	0x1004	Current unbalance	0-3000	×0.1%	UINT32	R	
+10,11	0x1005	DC voltage	0-999900	×0.01V	UINT32	R	
+12,13	0x1006	V4 voltage	0-V4max	U4	UINT32	R	
+14,15	0x1007	I4x current	0-Ixmax	U2	UINT32	R	
13888-13919		Fundamental Phasor Values					
+0, 1	0x1080	V1 voltage magnitude	0-Vmax	U1	UINT32	R	2
+2, 3	0x1081	V2 voltage magnitude	0-Vmax	U1	UINT32	R	2
+4, 5	0x1082	V3 voltage magnitude	0-Vmax	U1	UINT32	R	2
+6, 7	0x1083	V4 voltage magnitude	0-V4max	U1	UINT32	R	
+8, 9	0x1084	I1 current magnitude	0-Imax	U2	UINT32	R	
+10, 11	0x1085	I2 current magnitude	0-Imax	U2	UINT32	R	
+12, 13	0x1086	I3 current magnitude	0-Imax	U2	UINT32	R	
+14, 15	0x1087	I4 current magnitude	0-Imax	U2	UINT32	R	
+16, 17	0x1088	V1 voltage angle	-1800-1800	×0.1°	INT32	R	2
+18, 19	0x1089	V2 voltage angle	-1800-1800	×0.1°	INT32	R	2
+20, 21	0x108A	V3 voltage angle	-1800-1800	×0.1°	INT32	R	2
+22, 23	0x108B	V4 voltage angle	-1800-1800	×0.1°	INT32	R	
+24, 25	0x108C	I1 current angle	-1800-1800	×0.1°	INT32	R	
+26, 27	0x108D	I2 current angle	-1800-1800	×0.1°	INT32	R	
+28, 29	0x108E	I3 current angle	-1800-1800	×0.1°	INT32	R	
+30, 31	0x108F	I4 current angle	-1800-1800	×0.1°	INT32	R	
13952-14023		1-Second Phase Values					
+0, 1	0x1100	V1 voltage	0-Vmax	U1	UINT32	R	1
+2, 3	0x1101	V2 voltage	0-Vmax	U1	UINT32	R	1
+4, 5	0x1102	V3 voltage	0-Vmax	U1	UINT32	R	1
+6, 7	0x1103	I1 current	0-Imax	U2	UINT32	R	
+8, 9	0x1104	I2 current	0-Imax	U2	UINT32	R	
+10, 11	0x1105	I3 current	0-Imax	U2	UINT32	R	
+12, 13	0x1106	kW L1	-Pmax-Pmax	U3	INT32	R	
+14, 15	0x1107	kW L2	-Pmax-Pmax	U3	INT32	R	
+16, 17	0x1108	kW L3	-Pmax-Pmax	U3	INT32	R	
+18, 19	0x1109	kvar L1	-Pmax-Pmax	U3	INT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+20, 21	0x110A	kvar L2	-Pmax-Pmax	U3	INT32	R	
+22, 23	0x110B	kvar L3	-Pmax-Pmax	U3	INT32	R	
+24, 25	0x110C	kVA L1	0-Pmax	U3	UINT32	R	
+26, 27	0x110D	kVA L2	0-Pmax	U3	UINT32	R	
+28, 29	0x110E	kVA L3	0-Pmax	U3	UINT32	R	
+30, 31	0x110F	Power factor L1	-1000-1000	×0.001	INT32	R	
+32, 33	0x1110	Power factor L2	-1000-1000	×0.001	INT32	R	
+34, 35	0x1111	Power factor L3	-1000-1000	×0.001	INT32	R	
+36, 37	0x1112	V1 voltage THD	0-9999	×0.1%	UINT32	R	2, 5
+38, 39	0x1113	V2 voltage THD	0-9999	×0.1%	UINT32	R	2, 5
+40, 41	0x1114	V3 voltage THD	0-9999	×0.1%	UINT32	R	2, 5
+42, 43	0x1115	I1 current THD	0-9999	×0.1%	UINT32	R	5
+44, 45	0x1116	I2 current THD	0-9999	×0.1%	UINT32	R	5
+46, 47	0x1117	I3 current THD	0-9999	×0.1%	UINT32	R	5
+48, 49	0x1118	I1 K-Factor	10-9999	×0.1	UINT32	R	5
+50, 51	0x1119	I2 K-Factor	10-9999	×0.1	UINT32	R	5
+52, 53	0x111A	I3 K-Factor	10-9999	×0.1	UINT32	R	5
+54, 55	0x111B	I1 current TDD	0-1000	×0.1%	UINT32	R	5
+56, 57	0x111C	I2 current TDD	0-1000	×0.1%	UINT32	R	5
+58, 59	0x111D	I3 current TDD	0-1000	×0.1%	UINT32	R	5
+60, 61	0x111E	V12 voltage	0-Vmax	U1	UINT32	R	
+62, 63	0x111F	V23 voltage	0-Vmax	U1	UINT32	R	
+64, 65	0x1120	V31 voltage	0-Vmax	U1	UINT32	R	
+66, 67	0x1121	I1x current	0-Ixmax	U2	UINT32	R	
+68, 69	0x1122	I2x current	0-Ixmax	U2	UINT32	R	
+70, 71	0x1123	I3x current	0-Ixmax	U2	UINT32	R	
14080-14107		1-Second Low Phase Values					
+0, 1	0x1200	Low L-N voltage	0-Vmax	U1	UINT32	R	
+2, 3	0x1201	Low current	0-Imax	U2	UINT32	R	
+4, 5	0x1202	Low kW	-Pmax-Pmax	U3	INT32	R	
+6, 7	0x1203	Low kvar	-Pmax-Pmax	U3	INT32	R	
+8, 9	0x1204	Low kVA	0-Pmax	U3	UINT32	R	
+10, 11	0x1205	Low PF Lag	0-1000	×0.001	UINT32	R	
+12, 13	0x1206	Low PF Lead	0-1000	×0.001	UINT32	R	
+14, 15	0x1207	Low voltage THD	0-9999	×0.1%	UINT32	R	2, 5
+16, 17	0x1208	Low current THD	0-9999	×0.1%	UINT32	R	5
+18, 19	0x1209	Low K-Factor	10-9999	×0.1	UINT32	R	5
+20, 21	0x120A	Low current TDD	0-1000	×0.1%	UINT32	R	5
+22, 23	0x120B	Low L-L voltage	0-Vmax	U1	UINT32	R	
+24, 25	0x120C	Low voltage interharmonics THD	0-9999	×0.1%	UINT32	R	2, 5
+26, 27	0x120D	Low current interharmonics THD	0-9999	×0.1%	UINT32	R	5
14208-14235		1-Second High Phase Values					
+0, 1	0x1300	High L-N voltage	0-Vmax	U1	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+2, 3	0x1301	High current	0-Imax	U2	UINT32	R	
+4, 5	0x1302	High kW	-Pmax-Pmax	U3	INT32	R	
+6, 7	0x1303	High kvar	-Pmax-Pmax	U3	INT32	R	
+8, 9	0x1304	High kVA	0-Pmax	U3	UINT32	R	
+10, 11	0x1305	High PF Lag	0-1000	×0.001	UINT32	R	
+12, 13	0x1306	High PF Lead	0-1000	×0.001	UINT32	R	
+14, 15	0x1307	High voltage THD	0-9999	×0.1%	UINT32	R	2, 5
+16, 17	0x1308	High current THD	0-9999	×0.1%	UINT32	R	5
+18, 19	0x1309	High K-Factor	10-9999	×0.1	UINT32	R	5
+20, 21	0x130A	High current TDD	0-1000	×0.1%	UINT32	R	5
+22, 23	0x130B	High L-L voltage	0-Vmax	U1	UINT32	R	
+24, 25	0x130C	High voltage interharmonics THD	0-9999	×0.1%	UINT32	R	2, 5
+26, 27	0x130D	High current interharmonics THD	0-9999	×0.1%	UINT32	R	5
14336-14363		1-Second Total Values					
+0, 1	0x1400	Total kW	-Pmax-Pmax	U3	INT32	R	
+2, 3	0x1401	Total kvar	-Pmax-Pmax	U3	INT32	R	
+4, 5	0x1402	Total kVA	0-Pmax	U3	UINT32	R	
+6, 7	0x1403	Total PF	-1000-1000	×0.001	INT32	R	
+8, 9	0x1404	Total PF lag	0-1000	×0.001	UINT32	R	
+10, 11	0x1405	Total PF lead	0-1000	×0.001	UINT32		
+12, 13	0x1406	Total kW import	0-Pmax	U3	UINT32		
+14, 15	0x1407	Total kW export	0-Pmax	U3	UINT32	R	
+16, 17	0x1408	Total kvar import	0-Pmax	U3	UINT32	R	
+18, 19	0x1409	Total kvar export	0-Pmax	U3	UINT32	R	
+20, 21	0x140A	3-phase average L-N voltage	0-Vmax	U1	UINT32	R	
+22, 23	0x140B	3-phase average L-L voltage	0-Vmax	U1	UINT32	R	
+24, 25	0x140C	3-phase average current	0-Imax	U2	UINT32	R	
+26, 27	0x140D	3-phase average current, extended inputs I1x-I3x	0-Ixmax	U2	UINT32	R	
14464-14479		1-Second Auxiliary Values					
+0, 1	0x1500	I4 current	0-Imax	U2	UINT32	R	
+2, 3	0x1501	In current	0-Imax	U2	UINT32	R	
+4, 5	0x1502	Frequency	0-10000	×0.01Hz	UINT32	R	
+6, 7	0x1503	Voltage unbalance	0-3000	×0.1%	UINT32	R	
+8, 9	0x1504	Current unbalance	0-3000	×0.1%	UINT32	R	
+10, 11	0x1505	DC voltage	0-999900	×0.01V	UINT32	R	
+12, 13	0x1506	V4 voltage	0-V4max	U4	UINT32	R	
+14, 15	0x1507	I4x current	0-Ixmax	U2	UINT32	R	
14528-14551		Present Harmonic Demands					
+0, 1	0x1580	V1 THD demand	0-9999	×0.1%	UINT32	R	2
+2, 3	0x1581	V2 THD demand	0-9999	×0.1%	UINT32	R	2
+4, 5	0x1582	V3 THD demand	0-9999	×0.1%	UINT32	R	2
+6, 7	0x1583	V4 THD demand	0-9999	×0.1%	UINT32	R	
+8, 9	0x1584	I1 THD demand	0-9999	×0.1%	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+10, 11	0x1585	I2 THD demand	0-9999	×0.1%	UINT32	R	
+12, 13	0x1586	I3 THD demand	0-9999	×0.1%	UINT32	R	
+14, 15	0x1587	I4 THD demand	0-9999	×0.1%	UINT32	R	
+16, 17	0x1588	I1 TDD demand	0-1000	×0.1%	UINT32	R	
+18, 19	0x1589	I2 TDD demand	0-1000	×0.1%	UINT32	R	
+20, 21	0x158A	I3 TDD demand	0-1000	×0.1%	UINT32	R	
+22, 23	0x158B	I4 TDD demand	0-1000	×0.1%	UINT32	R	
14592-14661		Present Demands					
+0, 1	0x1600	V1 volt demand	0-Vmax	U1	UINT32	R	2
+2, 3	0x1601	V2 volt demand	0-Vmax	U1	UINT32	R	2
+4, 5	0x1602	V3 volt demand	0-Vmax	U1	UINT32	R	2
+6, 7	0x1603	I1 ampere demand	0-Imax	U2	UINT32	R	
+8, 9	0x1604	I2 ampere demand	0-Imax	U2	UINT32	R	
+10, 11	0x1605	I3 ampere demand	0-Imax	U2	UINT32	R	
+12, 13	0x1606	kW import block demand	0-Pmax	U3	UINT32	R	
+14, 15	0x1607	kvar import block demand	0-Pmax	U3	UINT32	R	
+16, 17	0x1608	kVA block demand	0-Pmax	U3	UINT32	R	
+18, 19	0x1609	kW import sliding window demand	0-Pmax	U3	UINT32	R	
+20, 21	0x160A	kvar import sliding window demand	0-Pmax	U3	UINT32	R	
+22, 23	0x160B	kVA sliding window demand	0-Pmax	U3	UINT32	R	
+24, 25	0x160C	Not used	0		UINT32	R	
+26, 27	0x160D	Not used	0		UINT32	R	
+28, 29	0x160E	Not used	0		UINT32	R	
+30, 31	0x160F	kW import accumulated demand	0-Pmax	U3	UINT32	R	
+32, 33	0x1610	kvar import accumulated demand	0-Pmax	U3	UINT32	R	
+34, 35	0x1611	kVA accumulated demand	0-Pmax	U3	UINT32	R	
+36, 37	0x1612	kW import predicted sliding window demand	0-Pmax	U3	UINT32	R	
+38, 39	0x1613	kvar import predicted sliding window demand	0-Pmax	U3	UINT32	R	
+40, 41	0x1614	kVA predicted sliding window demand	0-Pmax	U3	UINT32	R	
+42, 43	0x1615	PF (import) at Max. kVA sliding window demand	0-1000	×0.001	UINT32	R	
+44, 45	0x1616	kW export block demand	0-Pmax	U3	UINT32	R	
+46, 47	0x1617	kvar export block demand	0-Pmax	U3	UINT32	R	
+48, 49	0x1618	kW export sliding window demand	0-Pmax	U3	UINT32	R	
+50, 51	0x1619	kvar export sliding window demand	0-Pmax	U3	UINT32	R	
+52, 53	0x161A	kW export accumulated demand	0-Pmax	U3	UINT32	R	
+54, 55	0x161B	kvar export accumulated demand	0-Pmax	U3	UINT32	R	
+56, 57	0x161C	kW export predicted sliding window demand	0-Pmax	U3	UINT32	R	
+58, 59	0x161D	kvar export predicted sliding window demand	0-Pmax	U3	UINT32	R	
+60, 61	0x161E	Not used	0		UINT32	R	
+62, 63	0x161F	Not used	0		UINT32	R	
+64, 65	0x1620	V4 volt demand	0-Vmax	U4	UINT32	R	
+66, 67	0x1621	I4 ampere demand	0-Imax	U2	UINT32	R	
+68, 69	0x1622	In ampere demand	0-Imax	U2	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
14720-14741		Total Energies					
+0, 1	0x1700	kWh import	0-999,999,999	1 kWh	UINT32	R	
+2, 3	0x1701	kWh export	0-999,999,999	1 kWh	UINT32	R	
+4, 5	0x1702	kWh net	-999,999,999-999,999,999	1 kWh	INT32	R	
+6, 7	0x1703	kWh total	0-999,999,999	1 kWh	UINT32	R	
+8, 9	0x1704	kvarh import	0-999,999,999	1 kvarh	UINT32	R	
+10, 11	0x1705	kvarh export	0-999,999,999	1 kvarh	UINT32	R	
+12, 13	0x1706	kvarh net	-999,999,999-999,999,999	1 kvarh	INT32	R	
+14, 15	0x1707	kvarh total	0-999,999,999	1 kvarh	UINT32	R	
+16, 17	0x1708	kVAh total	0-999,999,999	1 kVAh	UINT32	R	
+18, 19	0x1709	Vh total	0-999,999,999	1 Vh	UINT32	R	
+20, 21	0x170A	Ah total	0-999,999,999	1 Ah	UINT32	R	
14784-14815		Billing Summary Registers					
+0, 1	0x1780	Summary energy register #1	0-999,999,999	1 kWh	UINT32	R	
+2, 3	0x1781	Summary energy register #2	0-999,999,999	1 kWh	UINT32	R	
		...					
+30, 31	0x178F	Summary energy register #16	0-999,999,999	1 kWh	UINT32	R	
14912-14931		Symmetrical Components					
+0, 1	0x1880	Positive-sequence voltage	0-Vmax	U1	UINT32	R	
+2, 3	0x1881	Negative-sequence voltage	0-Vmax	U1	UINT32	R	
+4, 5	0x1882	Zero-sequence voltage	0-Vmax	U1	UINT32	R	
+6, 7	0x1883	Negative-sequence voltage unbalance	0-3000	×0.1%	UINT32	R	
+8, 9	0x1884	Zero-sequence voltage unbalance	0-3000	×0.1%	UINT32	R	
+10, 11	0x1885	Positive-sequence current	0-Imax	U2	UINT32	R	
+12, 13	0x1886	Negative-sequence current	0-Imax	U2	UINT32	R	
+14, 15	0x1887	Zero-sequence current	0-Imax	U2	UINT32	R	
+16, 17	0x1888	Negative-sequence current unbalance	0-3000	×0.1%	UINT32	R	
+18, 19	0x1889	Zero-sequence current unbalance	0-3000	×0.1%	UINT32	R	
14976-15101		V1 Harmonics					2
+0, 1	0x1900	H01 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
+2, 3	0x1901	H02 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
		...					
+124, 125	0x193E	H63 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
15104-15229		V2 Harmonics					2
+0, 1	0x1A00	H01 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
+2, 3	0x1A01	H02 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
		...					
+124, 125	0x1A3E	H63 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
15232-15357		V3 Harmonics					2
+0, 1	0x1B00	H01 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
+2, 3	0x1B01	H02 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
		...					

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+124, 125	0x1B3E	H63 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
15360-15485		I1 Harmonics					
+0, 1	0x1C00	H01 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
+2, 3	0x1C01	H02 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
		...					
+124, 125	0x1C3E	H63 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
15488-15613		I2 Harmonics					
+0, 1	0x1D00	H01 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
+2, 3	0x1D01	H02 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
		...					
+124, 125	0x1D3E	H63 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
15616-15741		I3 Harmonics					
+0, 1	0x1E00	H01 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
+2, 3	0x1E01	H02 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
		...					
+124, 125	0x1E3E	H63 Harmonic magnitude	0-10000	×0.01%	UINT32	R	
15744-15807		V1 Harmonic Voltages (odd numbers)					2
+0, 1	0x1F00	H01 Harmonic voltage	0-Vmax	U1	UINT32	R	
+2, 3	0x1F01	H03 Harmonic voltage	0-Vmax	U1	UINT32	R	
		...					
+62, 63	0x1F3E	H63 Harmonic voltage	0-Vmax	U1	UINT32	R	
15872-15935		V2 Harmonic Voltages (odd numbers)					2
+0, 1	0x2000	H01 Harmonic voltage	0-Vmax	U1	UINT32	R	
+2, 3	0x2001	H03 Harmonic voltage	0-Vmax	U1	UINT32	R	
		...					
+62, 63	0x203E	H63 Harmonic voltage	0-Vmax	U1	UINT32	R	
16000-16063		V3 Harmonic Voltages (odd numbers)					2
+0, 1	0x2100	H01 Harmonic voltage	0-Vmax	U1	UINT32	R	
+2, 3	0x2101	H03 Harmonic voltage	0-Vmax	U1	UINT32	R	
		...					
+62, 63	0x213E	H63 Harmonic voltage	0-Vmax	U1	UINT32	R	
16128-16191		I1 Harmonic Currents (odd numbers)					
+0, 1	0x2200	H01 Harmonic current	0-Imax	U2	UINT32	R	
+2, 3	0x2201	H03 Harmonic current	0-Imax	U2	UINT32	R	
		...					
+62, 63	0x223E	H63 Harmonic current	0-Imax	U2	UINT32	R	
16256-16319		I2 Harmonic Currents (odd numbers)					
+0, 1	0x2300	H01 Harmonic current	0-Imax	U2	UINT32	R	
+2, 3	0x2301	H03 Harmonic current	0-Imax	U2	UINT32	R	
		...					

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+62, 63	0x233E	H63 Harmonic current	0-Imax	U2	UINT32	R	
16384-16447		I3 Harmonic Currents (odd numbers)					
+0, 1	0x2400	H01 Harmonic current	0-Imax	U2	UINT32	R	
+2, 3	0x2401	H03 Harmonic current	0-Imax	U2	UINT32	R	
		...					
+62, 63	0x243E	H63 Harmonic current	0-Imax	U2	UINT32	R	
16512-16575		Total Harmonic kW (odd numbers)					
+0, 1	0x2500	H01 Harmonic kW	-Pmax -Pmax	U3	INT32	R	
+2, 3	0x2501	H03 Harmonic kW	-Pmax -Pmax	U3	INT32	R	
		...					
+62, 63	0x253E	H63 Harmonic kW	-Pmax -Pmax	U3	INT32	R	
16640-16703		Total Harmonic kvar (odd numbers)					
+0, 1	0x2600	H01 Harmonic kvar	-Pmax -Pmax	U3	INT32	R	
+2, 3	0x2601	H03 Harmonic kvar	-Pmax -Pmax	U3	INT32	R	
		...					
+62, 63	0x263E	H63 Harmonic kvar	-Pmax -Pmax	U3	INT32	R	
16768-16831		Total Harmonic Power Factor (odd numbers)					
+0, 1	0x2700	H01 Harmonic PF	-1000-1000	×0.001	INT32	R	
+2, 3	0x2701	H03 Harmonic PF	-1000-1000	×0.001	INT32	R	
		...					
+62, 63	0x273E	H63 Harmonic PF	-1000-1000	×0.001	INT32	R	
16896-17021		V4 Harmonics					
+0, 1	0x2800	H01 Harmonic magnitude	0-10000	0.01%	UINT32	R	
+2, 3	0x2801	H02 Harmonic magnitude	0-10000	0.01%	UINT32	R	
		...					
+124, 125	0x283E	H63 Harmonic magnitude	0-10000	0.01%	UINT32	R	
17088-17099		Flicker					
+0,1	0x2980	V1 Pst	0-10000	×0.01	UINT32	R	
+2,3	0x2981	V2 Pst	0-10000	×0.01	UINT32	R	
+4,5	0x2982	V3 Pst	0-10000	×0.01	UINT32	R	
+6,7	0x2983	V1 Plt	0-10000	×0.01	UINT32	R	
+8,9	0x2984	V2 Plt	0-10000	×0.01	UINT32	R	
+10,11	0x2985	V3 Plt	0-10000	×0.01	UINT32	R	
17280-17405		I4 Harmonics					
+0, 1	0x2B00	H01 Harmonic magnitude	0-10000	0.01%	UINT32	R	
+2, 3	0x2B01	H02 Harmonic magnitude	0-10000	0.01%	UINT32	R	
		...					
+124, 125	0x2B3E	H63 Harmonic magnitude	0-10000	0.01%	UINT32	R	
17408-17479		Minimum 1-Cycle Phase Values					
+0, 1	0x2C00	V1 voltage	0-Vmax	U1	UINT32	R	¹
+2, 3	0x2C01	V2 voltage	0-Vmax	U1	UINT32	R	¹

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+4, 5	0x2C02	V3 voltage	0-Vmax	U1	UINT32	R	1
+6, 7	0x2C03	I1 current	0-Imax	U2	UINT32	R	
+8, 9	0x2C04	I2 current	0-Imax	U2	UINT32	R	
+10, 11	0x2C05	I3 current	0-Imax	U2	UINT32	R	
+12, 13	0x2C06	kW L1	-Pmax-Pmax	U3	INT32	R	
+14, 15	0x2C07	kW L2	-Pmax-Pmax	U3	INT32	R	
+16, 17	0x2C08	kW L3	-Pmax-Pmax	U3	INT32	R	
+18, 19	0x2C09	kvar L1	-Pmax-Pmax	U3	INT32	R	
+20, 21	0x2C0A	kvar L2	-Pmax-Pmax	U3	INT32	R	
+22, 23	0x2C0B	kvar L3	-Pmax-Pmax	U3	INT32	R	
+24, 25	0x2C0C	kVA L1	0-Pmax	U3	UINT32	R	
+26, 27	0x2C0D	kVA L2	0-Pmax	U3	UINT32	R	
+28, 29	0x2C0E	kVA L3	0-Pmax	U3	UINT32	R	
+30, 31	0x2C0F	Power factor L1	0-1000	×0.001	UINT32	R	Absolute value
+32, 33	0x2C10	Power factor L2	0-1000	×0.001	UINT32	R	Absolute value
+34, 35	0x2C11	Power factor L3	0-1000	×0.001	UINT32	R	Absolute value
+36, 37	0x2C12	V1 voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+38, 39	0x2C13	V2 voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+40, 41	0x2C14	V3 voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+42, 43	0x2C15	I1 current THD	0-9999	×0.1%	UINT32	R	4
+44, 45	0x2C16	I2 current THD	0-9999	×0.1%	UINT32	R	4
+46, 47	0x2C17	I3 current THD	0-9999	×0.1%	UINT32	R	4
+48, 49	0x2C18	I1 K-Factor	10-9999	×0.1	UINT32	R	4
+50, 51	0x2C19	I2 K-Factor	10-9999	×0.1	UINT32	R	4
+52, 53	0x2C1A	I3 K-Factor	10-9999	×0.1	UINT32	R	4
+54, 55	0x2C1B	I1 current TDD	0-1000	×0.1%	UINT32	R	4
+56, 57	0x2C1C	I2 current TDD	0-1000	×0.1%	UINT32	R	4
+58, 59	0x2C1D	I3 current TDD	0-1000	×0.1%	UINT32	R	4
+60, 61	0x2C1E	V12 voltage	0-Vmax	U1	UINT32	R	
+62, 63	0x2C1F	V23 voltage	0-Vmax	U1	UINT32	R	
+64, 65	0x2C20	V31 voltage	0-Vmax	U1	UINT32	R	
+66, 67	0x2C21	I1x current	0-Ixmax	U2	UINT32	R	
+68, 69	0x2C22	I2x current	0-Ixmax	U2	UINT32	R	
+70, 71	0x2C23	I3x current	0-Ixmax	U2	UINT32	R	
17536-17547		Minimum 1-Cycle Total Values					
+0, 1	0x2D00	Total kW	-Pmax-Pmax	U3	INT32	R	
+2, 3	0x2D01	Total kvar	-Pmax-Pmax	U3	INT32	R	
+4, 5	0x2D02	Total kVA	0-Pmax	U3	UINT32	R	
+6, 7	0x2D03	Total PF	0-1000	×0.001	UINT32	R	Absolute value
+8, 9	0x2D04	Total PF lag	0-1000	×0.001	UINT32	R	
+10, 11	0x2D05	Total PF lead	0-1000	×0.001	UINT32	R	
17664-17685		Minimum 1-Cycle Auxiliary Values					
+0, 1	0x2E00	I4 current	0-Imax	U2	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+2, 3	0x2E01	In current	0-Imax	U2	UINT32	R	
+4, 5	0x2E02	Frequency	0-10000	×0.01Hz	UINT32	R	
+6, 7	0x2E03	Voltage unbalance	0-3000	×0.1%	UINT32	R	
+8, 9	0x2E04	Current unbalance	0-3000	×0.1%	UINT32	R	
+10, 11	0x2E05	DC voltage	0-999900	×0.01V	UINT32	R	
+12, 13	0x2E06	V4 voltage	0-V4max	U4	UINT32	R	
+14, 15	0x2E07	I4x current	0-Ixmax	U2	UINT32	R	
+16, 17	0x2E08	V4 THD	0-9999	×0.1%	UINT32	R	4
+18, 19	0x2E09	I4x THD	0-9999	×0.1%	UINT32	R	4
+20, 21	0x2E0A	I4x TDD	0-1000	×0.1%	UINT32	R	4
17728-17759		Minimum Analog Inputs					
+0,1	0x2E80	Analog input AI1	AI1min-AI1max		INT32	R	
+2,3	0x2E81	Analog input AI2	AI2min-AI2max		INT32	R	
		...					
+30,31	0x2E8F	Analog input AI16	AI16min-AI16max		INT32	R	
17920-17951		Programmable Min/Max Minimum Values					
+0, 1	0x3000	Min/Max Register #1			UINT32	R	
+2, 3	0x3001	Min/Max Register #2			UINT32	R	
		...					
+30, 31	0x300F	Min/Max Register #16			UINT32	R	
18048-18111		V4 Harmonic Voltages (odd numbers)					
+0, 1	0x3100	H01 Harmonic voltage	0-Vmax	U1	UINT32	R	
+2, 3	0x3101	H03 Harmonic voltage	0-Vmax	U1	UINT32	R	
		...					
+62, 63	0x313E	H63 Harmonic voltage	0-Vmax	U1	UINT32	R	
18176-18239		I4 Harmonic Currents (odd numbers)					
+0, 1	0x3200	H01 Harmonic current	0-Imax	U2	UINT32	R	
+2, 3	0x3201	H03 Harmonic current	0-Imax	U2	UINT32	R	
		...					
+62, 63	0x323E	H63 Harmonic current	0-Imax	U2	UINT32	R	
18432-18503		Maximum 1-Cycle Phase Values					
+0, 1	0x3400	V1 voltage	0-Vmax	U1	UINT32	R	1
+2, 3	0x3401	V2 voltage	0-Vmax	U1	UINT32	R	1
+4, 5	0x3402	V3 voltage	0-Vmax	U1	UINT32	R	1
+6, 7	0x3403	I1 current	0-Imax	U2	UINT32	R	
+8, 9	0x3404	I2 current	0-Imax	U2	UINT32	R	
+10, 11	0x3405	I3 current	0-Imax	U2	UINT32	R	
+12, 13	0x3406	kW L1	-Pmax-Pmax	U3	INT32	R	
+14, 15	0x3407	kW L2	-Pmax-Pmax	U3	INT32	R	
+16, 17	0x3408	kW L3	-Pmax-Pmax	U3	INT32	R	
+18, 19	0x3409	kvar L1	-Pmax-Pmax	U3	INT32	R	
+20, 21	0x340A	kvar L2	-Pmax-Pmax	U3	INT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+22, 23	0x340B	kvar L3	-Pmax-Pmax	U3	INT32	R	
+24, 25	0x340C	kVA L1	0-Pmax	U3	UINT32	R	
+26, 27	0x340D	kVA L2	0-Pmax	U3	UINT32	R	
+28, 29	0x340E	kVA L3	0-Pmax	U3	UINT32	R	
+30, 31	0x340F	Power factor L1	0-1000	×0.001	UINT32	R	Absolute value
+32, 33	0x3410	Power factor L2	0-1000	×0.001	UINT32	R	Absolute value
+34, 35	0x3411	Power factor L3	0-1000	×0.001	UINT32	R	Absolute value
+36, 37	0x3412	V1 voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+38, 39	0x3413	V2 voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+40, 41	0x3414	V3 voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+42, 43	0x3415	I1 current THD	0-9999	×0.1%	UINT32	R	4
+44, 45	0x3416	I2 current THD	0-9999	×0.1%	UINT32	R	4
+46, 47	0x3417	I3 current THD	0-9999	×0.1%	UINT32	R	4
+48, 49	0x3418	I1 K-Factor	10-9999	×0.1	UINT32	R	4
+50, 51	0x3419	I2 K-Factor	10-9999	×0.1	UINT32	R	4
+52, 53	0x341A	I3 K-Factor	10-9999	×0.1	UINT32	R	4
+54, 55	0x341B	I1 current TDD	0-1000	×0.1%	UINT32	R	4
+56, 57	0x341C	I2 current TDD	0-1000	×0.1%	UINT32	R	4
+58, 59	0x341D	I3 current TDD	0-1000	×0.1%	UINT32	R	4
+60, 61	0x341E	V12 voltage	0-Vmax	U1	UINT32	R	
+62, 63	0x341F	V23 voltage	0-Vmax	U1	UINT32	R	
+64, 65	0x3420	V31 voltage	0-Vmax	U1	UINT32	R	
+66, 67	0x3421	I1x current	0-Ixmax	U2	UINT32	R	
+68, 69	0x3422	I2x current	0-Ixmax	U2	UINT32	R	
+70, 71	0x3423	I3x current	0-Ixmax	U2	UINT32	R	
18560-18571		Maximum 1-Cycle Total Values					
+0, 1	0x3500	Total kW	-Pmax-Pmax	U3	INT32	R	
+2, 3	0x3501	Total kvar	-Pmax-Pmax	U3	INT32	R	
+4, 5	0x3502	Total kVA	0-Pmax	U3	UINT32	R	
+6, 7	0x3503	Total PF	0-1000	×0.001	UINT32	R	Absolute value
+8, 9	0x3504	Total PF lag	0-1000	×0.001	UINT32	R	
+10, 11	0x3505	Total PF lead	0-1000	×0.001	UINT32	R	
18668-18689		Maximum 1-Cycle Auxiliary Values					
+0, 1	0x3600	I4 current	0-Imax	U2	UINT32	R	
+2, 3	0x3601	In current	0-Imax	U2	UINT32	R	
+4, 5	0x3602	Frequency	0-10000	×0.01Hz	UINT32	R	
+6, 7	0x3603	Voltage unbalance	0-3000	×0.1%	UINT32	R	
+8, 9	0x3604	Current unbalance	0-3000	×0.1%	UINT32	R	
+10, 11	0x3605	DC voltage	0-999900	×0.01V	UINT32	R	
+12, 13	0x3606	V4 voltage	0-V4max	U4	UINT32	R	
+14, 15	0x3607	I4x current	0-Ixmax	U2	UINT32	R	
+16, 17	0x3608	V4 THD	0-9999	×0.1%	UINT32	R	4
+18, 19	0x3609	I4x THD	0-9999	×0.1%	UINT32	R	4

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+20, 21	0x360A	I4x TDD	0-1000	×0.1%	UINT32	R	4
18732-18795		Maximum Analog Inputs					
+0,1	0x3680	Analog input AI1	AI1min-AI1max		INT32	R	
+2,3	0x3681	Analog input AI2	AI2min-AI2max		INT32	R	
		...					
+30,31	0x368F	Analog input AI16	AI16min-AI16max		INT32	R	
18816-18859		Maximum Demands					
+0, 1	0x3700	V1 Maximum volt demand	0-Vmax	U1	UINT32	R	2
+2, 3	0x3701	V2 Maximum volt demand	0-Vmax	U1	UINT32	R	2
+4, 5	0x3702	V3 Maximum volt demand	0-Vmax	U1	UINT32	R	2
+6, 7	0x3703	I1 Maximum ampere demand	0-Imax	U2	UINT32	R	
+8, 9	0x3704	I2 Maximum ampere demand	0-Imax	U2	UINT32	R	
+10, 11	0x3705	I3 Maximum ampere demand	0-Imax	U2	UINT32	R	
+12, 13	0x3706	Not used	0		UINT32	R	
+14, 15	0x3707	Not used	0		UINT32	R	
+16, 17	0x3708	Not used	0		UINT32	R	
+18, 19	0x3709	Maximum kW import sliding window demand	0-Pmax	U3	UINT32	R	
+20, 21	0x370A	Maximum kvar import sliding window demand	0-Pmax	U3	UINT32	R	
+22, 23	0x370B	Maximum kVA sliding window demand	0-Pmax	U3	UINT32	R	
+24, 25	0x3737	Not used	0		UINT32	R	
+26, 27	0x370D	Not used	0		UINT32	R	
+28, 29	0x370E	Not used	0		UINT32	R	
+30, 31	0x370F	Maximum kW export sliding window demand	0-Pmax	U3	UINT32	R	
+32, 33	0x3710	Maximum kvar export sliding window demand	0-Pmax	U3	UINT32	R	
+34, 35	0x3737	Not used	0		UINT32	R	
+36, 37	0x3712	Not used	0		UINT32	R	
+38, 39	0x3713	V4 Maximum volt demand	0-Vmax	U4	UINT32	R	
+40, 41	0x3714	I4 Maximum ampere demand	0-I4max	U2	UINT32	R	
+42, 43	0x3715	In Maximum ampere demand	0-Imax	U2	UINT32	R	
18944-18975		Programmable Min/Max Maximum Values					
+0, 1	0x3800	Min/Max Register #1			UINT32	R	
+2, 3	0x3801	Min/Max Register #2			UINT32	R	
		...					
+30, 31	0x380F	Min/Max Register #16			UINT32	R	
19008-19031		Maximum Harmonic Demands					
+0, 1	0x3880	V1 THD demand	0-9999	×0.1%	UINT32	R	2
+2, 3	0x3881	V2 THD demand	0-9999	×0.1%	UINT32	R	2
+4, 5	0x3882	V3 THD demand	0-9999	×0.1%	UINT32	R	2
+6, 7	0x3883	V4 THD demand	0-9999	×0.1%	UINT32	R	
+8, 9	0x3884	I1 THD demand	0-9999	×0.1%	UINT32	R	
+10, 11	0x3885	I2 THD demand	0-9999	×0.1%	UINT32	R	
+12, 13	0x3886	I3 THD demand	0-9999	×0.1%	UINT32	R	
+14, 15	0x3887	I4 THD demand	0-9999	×0.1%	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+16, 17	0x3888	I1 TDD demand	0-1000	×0.1%	UINT32	R	
+18, 19	0x3889	I2 TDD demand	0-1000	×0.1%	UINT32	R	
+20, 21	0x388A	I3 TDD demand	0-1000	×0.1%	UINT32	R	
+22, 23	0x388B	I4 TDD demand	0-1000	×0.1%	UINT32	R	
19072-19135		Maximum Analog Input Demands					
+0,1	0x3900	Analog input AI1+	AI1min-AI1max		UINT32	R	Positive AI readings demand
+2,3	0x3901	Analog input AI2+	AI2min-AI2max		UINT32	R	
		...					
+30,31	0x390F	Analog input AI16+	AI16min-AI16max		UINT32	R	
+32,33	0x3910	Analog input AI1-	AI1min-AI1max		UINT32	R	Negative AI readings demand
+34,35	0x3911	Analog input AI2-	AI2min-AI2max		UINT32	R	
		...					
+62,63	0x391F	Analog input AI16-	AI16min-AI16max		UINT32	R	
19200-19263		Present Analog Input Demands					
+0,1	0x3A00	Analog input AI1+	AI1min-AI1max		UINT32	R	Positive AI readings demand
+2,3	0x3A01	Analog input AI2+	AI2min-AI2max		UINT32	R	
		...					
+30,31	0x3A0F	Analog input AI16+	AI16min-AI16max		UINT32	R	
+32,33	0x3A10	Analog input AI1-	AI1min-AI1max		UINT32	R	Negative AI readings demand
+34,35	0x3A11	Analog input AI2-	AI2min-AI2max		UINT32	R	
		...					
+62,63	0x3A1F	Analog input AI16-	AI16min-AI16max		UINT32	R	
19328-19359		1-Cycle Analog Inputs					
+0,1	0x3B00	Analog input AI1	AI1min-AI1max		INT32	R	
+2,3	0x3B01	Analog input AI2	AI2min-AI2max		INT32	R	
		...					
+30,31	0x3B0F	Analog input AI16	AI16min-AI16max		INT32	R	
19392-19423		Raw Analog Inputs					
+0,1	0x3B80	Analog input AI1	0-4095		UINT32	R	
+2,3	0x3B81	Analog input AI2	0-4095		UINT32	R	
		...					
+30,31	0x3B8F	Analog input AI16	0-4095		UINT32	R	
19456-19459		TOU Parameters					
+0, 1	0x3C00	Active tariff	0-15 = Tariff 1-16		UINT32	R	
+2, 3	0x3C01	Active profile	0-15 = Profile 1-16		UINT32	R	
19520-19551		Scaled Analog Outputs					
+0, 1	0x3C80	Analog input AO1	0-4095		UINT32	R/W	
+2, 3	0x3C81	Analog input AO2	0-4095		UINT32	R/W	
		...					
+30, 31	0x3C8F	Analog input AO16	0-4095		UINT32	R/W	
19584-19615		Billing TOU Register #1					
+0, 1	0x3D00	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x3D01	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
		...				R	
+30, 31	0x3D0F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
19712-19743		Billing TOU Register #2					
+0, 1	0x3E00	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x3E01	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x3E0F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
19840-19871		Billing TOU Register #3					
+0, 1	0x3F00	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x3F01	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x3F0F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
19968-19999		Billing TOU Register #4					
+0, 1	0x4000	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x4001	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x400F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
20096-20127		Billing TOU Register #5					
+0, 1	0x4100	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x4101	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x410F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
20224-20255		Billing TOU Register #6					
+0, 1	0x4200	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x4201	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x420F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
20352-20383		Billing TOU Register #7					
+0, 1	0x4300	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x4301	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x430F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
20480-20511		Billing TOU Register #8					
+0, 1	0x4400	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x4401	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x440F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
21376-21407		Billing TOU Register #9					
+0, 1	0x4B00	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x4B01	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+30, 31	0x4B0F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
21504-21535		Billing TOU Register #10					
+0, 1	0x4C00	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x4C01	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x4C0F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
21632-21663		Billing TOU Register #11					
+0, 1	0x4D00	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x4D01	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x4D0F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
21760-21791		Billing TOU Register #12					
+0, 1	0x4E00	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x4E01	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x4E0F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
21888-21919		Billing TOU Register #13					
+0, 1	0x4F00	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x4F01	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x4F0F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
22016-22047		Billing TOU Register #14					
+0, 1	0x5000	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x5001	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x500F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
22144-22175		Billing TOU Register #15					
+0, 1	0x5100	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x5101	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x510F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
22272-22303		Billing TOU Register #16					
+0, 1	0x5200	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
+2, 3	0x5201	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
		...				R	
+30, 31	0x520F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32	R	
20608-20639		Billing Summary Accumulated Demands					
+0, 1	0x4500	Summary register #1	0-Pmax	U3	UINT32	R	
+2, 3	0x4501	Summary register #2	0-Pmax	U3	UINT32	R	
		...					

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+30, 31	0x4503	Summary register #16	0-Pmax	U3	UINT32	R	
20672-20703		Billing Summary Block Demands					
+0, 1	0x4580	Summary register #1	0-Pmax	U3	UINT32	R	
+2, 3	0x4581	Summary register #2	0-Pmax	U3	UINT32	R	
		...					
+30, 31	0x4583	Summary register #16	0-Pmax	U3	UINT32	R	
20736-20767		Billing Summary Sliding Window Demands					
+0, 1	0x4600	Summary register #1	0-Pmax	U3	UINT32	R	
+2, 3	0x4601	Summary register #2	0-Pmax	U3	UINT32	R	
		...					
+30, 31	0x4603	Summary register #16	0-Pmax	U3	UINT32	R	
20928-20959		Billing Summary Maximum Demands					
+0, 1	0x4780	Summary register #1	0-Pmax	U3	UINT32	R	
+2, 3	0x4781	Summary register #2	0-Pmax	U3	UINT32	R	
		...					
+30, 31	0x4783	Summary register #16	0-Pmax	U3	UINT32	R	
20992-21023		Billing TOU Maximum Demand Register #1					
+0, 1	0x4800	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x4801	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x480F	Tariff #16 register	0-Pmax	U3	UINT32	R	
21056-21087		Billing TOU Maximum Demand Register #4					
+0, 1	0x4880	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x4881	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x488F	Tariff #16 register	0-Pmax	U3	UINT32	R	
21120-21151		Billing TOU Maximum Demand Register #2					
+0, 1	0x4900	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x4901	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x490F	Tariff #16 register	0-Pmax	U3	UINT32	R	
21184-21215		Billing TOU Maximum Demand Register #5					
+0, 1	0x4980	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x4981	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x498F	Tariff #16 register	0-Pmax	U3	UINT32	R	
21248-21279		Billing TOU Maximum Demand Register #3					
+0, 1	0x4A00	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x4A01	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+30, 31	0x4A0F	Tariff #16 register	0-Pmax	U3	UINT32	R	
21312-21343		Billing TOU Maximum Demand Register #6					
+0, 1	0x4A80	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x4A81	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x4A8F	Tariff #16 register	0-Pmax	U3	UINT32	R	
22400-22431		Billing TOU Maximum Demand Register #7					
+0, 1	0x5300	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x5301	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x530F	Tariff #16 register	0-Pmax	U3	UINT32	R	
22464-22495		Billing TOU Maximum Demand Register #8					
+0, 1	0x5380	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x5381	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x538F	Tariff #16 register	0-Pmax	U3	UINT32	R	
22528-22559		Billing TOU Maximum Demand Register #9					
+0, 1	0x5400	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x5401	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x540F	Tariff #16 register	0-Pmax	U3	UINT32	R	
22592-22623		Billing TOU Maximum Demand Register #10					
+0, 1	0x5480	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x5481	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x548F	Tariff #16 register	0-Pmax	U3	UINT32	R	
22656-22687		Billing TOU Maximum Demand Register #11					
+0, 1	0x5500	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x5501	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x550F	Tariff #16 register	0-Pmax	U3	UINT32	R	
22720-22751		Billing TOU Maximum Demand Register #12					
+0, 1	0x5580	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x5581	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x558F	Tariff #16 register	0-Pmax	U3	UINT32	R	
22784-22815		Billing TOU Maximum Demand Register #13					
+0, 1	0x5600	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x5601	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+30, 31	0x560F	Tariff #16 register	0-Pmax	U3	UINT32	R	
22848-22879		Billing TOU Maximum Demand Register #14					
+0, 1	0x5680	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x5681	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x568F	Tariff #16 register	0-Pmax	U3	UINT32	R	
22912-22943		Billing TOU Maximum Demand Register #15					
+0, 1	0x5700	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x5701	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x570F	Tariff #16 register	0-Pmax	U3	UINT32	R	
22976-23007		Billing TOU Maximum Demand Register #16					
+0, 1	0x5780	Tariff #1 register	0-Pmax	U3	UINT32	R	
+2, 3	0x5781	Tariff #2 register	0-Pmax	U3	UINT32	R	
		...				R	
+30, 31	0x578F	Tariff #16 register	0-Pmax	U3	UINT32	R	
25600-25649		0.2-Second RMS and Auxiliary Values					
+0, 1	0x6C00	V1 voltage	0-Vmax	U1	UINT32	R	1
+2, 3	0x6C01	V2 voltage	0-Vmax	U1	UINT32	R	1
+4, 5	0x6C02	V3 voltage	0-Vmax	U1	UINT32	R	1
+6, 7	0x6C03	V4 voltage	0-V4max	U4	UINT32	R	
+8, 9	0x6C04	V12 voltage	0-Vmax	U1	UINT32	R	
+10, 11	0x6C05	V23 voltage	0-Vmax	U1	UINT32	R	
+12, 13	0x6C06	V31 voltage	0-Vmax	U1	UINT32	R	
+14, 15	0x6C07	I1 current	0-Imax	U2	UINT32	R	
+16, 17	0x6C08	I2 current	0-Imax	U2	UINT32	R	
+18, 19	0x6C09	I3 current	0-Imax	U2	UINT32	R	
+20, 21	0x6C0A	I4 current	0-I4max	U2	UINT32	R	
+22, 23	0x6C0B	In current	0-Imax	U2	UINT32	R	
+24, 25	0x6C0C	I1x current	0-Ixmax	U2	UINT32	R	
+26, 27	0x6C0D	I2x current	0-Ixmax	U2	UINT32	R	
+28, 29	0x6C0E	I3x current	0-Ixmax	U2	UINT32	R	
+30, 31	0x6C0F	I4x current	0-I4xmax	U2	UINT32	R	
+32, 33	0x6C10	Inx current	0-Ixmax	U2	UINT32	R	
+34, 35	0x6C11	Zero-sequence voltage	0-Vmax	U1	UINT32	R	
+36, 37	0x6C12	Zero-sequence current	0-Imax	U2	UINT32	R	
+38, 39	0x6C13	Ix Zero-sequence current	0-Ixmax	U2	UINT32	R	
+40, 41	0x6C14	Voltage unbalance	0-3000	×0.1%	UINT32	R	
+42, 43	0x6C15	Current unbalance	0-3000	×0.1%	UINT32	R	
+44, 45	0x6C16	Ix current unbalance	0-3000	×0.1%	UINT32	R	
+46, 47	0x6C17	DC voltage	0-999900	×0.01V	UINT32	R	
+48, 49	0x6C18	Frequency	0-10000	×0.01Hz	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
25664-25713		3-Second RMS and Auxiliary Values					
+0, 1	0x6C80	V1 voltage	0-Vmax	U1	UINT32	R	1
+2, 3	0x6C81	V2 voltage	0-Vmax	U1	UINT32	R	1
+4, 5	0x6C82	V3 voltage	0-Vmax	U1	UINT32	R	1
+6, 7	0x6C83	V4 voltage	0-V4max	U4	UINT32	R	
+8, 9	0x6C84	V12 voltage	0-Vmax	U1	UINT32	R	
+10, 11	0x6C85	V23 voltage	0-Vmax	U1	UINT32	R	
+12, 13	0x6C86	V31 voltage	0-Vmax	U1	UINT32	R	
+14, 15	0x6C87	I1 current	0-Imax	U2	UINT32	R	
+16, 17	0x6C88	I2 current	0-Imax	U2	UINT32	R	
+18, 19	0x6C89	I3 current	0-Imax	U2	UINT32	R	
+20, 21	0x6C8A	I4 current	0-I4max	U2	UINT32	R	
+22, 23	0x6C8B	In current	0-Imax	U2	UINT32	R	
+24, 25	0x6C8C	I1x current	0-Ixmax	U2	UINT32	R	
+26, 27	0x6C8D	I2x current	0-Ixmax	U2	UINT32	R	
+28, 29	0x6C8E	I3x current	0-Ixmax	U2	UINT32	R	
+30, 31	0x6C8F	I4x current	0-I4xmax	U2	UINT32	R	
+32, 33	0x6C90	Inx current	0-Ixmax	U2	UINT32	R	
+34, 35	0x6C91	Zero-sequence voltage	0-Vmax	U1	UINT32	R	
+36, 37	0x6C92	Zero-sequence current	0-Imax	U2	UINT32	R	
+38, 39	0x6C93	Ix Zero-sequence current	0-Ixmax	U2	UINT32	R	
+40, 41	0x6C94	Voltage unbalance	0-3000	×0.1%	UINT32	R	
+42, 43	0x6C95	Current unbalance	0-3000	×0.1%	UINT32	R	
+44, 45	0x6C96	Ix current unbalance	0-3000	×0.1%	UINT32	R	
+46, 47	0x6C97	DC voltage	0-999900	×0.01V	UINT32	R	
+48, 49	0x6C98	Frequency	0-10000	×0.01Hz	UINT32	R	
25728-25777		10-Minute RMS and Auxiliary Values					
+0, 1	0x6D00	V1 voltage	0-Vmax	U1	UINT32	R	1
+2, 3	0x6D01	V2 voltage	0-Vmax	U1	UINT32	R	1
+4, 5	0x6D02	V3 voltage	0-Vmax	U1	UINT32	R	1
+6, 7	0x6D03	V4 voltage	0-V4max	U4	UINT32	R	
+8, 9	0x6D04	V12 voltage	0-Vmax	U1	UINT32	R	
+10, 11	0x6D05	V23 voltage	0-Vmax	U1	UINT32	R	
+12, 13	0x6D06	V31 voltage	0-Vmax	U1	UINT32	R	
+14, 15	0x6D07	I1 current	0-Imax	U2	UINT32	R	
+16, 17	0x6D08	I2 current	0-Imax	U2	UINT32	R	
+18, 19	0x6D09	I3 current	0-Imax	U2	UINT32	R	
+20, 21	0x6D0A	I4 current	0-I4max	U2	UINT32	R	
+22, 23	0x6D0B	In current	0-Imax	U2	UINT32	R	
+24, 25	0x6D0C	I1x current	0-Ixmax	U2	UINT32	R	
+26, 27	0x6D0D	I2x current	0-Ixmax	U2	UINT32	R	
+28, 29	0x6D0E	I3x current	0-Ixmax	U2	UINT32	R	
+30, 31	0x6D0F	I4x current	0-I4xmax	U2	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+32, 33	0x6D10	I _x current	0-I _x max	U2	UINT32	R	
+34, 35	0x6D11	Zero-sequence voltage	0-V _{max}	U1	UINT32	R	
+36, 37	0x6D12	Zero-sequence current	0-I _{max}	U2	UINT32	R	
+38, 39	0x6D13	I _x Zero-sequence current	0-I _x max	U2	UINT32	R	
+40, 41	0x6D14	Voltage unbalance	0-3000	×0.1%	UINT32	R	
+42, 43	0x6D15	Current unbalance	0-3000	×0.1%	UINT32	R	
+44, 45	0x6D16	I _x current unbalance	0-3000	×0.1%	UINT32	R	
+46, 47	0x6D17	DC voltage	0-999900	×0.01V	UINT32	R	
+48, 49	0x6D18	Frequency	0-10000	×0.01Hz	UINT32	R	
25792-25841		2-Hour RMS and Auxiliary Values					
+0, 1	0x6D80	V1 voltage	0-V _{max}	U1	UINT32	R	1
+2, 3	0x6D81	V2 voltage	0-V _{max}	U1	UINT32	R	1
+4, 5	0x6D82	V3 voltage	0-V _{max}	U1	UINT32	R	1
+6, 7	0x6D83	V4 voltage	0-V ₄ max	U4	UINT32	R	
+8, 9	0x6D84	V12 voltage	0-V _{max}	U1	UINT32	R	
+10, 11	0x6D85	V23 voltage	0-V _{max}	U1	UINT32	R	
+12, 13	0x6D86	V31 voltage	0-V _{max}	U1	UINT32	R	
+14, 15	0x6D87	I1 current	0-I _{max}	U2	UINT32	R	
+16, 17	0x6D88	I2 current	0-I _{max}	U2	UINT32	R	
+18, 19	0x6D89	I3 current	0-I _{max}	U2	UINT32	R	
+20, 21	0x6D8A	I4 current	0-I ₄ max	U2	UINT32	R	
+22, 23	0x6D8B	I _n current	0-I _{max}	U2	UINT32	R	
+24, 25	0x6D8C	I1 _x current	0-I _x max	U2	UINT32	R	
+26, 27	0x6D8D	I2 _x current	0-I _x max	U2	UINT32	R	
+28, 29	0x6D8E	I3 _x current	0-I _x max	U2	UINT32	R	
+30, 31	0x6D8F	I4 _x current	0-I ₄ xmax	U2	UINT32	R	
+32, 33	0x6D90	I _n x current	0-I _x max	U2	UINT32	R	
+34, 35	0x6D91	Zero-sequence voltage	0-V _{max}	U1	UINT32	R	
+36, 37	0x6D92	Zero-sequence current	0-I _{max}	U2	UINT32	R	
+38, 39	0x6D93	I _x Zero-sequence current	0-I _x max	U2	UINT32	R	
+40, 41	0x6D94	Voltage unbalance	0-3000	×0.1%	UINT32	R	
+42, 43	0x6D95	Current unbalance	0-3000	×0.1%	UINT32	R	
+44, 45	0x6D96	I _x current unbalance	0-3000	×0.1%	UINT32	R	
+46, 47	0x6D97	DC voltage	0-999900	×0.01V	UINT32	R	
+48, 49	0x6D98	Frequency	0-10000	×0.01Hz	UINT32	R	
25856-25905		0.2-Second Harmonics					
+0, 1	0x6E00	V1 THD	0-9999	×0.1%	UINT32	R	2
+2, 3	0x6E01	V2 THD	0-9999	×0.1%	UINT32	R	2
+4, 5	0x6E02	V3 THD	0-9999	×0.1%	UINT32	R	2
+6, 7	0x6E03	V4 THD	0-9999	×0.1%	UINT32	R	
+8, 9	0x6E04	I1 THD	0-9999	×0.1%	UINT32	R	
+10, 11	0x6E05	I2 THD	0-9999	×0.1%	UINT32	R	
+12, 13	0x6E06	I3 THD	0-9999	×0.1%	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+14, 15	0x6E07	I4 THD	0-9999	×0.1%	UINT32	R	
+16, 17	0x6E08	V1 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+18, 19	0x6E09	V2 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+20, 21	0x6E0A	V3 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+22, 23	0x6E0B	V4 interharmonics THD	0-9999	×0.1%	UINT32	R	
+24, 25	0x6E0C	I1 interharmonics THD	0-9999	×0.1%	UINT32	R	
+26, 27	0x6E0D	I2 interharmonics THD	0-9999	×0.1%	UINT32	R	
+28, 29	0x6E0E	I3 interharmonics THD	0-9999	×0.1%	UINT32	R	
+30, 31	0x6E0F	I4 interharmonics THD	0-9999	×0.1%	UINT32	R	
+32, 33	0x6E10	I1 TDD	0-1000	×0.1%	UINT32	R	
+34, 35	0x6E11	I2 TDD	0-1000	×0.1%	UINT32	R	
+36, 37	0x6E12	I3 TDD	0-1000	×0.1%	UINT32	R	
+38, 39	0x6E13	I4 TDD	0-1000	×0.1%	UINT32	R	
+40, 41	0x6E14	I1 K-Factor	10-9999	×0.1	UINT32	R	
+42, 43	0x6E15	I2 K-Factor	10-9999	×0.1	UINT32	R	
+44, 45	0x6E16	I3 K-Factor	10-9999	×0.1	UINT32	R	
+46, 47	0x6E17	I4 K-Factor	10-9999	×0.1	UINT32	R	
+48, 49	0x6E18	V1 Crest Factor	0-10000	×0.01	UINT32	R	2
+50, 51	0x6E19	V2 Crest Factor	0-10000	×0.01	UINT32	R	2
+52, 53	0x6E1A	V3 Crest Factor	0-10000	×0.01	UINT32	R	2
+54, 55	0x6E1B	V4 Crest Factor	0-10000	×0.01	UINT32	R	
+56, 57	0x6E1C	I1 Crest Factor	0-10000	×0.01	UINT32	R	
+58, 59	0x6E1D	I2 Crest Factor	0-10000	×0.01	UINT32	R	
+60, 61	0x6E1E	I3 Crest Factor	0-10000	×0.01	UINT32	R	
+62, 63	0x6E1F	I4 Crest Factor	0-10000	×0.01	UINT32	R	
25920-25969		3-Second Harmonics					
+0, 1	0x6E80	V1 THD	0-9999	×0.1%	UINT32	R	2
+2, 3	0x6E81	V2 THD	0-9999	×0.1%	UINT32	R	2
+4, 5	0x6E82	V3 THD	0-9999	×0.1%	UINT32	R	2
+6, 7	0x6E83	V4 THD	0-9999	×0.1%	UINT32	R	
+8, 9	0x6E84	I1 THD	0-9999	×0.1%	UINT32	R	
+10, 11	0x6E85	I2 THD	0-9999	×0.1%	UINT32	R	
+12, 13	0x6E86	I3 THD	0-9999	×0.1%	UINT32	R	
+14, 15	0x6E87	I4 THD	0-9999	×0.1%	UINT32	R	
+16, 17	0x6E88	V1 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+18, 19	0x6E89	V2 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+20, 21	0x6E8A	V3 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+22, 23	0x6E8B	V4 interharmonics THD	0-9999	×0.1%	UINT32	R	
+24, 25	0x6E6E	I1 interharmonics THD	0-9999	×0.1%	UINT32	R	
+26, 27	0x6E8D	I2 interharmonics THD	0-9999	×0.1%	UINT32	R	
+28, 29	0x6E8E	I3 interharmonics THD	0-9999	×0.1%	UINT32	R	
+30, 31	0x6E8F	I4 interharmonics THD	0-9999	×0.1%	UINT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+32, 33	0x6E90	I1 TDD	0-1000	×0.1%	UINT32	R	
+34, 35	0x6E91	I2 TDD	0-1000	×0.1%	UINT32	R	
+36, 37	0x6E92	I3 TDD	0-1000	×0.1%	UINT32	R	
+38, 39	0x6E93	I4 TDD	0-1000	×0.1%	UINT32	R	
+40, 41	0x6E94	I1 K-Factor	10-9999	×0.1	UINT32	R	
+42, 43	0x6E95	I2 K-Factor	10-9999	×0.1	UINT32	R	
+44, 45	0x6E96	I3 K-Factor	10-9999	×0.1	UINT32	R	
+46, 47	0x6E97	I4 K-Factor	10-9999	×0.1	UINT32	R	
+48, 49	0x6E98	V1 Crest Factor	0-10000	×0.01	UINT32	R	2
+50, 51	0x6E99	V2 Crest Factor	0-10000	×0.01	UINT32	R	2
+52, 53	0x6E9A	V3 Crest Factor	0-10000	×0.01	UINT32	R	2
+54, 55	0x6E9B	V4 Crest Factor	0-10000	×0.01	UINT32	R	
+56, 57	0x6E9C	I1 Crest Factor	0-10000	×0.01	UINT32	R	
+58, 59	0x6E9D	I2 Crest Factor	0-10000	×0.01	UINT32	R	
+60, 61	0x6E9E	I3 Crest Factor	0-10000	×0.01	UINT32	R	
+62, 63	0x6E9F	I4 Crest Factor	0-10000	×0.01	UINT32	R	
25984-26033		10-Minute Harmonics					
+0, 1	0x6F00	V1 THD	0-9999	×0.1%	UINT32	R	2
+2, 3	0x6F01	V2 THD	0-9999	×0.1%	UINT32	R	2
+4, 5	0x6F02	V3 THD	0-9999	×0.1%	UINT32	R	2
+6, 7	0x6F03	V4 THD	0-9999	×0.1%	UINT32	R	
+8, 9	0x6F04	I1 THD	0-9999	×0.1%	UINT32	R	
+10, 11	0x6F05	I2 THD	0-9999	×0.1%	UINT32	R	
+12, 13	0x6F06	I3 THD	0-9999	×0.1%	UINT32	R	
+14, 15	0x6F07	I4 THD	0-9999	×0.1%	UINT32	R	
+16, 17	0x6F08	V1 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+18, 19	0x6F09	V2 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+20, 21	0x6FOA	V3 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+22, 23	0x6FOB	V4 interharmonics THD	0-9999	×0.1%	UINT32	R	
+24, 25	0x6FOC	I1 interharmonics THD	0-9999	×0.1%	UINT32	R	
+26, 27	0x6FOD	I2 interharmonics THD	0-9999	×0.1%	UINT32	R	
+28, 29	0x6FOE	I3 interharmonics THD	0-9999	×0.1%	UINT32	R	
+30, 31	0x6FOF	I4 interharmonics THD	0-9999	×0.1%	UINT32	R	
+32, 33	0x6F10	I1 TDD	0-1000	×0.1%	UINT32	R	
+34, 35	0x6F11	I2 TDD	0-1000	×0.1%	UINT32	R	
+36, 37	0x6F12	I3 TDD	0-1000	×0.1%	UINT32	R	
+38, 39	0x6F13	I4 TDD	0-1000	×0.1%	UINT32	R	
+40, 41	0x6F14	I1 K-Factor	10-9999	×0.1	UINT32	R	
+42, 43	0x6F15	I2 K-Factor	10-9999	×0.1	UINT32	R	
+44, 45	0x6F16	I3 K-Factor	10-9999	×0.1	UINT32	R	
+46, 47	0x6F17	I4 K-Factor	10-9999	×0.1	UINT32	R	
+48, 49	0x6F18	V1 Crest Factor	0-10000	×0.01	UINT32	R	2

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+50, 51	0x6F19	V2 Crest Factor	0-10000	×0.01	UINT32	R	2
+52, 53	0x6F1A	V3 Crest Factor	0-10000	×0.01	UINT32	R	2
+54, 55	0x6F1B	V4 Crest Factor	0-10000	×0.01	UINT32	R	
+56, 57	0x6F1C	I1 Crest Factor	0-10000	×0.01	UINT32	R	
+58, 59	0x6F1D	I2 Crest Factor	0-10000	×0.01	UINT32	R	
+60, 61	0x6F1E	I3 Crest Factor	0-10000	×0.01	UINT32	R	
+62, 63	0x6F1F	I4 Crest Factor	0-10000	×0.01	UINT32	R	
26046-26097		2-Hour Harmonics					
+0, 1	0x6F80	V1 THD	0-9999	×0.1%	UINT32	R	2
+2, 3	0x6F81	V2 THD	0-9999	×0.1%	UINT32	R	2
+4, 5	0x6F82	V3 THD	0-9999	×0.1%	UINT32	R	2
+6, 7	0x6F83	V4 THD	0-9999	×0.1%	UINT32	R	
+8, 9	0x6F84	I1 THD	0-9999	×0.1%	UINT32	R	
+10, 11	0x6F85	I2 THD	0-9999	×0.1%	UINT32	R	
+12, 13	0x6F86	I3 THD	0-9999	×0.1%	UINT32	R	
+14, 15	0x6F87	I4 THD	0-9999	×0.1%	UINT32	R	
+16, 17	0x6F88	V1 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+18, 19	0x6F89	V2 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+20, 21	0x6F8A	V3 interharmonics THD	0-9999	×0.1%	UINT32	R	2
+22, 23	0x6F8B	V4 interharmonics THD	0-9999	×0.1%	UINT32	R	
+24, 25	0x6F8C	I1 interharmonics THD	0-9999	×0.1%	UINT32	R	
+26, 27	0x6F8D	I2 interharmonics THD	0-9999	×0.1%	UINT32	R	
+28, 29	0x6F8E	I3 interharmonics THD	0-9999	×0.1%	UINT32	R	
+30, 31	0x6F8F	I4 interharmonics THD	0-9999	×0.1%	UINT32	R	
+32, 33	0x6F90	I1 TDD	0-1000	×0.1%	UINT32	R	
+34, 35	0x6F91	I2 TDD	0-1000	×0.1%	UINT32	R	
+36, 37	0x6F92	I3 TDD	0-1000	×0.1%	UINT32	R	
+38, 39	0x6F93	I4 TDD	0-1000	×0.1%	UINT32	R	
+40, 41	0x6F94	I1 K-Factor	10-9999	×0.1	UINT32	R	
+42, 43	0x6F95	I2 K-Factor	10-9999	×0.1	UINT32	R	
+44, 45	0x6F96	I3 K-Factor	10-9999	×0.1	UINT32	R	
+46, 47	0x6F97	I4 K-Factor	10-9999	×0.1	UINT32	R	
+48, 49	0x6F98	V1 Crest Factor	0-10000	×0.01	UINT32	R	2
+50, 51	0x6F99	V2 Crest Factor	0-10000	×0.01	UINT32	R	2
+52, 53	0x6F9A	V3 Crest Factor	0-10000	×0.01	UINT32	R	2
+54, 55	0x6F9B	V4 Crest Factor	0-10000	×0.01	UINT32	R	
+56, 57	0x6F9C	I1 Crest Factor	0-10000	×0.01	UINT32	R	
+58, 59	0x6F9D	I2 Crest Factor	0-10000	×0.01	UINT32	R	
+60, 61	0x6F9E	I3 Crest Factor	0-10000	×0.01	UINT32	R	
+62, 63	0x6F9F	I4 Crest Factor	0-10000	×0.01	UINT32	R	
27136-27179		Present EN50160 PQ Values					
+0,1	0x7800	V1 Voltage variation, +/-%Un		0.01%	INT32	R	Last 10-min measurement

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
+2,3	0x7801	V2 Voltage variation, +/-%Un		0.01%	INT32	R	"
+4,5	0x7802	V3 Voltage variation, +/-%Un		0.01%	INT32	R	"
+6,7	0x7803	Positive sequence voltage variation, +/-%Un	0 (Not used)	0.01%	INT32	R	"
+8,9	0x7804	V1 Voltage change, %Un		0.01%	UINT32	R	Last 1-hour measurement
+10,11	0x7805	Repetition rate of V1 voltage changes, 1/min		1/min × 0.01	UINT32	R	"
+12,13	0x7806	V2 Voltage change, %Un		0.01%	UINT32	R	"
+14,15	0x7807	Repetition rate of V2 voltage changes, 1/min		1/min × 0.01	UINT32	R	"
+16,17	0x7808	V3 Voltage change, %Un		0.01%	UINT32	R	"
+18,19	0x7809	Repetition rate of V3 voltage changes, 1/min		1/min × 0.01	UINT32	R	"
+20,21	0x780A	V1 Voltage Pst		0.01	UINT32	R	Last 10-min measurement
+22,23	0x780B	V2 Voltage Pst		0.01	UINT32	R	"
+24,25	0x780C	V3 Voltage Pst		0.01	UINT32	R	"
+26,27	0x780D	V1 Voltage PIt		0.01	UINT32	R	Last 2-hour measurement
+28,29	0x780E	V2 Voltage PIt		0.01	UINT32	R	"
+30,31	0x780F	V3 Voltage PIt		0.01	UINT32	R	"
+32,33	0x7810	V1 Voltage THD, %		0.1%	UINT32	R	Last 10-min measurement
+34,35	0x7811	V2 Voltage THD, %		0.1%	UINT32	R	"
+36,37	0x7812	V3 Voltage THD, %		0.1%	UINT32	R	"
+38,39	0x7813	Negative-sequence voltage unbalance, %		0.1%	UINT32	R	"
+40,41	0x7814	Zero-sequence voltage unbalance, %	0 (Not used)	0.1%	UINT32	R	"
+42,43	0x7815	Frequency variation, +/-Hz		0.01 Hz	INT32	R	Last 10-s measurement
28160-28223		External Integer Measured Values					
+0,1	0x8000	ExtiVal1			INT32	R	
+2,3	0x8001	ExtiVal2			INT32	R	
...			INT32	R	
+62,63	0x801F	ExtiVal32			INT32	R	
28288-28321		External Float Measured Values					
+0,1	0x8100	ExtfVal1			FLOAT32	R	
+2,3	0x8101	ExtfVal2			FLOAT32	R	
...			FLOAT32	R	
+62,63	0x801F	ExtfVal32			FLOAT32	R	

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
		External Indication					
28416-28417		ExtInd1:32 Bit 0: ExtInd1 ... Bit 32: ExtInd32	0x00000000-0xFFFFFFFF Bit Value: 0=OFF, 1=ON		UINT32	R	Bitmap
28480-28481		ExtInd33:64 Bit 0: ExtInd33 ... Bit 32: ExtInd64	0x00000000-0xFFFFFFFF Bit Value: 0=OFF, 1=ON		UINT32	R	Bitmap
28544-28545		ExtInd65:96 Bit 0: ExtInd65 ... Bit 32: ExtInd96	0x00000000-0xFFFFFFFF Bit Value: 0=OFF, 1=ON		UINT32	R	Bitmap
28608-28609		ExtInd97:128 Bit 0: ExtInd97 ... Bit 32: ExtInd128	0x00000000-0xFFFFFFFF Bit Value: 0=OFF, 1=ON		UINT32	R	Bitmap
	0x8200	ExtInd1	0/1		UINT32	TRG	
	0x8201	ExtInd2	0/1		UINT32	TRG	
					
	0x827F	ExtInd128	0/1		UINT32	TRG	
		Switch Position Indication					
29440-29471	0x8A00	Switch position (Pos)	00=intermediate-state, 01=OFF, 10=ON, 11=bad-state		UINT32	R	
	+0,1 0x8A00	XCBR1_Pos	00/01/10/11			TRG	
	+2,3 0x8A01	XCBR2_Pos	00/01/10/11			TRG	
	+4,5 0x8A02	XSWI1_Pos	00/01/10/11			TRG	
					
	+30,31 0x8A0F	XSWI14_Pos	00/01/10/11			TRG	
		Switch Operation-Open Indication					
29568-29569	0x8B00	Operation Open activation status (OpOpn): Bit 0: XCBR1_OpOpn Bit 1: XCBR2_OpOpn Bit 2: XSWI1_OpOpn ... Bit 15: XSWI14_OpOpn	0x00000000 - 0x0000FFFF Bit value: 0=not active, 1=activated		UINT32	R	Bitmap
	0x8B00	XCBR1_OpOpn	0/1			TRG	
	0x8B01	XCBR2_OpOpn	0/1			TRG	
	0x8B02	XSWI1_OpOpn	0/1			TRG	
					
	0x8B0F	XSWI14_OpOpn	0/1			TRG	
		Switch Operation-Close Indication					
29632-29633	0x8B80	Operation Close activation status (OpCls):	0x00000000 - 0x0000FFFF		UINT32	R	Bitmap

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
		Bit 0: XCBR1_OpCls Bit 1: XCBR2_OpCls Bit 2: XSWI1_OpCls ... Bit 15: XSWI14_OpCls	Bit value: 0=not active, 1=activated				
	0x8B80	XCBR1_OpCls	0/1				TRG
	0x8B81	XCBR2_OpCls	0/1				TRG
	0x8B82	XSWI1_OpCls	0/1				TRG
		...					TRG
	0x8B8F	XSWI14_OpCls	0/1				
29696-29727		Switch Operation Counters (resettable)					
+0,1	0x8C00	XCBR1_OpCnt	0-9999		UINT32	R/W	
+2,3	0x8C01	XCBR2_OpCnt	0-9999		UINT32	R/W	
+4,5	0x8C02	XSWI1_OpCnt	0-9999		UINT32	R/W	
		...					
+30,31	0x8C0F	XSWI14_OpCnt	0-9999		UINT32	R/W	
		Generic TOU Energy Registers					Point references
	0x7000	Tariff #1 register	-999,999,999-999,999,999	1 kWh	UINT32		
	0x7001	Tariff #2 register	-999,999,999-999,999,999	1 kWh	UINT32		
		...					
	0x700F	Tariff #16 register	-999,999,999-999,999,999	1 kWh	UINT32		
		Generic TOU Maximum Demand Registers					Point references
	0x7100	Tariff #1 register	0-Pmax	U3	UINT32		
	0x7101	Tariff #2 register	0-Pmax	U3	UINT32		
		...					
	0x710F	Tariff #16 register	0-Pmax	U3	UINT32		
		Generic Data					Point references
	0x7400	V1 voltage	0-Vmax	U1	UINT32		1
	0x7401	V2 voltage	0-Vmax	U1	UINT32		1
	0x7402	V3 voltage	0-Vmax	U1	UINT32		1
	0x7403	V4 voltage	0-V4max	U4	UINT32		
	0x7404	V12 voltage	0-Vmax	U1	UINT32		
	0x7405	V23 voltage	0-Vmax	U1	UINT32		
	0x7406	V31 voltage	0-Vmax	U1	UINT32		
	0x7407	I1 current	0-Imax	U2	UINT32		
	0x7408	I2 current	0-Imax	U2	UINT32		
	0x7409	I3 current	0-Imax	U2	UINT32		
	0x740A	I4 current	0-I4max	U2	UINT32		
	0x740B	In current	0-Imax	U2	UINT32		
	0x740C	I1x current	0-Ixmax	U2	UINT32		
	0x740D	I2x current	0-Ixmax	U2	UINT32		
	0x740E	I3x current	0-Ixmax	U2	UINT32		

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
	0x740F	I4x current	0-I4xmax	U2	UINT32		
	0x7410	I1x current	0-Ixmax	U2	UINT32		
	0x7411	Zero-sequence voltage	0-Vmax	U1	UINT32		
	0x7412	Zero-sequence current	0-Imax	U2	UINT32		
	0x7413	Ix Zero-sequence current	0-Ixmax	U2	UINT32		
	0x7414	Voltage unbalance	0-3000	×0.1%	UINT32		
	0x7415	Current unbalance	0-3000	×0.1%	UINT32		
	0x7416	Ix current unbalance	0-3000	×0.1%	UINT32		
	0x7417	DC voltage	0-999900	×0.01V	UINT32		
	0x7418	Frequency	0-10000	×0.01Hz	UINT32		
	0x7419	V1 THD	0-9999	×0.1%	UINT32		2
	0x741A	V2 THD	0-9999	×0.1%	UINT32		2
	0x741B	V3 THD	0-9999	×0.1%	UINT32		2
	0x741C	V4 THD	0-9999	×0.1%	UINT32		
	0x741D	I1 THD	0-9999	×0.1%	UINT32		
	0x741E	I2 THD	0-9999	×0.1%	UINT32		
	0x741F	I3 THD	0-9999	×0.1%	UINT32		
	0x7420	I4 THD	0-9999	×0.1%	UINT32		
	0x7421	V1 interharmonics THD	0-9999	×0.1%	UINT32		2
	0x7422	V2 interharmonics THD	0-9999	×0.1%	UINT32		2
	0x7423	V3 interharmonics THD	0-9999	×0.1%	UINT32		2
	0x7424	V4 interharmonics THD	0-9999	×0.1%	UINT32		
	0x7425	I1 interharmonics THD	0-9999	×0.1%	UINT32		
	0x7426	I2 interharmonics THD	0-9999	×0.1%	UINT32		
	0x7427	I3 interharmonics THD	0-9999	×0.1%	UINT32		
	0x7428	I4 interharmonics THD	0-9999	×0.1%	UINT32		
	0x7429	I1 TDD	0-1000	×0.1%	UINT32		
	0x742A	I2 TDD	0-1000	×0.1%	UINT32		
	0x742B	I3 TDD	0-1000	×0.1%	UINT32		
	0x742C	I4 TDD	0-1000	×0.1%	UINT32		
	0x742D	I1 K-Factor	10-9999	×0.1	UINT32		
	0x742E	I2 K-Factor	10-9999	×0.1	UINT32		
	0x742F	I3 K-Factor	10-9999	×0.1	UINT32		
	0x7430	I4 K-Factor	10-9999	×0.1	UINT32		
	0x7431	V1 Crest Factor	0-10000	×0.01	UINT32		2
	0x7432	V2 Crest Factor	0-10000	×0.01	UINT32		2
	0x7433	V3 Crest Factor	0-10000	×0.01	UINT32		2
	0x7434	V4 Crest Factor	0-10000	×0.01	UINT32		
	0x7435	I1 Crest Factor	0-10000	×0.01	UINT32		
	0x7436	I2 Crest Factor	0-10000	×0.01	UINT32		
	0x7437	I3 Crest Factor	0-10000	×0.01	UINT32		
	0x7438	I4 Crest Factor	0-10000	×0.01	UINT32		

Address	Point ID	Description	Options/Range ³	Units ³	Type	R/W	Notes
	0x750F	V1 impulsive voltage	0-Vmax	U1	UINT32		
	0x7510	V2 impulsive voltage	0-Vmax	U1	UINT32		
	0x7511	V3 impulsive voltage	0-Vmax	U1	UINT32		
	0x7513	V12 impulsive voltage	0-Vmax	U1	UINT32		
	0x7514	V23 impulsive voltage	0-Vmax	U1	UINT32		
	0x7515	V31 impulsive voltage	0-Vmax	U1	UINT32		
	0x1900	V1 H01 Harmonic voltage, %Un	0-10000	×0.01%	UINT32		2
	0x1901	V1 H02 Harmonic voltage, %Un	0-10000	×0.01%	UINT32		2
		...					
	0x1931	V1 H50 Harmonic voltage, %Un	0-10000	×0.01%	UINT32		2
	0x1A00	V2 H01 Harmonic voltage, %Un	0-10000	×0.01%	UINT32		2
	0x1A01	V2 H02 Harmonic voltage, %Un	0-10000	×0.01%	UINT32		2
		...					
	0x1A31	V2 H50 Harmonic voltage, %Un	0-10000	×0.01%	UINT32		2
	0x1B00	V3 H01 Harmonic voltage, %Un	0-10000	×0.01%	UINT32		2
	0x1B01	V3 H02 Harmonic voltage, %Un	0-10000	×0.01%	UINT32		2
		...					
	0x1B31	V3 H50 Harmonic voltage, %Un	0-10000	×0.01%	UINT32		2
	0x2980	V1 Pst	0-10000	×0.01	UINT32		2
	0x2981	V2 Pst	0-10000	×0.01	UINT32		2
	0x2982	V3 Pst	0-10000	×0.01	UINT32		2
	0x2983	V1 Plt	0-10000	×0.01	UINT32		2
	0x2984	V2 Plt	0-10000	×0.01	UINT32		2
	0x2985	V3 Plt	0-10000	×0.01	UINT32		2
	0x6005	V1 Frq1 %Un, 1st signaling voltage magnitude V1	0-10000	×0.01%	UINT32		2
	0x6006	V1 Frq2 %Un, 2nd signaling voltage magnitude V1	0-10000	×0.01%	UINT32		2
	0x6007	V1 Frq3 %Un, 3rd signaling voltage magnitude V1	0-10000	×0.01%	UINT32		2
	0x6008	V1 Frq4 %Un, 4th signaling voltage magnitude V1	0-10000	×0.01%	UINT32		2
	0x600A	V2 Frq1 %Un, 1st signaling voltage magnitude V2	0-10000	×0.01%	UINT32		2
	0x600B	V2 Frq2 %Un, 2nd signaling voltage magnitude V2	0-10000	×0.01%	UINT32		2
	0x600C	V2 Frq3 %Un, 3rd signaling voltage magnitude V2	0-10000	×0.01%	UINT32		2
	0x600D	V2 Frq4 %Un, 4th signaling voltage magnitude V2	0-10000	×0.01%	UINT32		2
	0x600F	V3 Frq1 %Un, 1st signaling voltage magnitude V3	0-10000	×0.01%	UINT32		2
	0x6010	V3 Frq2 %Un, 2nd signaling voltage magnitude V3	0-10000	×0.01%	UINT32		2
	0x6011	V3 Frq3 %Un, 3rd signaling voltage magnitude V3	0-10000	×0.01%	UINT32		2
	0x6012	V3 Frq4 %Un, 4th signaling voltage magnitude V3	0-10000	×0.01%	UINT32		2

NOTES:

- ¹ When the 4LN3, 4LL3, 3LN3, 3LL3, 3BLN3 or 3BLL3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line.
- ² When the 4LN3, 3LN3 or 3BLN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

- 3 For volts, amps, power and frequency scales and units, refer to Section 4 "Data Scales and Units".
- 4 On a 0.2-s interval.
- 5 On a 3-s interval.
- 6 Digital input registers return the state of the level-sensitive digital inputs in a 32-bit packed format beginning from the nearest lower point number divisible by 32. For example, registers 12544-12545 and 12548-12549 report the same 32-bit value that contains the state of digital inputs DI1:DI32. Bits that reference non-existent points will contain zeros.
- 7 Pulse input registers contain the transition status of the edge sensitive digital inputs. A bit value is set to '1' if a pulse edge (either rising, falling, or any of them depending on the input polarity setting) has been detected on the input. Pulse inputs cannot be directly read but can be tested through the setpoints and/or linked to the pulse counters and Billing/TOU registers.

3.5 Minimum/Maximum Log Registers

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
35840-35983		Minimum Phase Values					
+0, 1 +2, 3	0x2C00	Min. V1 voltage Timestamp	0-Vmax F1	U1 sec	UINT32 UINT32	R R	1
+4, 5 +6, 7	0x2C01	Min. V2 voltage Timestamp	0-Vmax F1	U1 sec	UINT32 UINT32	R R	1
+8, 9 +10, 11	0x2C02	Min. V3 voltage Timestamp	0-Vmax F1	U1 sec	UINT32 UINT32	R R	1
+12, 13 +14, 15	0x2C03	Min. I1 current Timestamp	0-Imax F1	U2 sec	UINT32 UINT32	R R	
+16, 17 +18, 19	0x2C04	Min. I2 current Timestamp	0-Imax	U2 sec	UINT32 UINT32	R R	
+20, 21 +22, 23	0x2C05	Min. I3 current Timestamp	0-Imax	U2 sec	UINT32 UINT32	R R	
+24, 25 +26, 27	0x2C06	Min. kW L1 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+28, 29 +30, 31	0x2C07	Min. kW L2 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+32, 33 +34, 35	0x2C08	Min. kW L3 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+36, 37 +38, 39	0x2C09	Min. kvar L1 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+40, 41 +42, 43	0x2C0A	Min. kvar L2 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+44, 45 +46, 47	0x2C0B	Min. kvar L3 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+48, 49 +50, 51	0x2C0C	Min. kVA L1 Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+52, 53 +54, 55	0x2C0D	Min. kVA L2 Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+56, 57 +58, 59	0x2C0E	Min. kVA L3 Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+60, 61 +62, 63	0x2C0F	Min. Power factor L1 Timestamp	0-1000	×0.001 sec	UINT32 UINT32	R R	Absolute value
+64, 65 +66, 67	0x2C10	Min. Power factor L2 Timestamp	0-1000	×0.001 sec	UINT32 UINT32	R R	Absolute value
+68, 69 +70, 71	0x2C11	Min. Power factor L3 Timestamp	0-1000	×0.001 sec	UINT32 UINT32	R R	Absolute value
+72, 73 +74, 75	0x2C12	Min. V1 voltage THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	2, 4
+76, 77	0x2C13	Min. V2 voltage THD	0-9999	×0.1%	UINT32	R	2, 4

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
+78, 79		Timestamp		sec	UINT32	R	
+80, 81	0x2C14	Min. V3 voltage THD	0-9999	×0.1%	UINT32	R	2, 4
+82, 83		Timestamp		sec	UINT32	R	
+84, 85	0x2C15	Min. I1 current THD	0-9999	×0.1%	UINT32	R	4
+86, 87		Timestamp		sec	UINT32	R	
+88, 89	0x2C16	Min. I2 current THD	0-9999	×0.1%	UINT32	R	4
+90, 91		Timestamp		sec	UINT32	R	
+92, 93	0x2C17	Min. I3 current THD	0-9999	×0.1%	UINT32	R	4
+94, 95		Timestamp		sec	UINT32	R	
+96, 97	0x2C18	Min. I1 K-Factor	10-9999	×0.1	UINT32	R	4
+98, 99		Timestamp		sec	UINT32	R	
+100, 101	0x2C19	Min. I2 K-Factor	10-9999	×0.1	UINT32	R	4
+102, 103		Timestamp		sec	UINT32	R	
+104, 105	0x2C1A	Min. I3 K-Factor	10-9999	×0.1	UINT32	R	4
+106, 107		Timestamp		sec	UINT32	R	
+108, 109	0x2C1B	Min. I1 current TDD	0-1000	×0.1%	UINT32	R	4
+110, 111		Timestamp		sec	UINT32	R	
+112, 113	0x2C1C	Min. I2 current TDD	0-1000	×0.1%	UINT32	R	4
+114, 115		Timestamp		sec	UINT32	R	
+116, 117	0x2C1D	Min. I3 current TDD	0-1000	×0.1%	UINT32	R	4
+118, 119		Timestamp		sec	UINT32	R	
+120, 121	0x2C1E	Min. V12 voltage	0-Vmax	U1	UINT32	R	
+122, 123		Timestamp		sec	UINT32	R	
+124, 125	0x2C1F	Min. V23 voltage	0-Vmax	U1	UINT32	R	
+126, 127		Timestamp		sec	UINT32	R	
+128, 129	0x2C20	Min. V31 voltage	0-Vmax	U1	UINT32	R	
+130, 131		Timestamp		sec	UINT32	R	
+132, 133	0x2C21	Min. I1x current	0-Ixmax	U2	UINT32	R	
+134, 135		Timestamp		sec	UINT32	R	
+136, 137	0x2C22	Min. I2x current	0-Ixmax	U2	UINT32	R	
+138, 139		Timestamp		sec	UINT32	R	
+140, 141	0x2C23	Min. I3x current	0-Ixmax	U2	UINT32	R	
+142, 143		Timestamp		sec	UINT32	R	
36096-36119		Minimum Total Values					
+0, 1	0x2D00	Min. Total kW	-Pmax-Pmax	U3	INT32	R	
+2, 3		Timestamp		sec	UINT32	R	
+4, 5	0x2D01	Min. Total kvar	-Pmax-Pmax	U3	INT32	R	
+6, 7		Timestamp		sec	UINT32	R	
+8, 9	0x2D02	Min. Total kVA	0-Pmax	U3	UINT32	R	
+10, 11		Timestamp		sec	UINT32	R	
+12, 13	0x2D03	Min. Total PF	-1000-1000	×0.001	INT32	R	
+14, 15		Timestamp		sec	UINT32	R	
+16, 17	0x2D04	Min. Total PF lag	0-1000	×0.001	UINT32	R	
+18, 19		Timestamp		sec	UINT32	R	

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
+20, 21 +22, 23	0x2D05	Min. Total PF lead Timestamp	0-1000	×0.001 sec	UINT32 UINT32	R R	
36224-36287		Minimum Analog Inputs					
+0, 1 +2, 3	0x2E80	Min. analog input AI1 Timestamp	AI1min-AI1max		INT32 UINT32	R R	
+4, 5 +6, 7	0x2E81	Min. analog input AI2 Timestamp	AI2min-AI2max		INT32 UINT32	R R	
		...					
+60, 61 +62, 63	0x2E8F	Min. analog input AI16 Timestamp	AI16min-AI16max		INT32 UINT32	R R	
36352-36395		Minimum Auxiliary Values					
+0, 1 +2, 3	0x2E00	Min. I4 current Timestamp	0-I _{max}	U2 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x2E01	Min. I _n current Timestamp	0-I _{max}	U2 sec	UINT32 UINT32	R R	
+8, 9 +10, 11	0x2E02	Min. Frequency Timestamp	0-10000	×0.01Hz sec	UINT32 UINT32	R R	
+12, 13 +14, 15	0x2E03	Min. Voltage unbalance Timestamp	0-3000	×0.1% sec	UINT32 UINT32	R R	
+16, 17 +18, 19	0x2E04	Min. Current unbalance Timestamp	0-3000	×0.1% sec	UINT32 UINT32	R R	
+20, 21 +22, 23	0x2E05	Min. DC voltage Timestamp	0-999900	×0.01V sec	UINT32 UINT32	R R	
+24, 25 +26, 27	0x2E06	Min. V4 voltage Timestamp	0-V4 _{max}	U4 sec	UINT32 UINT32	R R	
+28, 29 +30, 31	0x2E07	Min. I4x current Timestamp	0-I _{xmax}	U2 sec	UINT32 UINT32	R R	
+32, 33 +34, 35	0x2E08	Min. V4 THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	⁴
+36, 37 +38, 39	0x2E09	Min. I4x THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	⁴
+40, 41 +42, 43	0x2E0A	Min. I4x TDD Timestamp	0-1000	×0.1% sec	UINT32 UINT32	R R	⁴
36608-36671		Programmable Min/Max Minimum Values					
+0, 1 +2, 3	0x3000	Min. Min/Max Register #1 Timestamp			UINT32 UINT32	R R	
+4, 5 +6, 7	0x3001	Min. Min/Max Register #2 Timestamp			UINT32 UINT32	R R	
		...					
+60, 61 +62, 63	0x300F	Min. Min/Max Register #16 Timestamp			UINT32 UINT32	R R	
36736-36799		Maximum Analog Inputs					
+0, 1 +2, 3	0x3680	Max. analog input AI1 Timestamp	AI1min-AI1max		INT32 UINT32	R R	

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
+4, 5 +6, 7	0x3681	Max. analog input AI2 Timestamp	AI2min-AI2max		INT32 UINT32	R R	
		...					
+60, 61 +62, 63	0x368F	Max. analog input AI16 Timestamp	AI16min-AI16max		INT32 UINT32	R R	
36864-37007		Maximum Phase Values					
+0, 1 +2, 3	0x3400	Max. V1 voltage Timestamp	0-Vmax	U1 sec	UINT32 UINT32	R R	1
+4, 5 +6, 7	0x3401	Max. V2 voltage Timestamp	0-Vmax	U1 sec	UINT32 UINT32	R R	1
+8, 9 +10, 11	0x3402	Max. V3 voltage Timestamp	0-Vmax	U1 sec	UINT32 UINT32	R R	1
+12, 13 +14, 15	0x3403	Max. I1 current Timestamp	0-Imax	U2 sec	UINT32 UINT32	R R	
+16, 17 +18, 19	0x3404	Max. I2 current Timestamp	0-Imax	U2 sec	UINT32 UINT32	R R	
+20, 21 +22, 23	0x3405	Max. I3 current Timestamp	0-Imax	U2 sec	UINT32 UINT32	R R	
+24, 25 +26, 27	0x3406	Max. kW L1 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+28, 29 +30, 31	0x3407	Max. kW L2 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+32, 33 +34, 35	0x3408	Max. kW L3 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+36, 37 +38, 39	0x3409	Max. kvar L1 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+40, 41 +42, 43	0x340A	Max. kvar L2 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+44, 45 +46, 47	0x340B	Max. kvar L3 Timestamp	-Pmax-Pmax	U3 sec	INT32 INT32	R R	
+48, 49 +50, 51	0x340C	Max. kVA L1 Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+52, 53 +54, 55	0x340D	Max. kVA L2 Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+56, 57 +58, 59	0x340E	Max. kVA L3 Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+60, 61 +62, 63	0x340F	Max. Power factor L1 Timestamp	0-1000	×0.001 sec	UINT32 UINT32	R R	Absolute value
+64, 65 +66, 67	0x3410	Max. Power factor L2 Timestamp	0-1000	×0.001 sec	UINT32 UINT32	R R	Absolute value
+68, 69 +70, 71	0x3411	Max. Power factor L3 Timestamp	0-1000	×0.001 sec	UINT32 UINT32	R R	Absolute value
+72, 73 +74, 75	0x3412	Max. V1 voltage THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	2, 4

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
+76, 77 +78, 79	0x3413	Max. V2 voltage THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	2, 4
+80, 81 +82, 83	0x3414	Max. V3 voltage THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	2, 4
+84, 85 +86, 87	0x3415	Max. I1 current THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	4
+88, 89 +90, 91	0x3416	Max. I2 current THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	4
+92, 93 +94, 95	0x3417	Max. I3 current THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	4
+96, 97 +98, 99	0x3418	Max. I1 K-Factor Timestamp	10-9999	×0.1 sec	UINT32 UINT32	R R	4
+100, 101 +102, 103	0x3419	Max. I2 K-Factor Timestamp	10-9999	×0.1 sec	UINT32 UINT32	R R	4
+104, 105 +106, 107	0x341A	Max. I3 K-Factor Timestamp	10-9999	×0.1 sec	UINT32 UINT32	R R	4
+108, 109 +110, 111	0x341B	Max. I1 current TDD Timestamp	0-1000	×0.1% sec	UINT32 UINT32	R R	4
+112, 113 +114, 115	0x341C	Max. I2 current TDD Timestamp	0-1000	×0.1% sec	UINT32 UINT32	R R	4
+116, 117 +118, 119	0x341D	Max. I3 current TDD Timestamp	0-1000	×0.1% sec	UINT32 UINT32	R R	4
+120, 121 +122, 123	0x341E	Max. V12 voltage Timestamp	0-Vmax	U1 sec	UINT32 UINT32	R R	
+124, 125 +126, 127	0x341F	Max. V23 voltage Timestamp	0-Vmax	U1 sec	UINT32 UINT32	R R	
+128, 129 +130, 131	0x3420	Max. V31 voltage Timestamp	0-Vmax	U1 sec	UINT32 UINT32	R R	
+132, 133 +134, 135	0x3421	Max. I1x current Timestamp	0-Ixmax	U2 sec	UINT32 UINT32	R R	
+136, 137 +138, 139	0x3422	Max. I2x current Timestamp	0-Ixmax	U2 sec	UINT32 UINT32	R R	
+140, 141 +142, 143	0x3423	Max. I3x current Timestamp	0-Ixmax	U2 sec	UINT32 UINT32	R R	
37120-37143		Maximum Total Values					
+0, 1 +2, 3	0x3500	Max. Total kW Timestamp	-Pmax-Pmax	U3 sec	INT32 UINT32	R R	
+4, 5 +6, 7	0x3501	Max. Total kvar Timestamp	-Pmax-Pmax	U3 sec	INT32 UINT32	R R	
+8, 9 +10, 11	0x3502	Max. Total kVA Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+12, 13 +14, 15	0x3503	Max. Total PF Timestamp	-1000-1000	×0.001 sec	INT32 UINT32	R R	
+16, 17	0x3504	Max. Total PF lag	0-1000	×0.001	UINT32	R	

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
+18, 19		Timestamp		sec	UINT32	R	
+20, 21 +22, 23	0x3505	Max. Total PF lead Timestamp	0-1000	×0.001 sec	UINT32 UINT32	R R	
37248-37375		Maximum Analog Input Demands					
+0, 1 +2, 3	0x3900	Max. analog input demand AI1+ Timestamp	AI1min-AI1max		UINT32 UINT32	R R	Positive AI readings demand
+4, 5 +6, 7	0x3901	Max. analog input demand AI2+ Timestamp	AI2min-AI2max		UINT32 UINT32	R R	
		...					
+60, 61 +62, 63	0x390F	Max. analog input demand AI16+ Timestamp	AI16min-AI16max		UINT32 UINT32	R R	
+64, 65 +66, 67	0x3910	Max. analog input demand AI1- Timestamp	AI1min-AI1max		UINT32 UINT32	R R	Negative AI readings demand
+68, 69 +70, 71	0x3911	Max. analog input demand AI2- Timestamp	AI2min-AI2max		UINT32 UINT32	R R	
		...					
+124, 125 +126, 127	0x391F	Max. analog input demand AI16- Timestamp	AI16min-AI16max		UINT32 UINT32	R R	
37376-37419		Maximum Auxiliary Values					
+0, 1 +2, 3	0x3600	Max. I4 current Timestamp	0-I _{max}	U2 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x3601	Max. In current Timestamp	0-I _{max}	U2 sec	UINT32 UINT32	R R	
+8, 9 +10, 11	0x3602	Max. Frequency Timestamp	0-10000	×0.01Hz sec	UINT32 UINT32	R R	
+12, 13 +14, 15	0x3603	Max. Voltage unbalance Timestamp	0-3000	×0.1% sec	UINT32 UINT32	R R	
+16, 17 +18, 19	0x3604	Max. Current unbalance Timestamp	0-3000	×0.1% sec	UINT32 UINT32	R R	
+20, 21 +22, 23	0x3605	Max. DC voltage Timestamp	0-999900	×0.01V sec	UINT32 UINT32	R R	
+24, 25 +26, 27	0x3606	Max. V4 voltage Timestamp	0-V4max	U4 sec	UINT32 UINT32	R R	
+28, 29 +30, 31	0x3607	Max. I4x current Timestamp	0-I _{xmax}	U2 sec	UINT32 UINT32	R R	
+32, 33 +34, 35	0x3608	Max. V4 THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	4
+36, 37 +38, 39	0x3609	Max. I4x THD Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	4
+40, 41 +42, 43	0x360A	Max. I4x TDD Timestamp	0-1000	×0.1% sec	UINT32 UINT32	R R	4
37504-37567		Billing Summary Maximum Demands					
+0, 1 +2, 3	0x4780	Summary register #1 Maximum Demand Timestamp	0-P _{max}	U3	UINT32	R	

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
+4, 5 +6, 7	0x4781	Summary register #2 Maximum Demand Timestamp	0-Pmax	U3	UINT32	R	
		...					
+60, 61 +62, 63	0x4783	Summary register #16 Maximum Demand Timestamp	0-Pmax	U3	UINT32	R	
37632-37719		Maximum Demands					
+0, 1 +2, 3	0x3700	V1 Maximum volt demand Timestamp	0-Vmax	U1 sec	UINT32 UINT32	R R	²
+4, 5 +6, 7	0x3701	V2 Maximum volt demand Timestamp	0-Vmax	U1 sec	UINT32 UINT32	R R	²
+8, 9 +10, 11	0x3702	V3 Maximum volt demand Timestamp	0-Vmax	U1 sec	UINT32 UINT32	R R	²
+12, 13 +14, 15	0x3703	I1 Maximum ampere demand Timestamp	0-Imax	U2 sec	UINT32 UINT32	R R	
+16, 17 +18, 19	0x3704	I2 Maximum ampere demand Timestamp	0-Imax	U2 sec	UINT32 UINT32	R R	
+20, 21 +22, 23	0x3705	I3 Maximum ampere demand Timestamp	0-Imax	U2 sec	UINT32 UINT32	R R	
+24, 25 +26, 27	0x3706	Not used Timestamp	0		UINT32 UINT32	R R	
+28, 29 +30, 31	0x3707	Not used Timestamp	0		UINT32 UINT32	R R	
+32, 33 +34, 35	0x3708	Not used Timestamp	0		UINT32 UINT32	R R	
+36, 37 +38, 39	0x3709	Maximum kW import sliding window demand Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+40, 41 +42, 43	0x370A	Maximum kvar import sliding window demand Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+44, 45 +46, 47	0x370B	Maximum kVA sliding window demand Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+48, 49 +50, 51	0x3737	Not used Timestamp	0		UINT32 UINT32	R R	
+52, 53 +54, 55	0x370D	Not used Timestamp	0		UINT32 UINT32	R R	
+56, 57 +58, 59	0x370E	Not used Timestamp	0		UINT32 UINT32	R R	
+60, 61 +62, 63	0x370F	Maximum kW export sliding window demand Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+64, 65 +66, 67	0x3710	Maximum kvar export sliding window demand Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+68, 69 +70, 71	0x3737	Not used Timestamp	0		UINT32 UINT32	R R	
+72, 73 +74, 75	0x3712	Not used Timestamp	0		UINT32 UINT32	R R	

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
+76, 77 +78, 79	0x3713	V4 Maximum volt demand Timestamp	0-Vmax	U4 sec	UINT32 UINT32	R R	
+80, 81 +82, 83	0x3714	I4 Maximum ampere demand Timestamp	0-I4max	U2 sec	UINT32 UINT32	R R	
+84, 85 +86, 87	0x3715	In Maximum ampere demand Timestamp	0-Imax	U2 sec	UINT32 UINT32	R R	
37888-37951		Programmable Min/Max Maximum Values					
+0, 1 +2, 3	0x3800	Max. Min/Max Register #1 Timestamp			UINT32 UINT32	R R	
+4, 5 +6, 7	0x3801	Max. Min/Max Register #2 Timestamp			UINT32 UINT32	R R	
		...					
+60, 61 +62, 63	0x380F	Max. Min/Max Register #16 Timestamp			UINT32 UINT32	R R	
38016-38063		Maximum Harmonic Demands					
+0, 1 +2, 3	0x3880	V1 THD demand Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	²
+4, 5 +6, 7	0x3881	V2 THD demand Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	²
+8, 9 +10, 11	0x3882	V3 THD demand Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	²
+12, 13 +14, 15	0x3883	V4 THD demand Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	
+16, 17 +18, 19	0x3884	I1 THD demand Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	
+20, 21 +22, 23	0x3885	I2 THD demand Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	
+24, 25 +26, 27	0x3886	I3 THD demand Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	
+28, 29 +30, 31	0x3887	I4 THD demand Timestamp	0-9999	×0.1% sec	UINT32 UINT32	R R	
+32, 33 +34, 35	0x3888	I1 TDD demand Timestamp	0-1000	×0.1% sec	UINT32 UINT32	R R	
+36, 37 +38, 39	0x3889	I2 TDD demand Timestamp	0-1000	×0.1% sec	UINT32 UINT32	R R	
+40, 41 +42, 43	0x388A	I3 TDD demand Timestamp	0-1000	×0.1% sec	UINT32 UINT32	R R	
+44, 45 +46, 47	0x388B	I4 TDD demand Timestamp	0-1000	×0.1% sec	UINT32 UINT32	R R	
38144-38207		Billing TOU Maximum Demand Register #1					
+0, 1 +2, 3	0x4800	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x4801	Tariff #2 register	0-Pmax	U3 sec	UINT32 UINT32	R R	

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
		Timestamp					
		...				R	
+60, 61 +62, 63	0x480F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
38272-38335		Billing TOU Maximum Demand Register #4					
+0, 1 +2, 3	0x4880	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x4881	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x488F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
38400-38463		Billing TOU Maximum Demand Register #2					
+0, 1 +2, 3	0x4900	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x4901	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x490F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
38528-38591		Billing TOU Maximum Demand Register #5					
+0, 1 +2, 3	0x4980	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x4981	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x498F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
38656-38719		Billing TOU Maximum Demand Register #3					
+0, 1 +2, 3	0x4A00	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x4A01	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x4A0F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
38784-38847		Billing TOU Maximum Demand Register #6					
+0, 1 +2, 3	0x4A80	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x4A81	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
+60, 61 +62, 63	0x4A8F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
38912-38975		Billing TOU Maximum Demand Register #7					
+0, 1 +2, 3	0x5300	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x5301	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x530F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
39040-39103		Billing TOU Maximum Demand Register #8					
+0, 1 +2, 3	0x5380	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x5381	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x538F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
39168-39231		Billing TOU Maximum Demand Register #9					
+0, 1 +2, 3	0x5400	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x5401	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x540F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
39296-39359		Billing TOU Maximum Demand Register #10					
+0, 1 +2, 3	0x5480	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x5481	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x548F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
39424-39487		Billing TOU Maximum Demand Register #11					
+0, 1 +2, 3	0x5500	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x5501	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x550F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	

Address	Point ID	Description	Options/Range/Format ³	Units ³	Type	R/W	Notes
39552-39615		Billing TOU Maximum Demand Register #12					
+0, 1 +2, 3	0x5580	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x5581	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x558F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
39680-39743		Billing TOU Maximum Demand Register #13					
+0, 1 +2, 3	0x5600	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x5601	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x560F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
39808-39871		Billing TOU Maximum Demand Register #14					
+0, 1 +2, 3	0x5680	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x5681	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x568F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
39936-39999		Billing TOU Maximum Demand Register #15					
+0, 1 +2, 3	0x5700	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x5701	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x570F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
40064-40127		Billing TOU Maximum Demand Register #16					
+0, 1 +2, 3	0x5780	Tariff #1 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
+4, 5 +6, 7	0x5781	Tariff #2 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	
		...				R	
+60, 61 +62, 63	0x578F	Tariff #16 register Timestamp	0-Pmax	U3 sec	UINT32 UINT32	R R	

NOTES:

- ¹ When the 4LN3, 4LL3, 3LN3, 3LL3, 3BLN3 or 3BLL3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line.
- ² When the 4LN3, 3LN3 or 3BLN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.
- ³ For volts, amps, power and frequency scales and units, refer to Section 4 "Data Scales and Units".
- ⁴ On a 0.2-s interval.

3.6 Device Control and Status Registers

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
Event Flags Registers (bitmap)							
44032-44033		Event flags 1-32 set register (0 = no effect, 1 = set)	0x00000000 - 0xFFFFFFFF		UINT32	W	Read as 0
44034-44035		Event flags 1-32 clear register (0=clear,1 = no effect)	0x00000000 - 0xFFFFFFFF		UINT32	W	Read as 0
44036-44037		Event flags 1-32 status (0 = cleared, 1 = set)	0x00000000 - 0xFFFFFFFF		UINT32	R	
44238-44241		Event flags 1-64 set register (0 = no effect, 1 = set)	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	W	Read as 0
44242-44245		Reserved			UINT32		Read as 0
44246-44249		Event flags 1-64 clear register (0=clear, 1 = no effect)	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	W	Read as 0
44250-44253		Reserved			UINT32		Read as 0
44254-44257		Event flags 1-64 status (0 = cleared, 1 = set)	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	
44258-44261		Reserved			UINT32		Read as 0
Remote Relay Control Registers (bitmap)							
44038-44045		Reserved			UINT32		
44046-44049		Force relay operate register: 0 = no effect, 1 = operate	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	W	Read as 0
44050-44053		Force relay release register: 0 = no effect, 1 = release	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	W	Read as 0
44054-44057		Locally latched relays status: 0 = unlatched, 1 = locally latched	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	
44058-44061		Remote latched relays status: 0 = unlatched, 1 = remote latched	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	
44062-44065		Direct relay control disable status: 0 = direct control enabled, 1 = direct control disabled	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	Direct relay control is disabled if a relay is under local automation control
44066-44069		Relay status: 0 = open, 1 = closed	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	
44070-44073		Latch relays mode: 0 = unlatched mode, 1 = latched mode	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	
44074-44077		Pulse relays mode: 0 = not pulse mode, 1 = pulse mode	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT32	R	
44078-44081		KYZ relays mode: 0 = not KYZ mode, 1 = KYZ mode	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	
44082-44085		Relay polarity mode: 0 = normal mode, 1 = inverting mode	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	
44086-44089		Relay blocking mode: 0 = normal mode, 1 = blocked mode	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	
44090-44093		Blocked relay status: 0 = relay unblocked, 1 = relay blocked	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	Relay control commands are ignored if a relay is blocked

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
44094-44101		Reserved			UINT32		
Reset/Clear Registers							
44102		Clear energies	0		UINT16	W	
44103		Clear maximum demands	0 = clear all maximum demands 1 = clear power demands 2 = clear volt and ampere demands 3 = clear volt demands 4 = clear ampere demands 5 = clear harmonic demands		UINT16	W	
44104		Clear Billing/TOU energy registers	0		UINT16	W	
44105		Clear Billing/TOU maximum demands	0		UINT16	W	
44106		Clear counters	0 = clear all counters, 1-32 = clear counter #1-#32		UINT16	W	
44107		Clear Min/Max log	0		UINT16	W	
44108		Clear operation/event counters	0 = clear EN50160 statistics 6 = clear communication counters 7 = clear switch operation counters		UINT16	W	
44109-44133		Reserved			UINT16		
Device Mode Control Registers							
44134		Energy test mode	0 = disabled, 1 = enabled		UINT16		
44135		Controller/setpoints operation	0 = disabled, 1 = enabled		UINT16		
44136		PQ recorder	0 = disabled, 1 = enabled		UINT16		
44137		Fault recorder	0 = disabled, 1 = enabled		UINT16		
44138-44165		Reserved			UINT16		
UDP Cross-trigger Register							
44166		External trigger index	0-15		UINT16	W	
44167		Reserved			UINT16		
44168-44237		Reserved			UINT16		
Memory Status Registers							
44262-44263		Memory size, bytes			UINT32	R	
44264-44265		Free memory, bytes			UINT32	R	
44266-44277		Reserved			UINT32	R	
Log Notification Registers (bitmap)							
44278-44279		Files 0-31 (0 = no new logs, 1 = new record logged)	0x00000000 - 0xFFFFFFFF		UINT32	R	
44280-44293		Reserved			UINT32	R	
Setpoint Status Registers (bitmap)							
44294-44297		Setpoints 1-64 status (0 = released, 1 = operated)	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R	
44298-44309		Reserved			UINT32	R	
Setpoint Alarm Latch Registers (bitmap)							
44310-44313		Setpoints 1-64 alarm status. When read: 0 = no setpoint operations logged, 1 = setpoint has been operated at least once since the last alarm bit reset. When written: 0 = clear setpoint	0x00000000 - 0xFFFFFFFF 0x00000000 - 0xFFFFFFFF		UINT64	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
44314-44325		alarm bit, 1 = no effect. Reserved					
Device Diagnostics Register (bitmap)							
44326-44327		Device self-diagnostics flags. When read: 0 = no faults logged, 1 = a fault bit has been set at least once since the last reset. When written: 0 = clear a fault bit, 1 = no effect.	F23		UINT32	R/W	
44328-44339		Reserved					
GOOSE Subscriber Status Register (bitmap)							
44340-44341		Bits 0-19 = subscriber #1-#20 status: 0 = subscriber does not receive updates or the data set differs from the subscriber setup; 1 = subscriber receives updates.	0x00000000 - 0x000FFFFF		UINT32	R	Bitmap
Port Identification							
44342		Active port number	0-2 = serial port COM1-COM3, 3 = IR Port, 4 = Modem port, 5 = USB/Modbus port, 6-10 = Ethernet/TCP port		UINT16	R	
44343-44345		Reserved					
Current Network Settings							
44346-44377							
+0, 1		Active device IP Address			UINT32	R	Network byte order
+2, 3		Active network subnet mask			UINT32	R	Network byte order
+4, 5		Active network default gateway			UINT32	R	Network byte order
44352-44377		Reserved					
Device Authorization Register							
44378-44379		When write: 8-digit password. When read: 0 = access permitted, -1 = authorization required.	0 - 99999999 (write) 0/-1 (read)		INT32	R/W	
44380-44385		Reserved					
Communication Counters							
44410		Successful eXpertPower client connections	0-65534		UINT16	R	
44411		Failed eXpertPower client connections	0-65534		UINT16	R	
44412		Successful TCP notification client connections	0-65534		UINT16	R	
44413		Failed TCP notification client connections	0-65534		UINT16	R	
44414-44441		Reserved			UINT16	R	65535 = N/A
Switch Remote Control Registers							
44458-44459		ON/Close command register: Bit 0: XCBR1 Bit 1: XCBR2 Bit 2: XSWI1 ... Bit 15: XSWI14	0x00000000 - 0x0000FFFF Bit value: 0=no effect, 1=ON		UINT32	W	Read as 0
44460-44461		OFF/Open command register: Bit 0: XCBR1	0x00000000 - 0x0000FFFF: Bit value: 0=no effect, 1=OFF		UINT32	W	Read as 0

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
		Bit 1: XCBR2 Bit 2: XSWI1 ... Bit 15: XSWI14					
44462-44463		Position substitution enable command register (subEna): Bit 0: XCBR1 Bit 1: XCBR2 Bit 2: XSWI1 ... Bit 15: XSWI14	0x00000000 - 0x0000FFFF Bit value: 0=no effect, 1=enable		UINT32	W	Read as 0
44464-44465		Position substitution disable command register (~subEna): Bit 0: XCBR1 Bit 1: XCBR2 Bit 2: XSWI1 ... Bit 15: XSWI14	0x00000000 - 0x0000FFFF Bit value: 0=no effect, 1=disable		UINT32	W	Read as 0
44466-44481		Position substitution value registers (subVal)	00=intermediate-state, 01=OFF, 10=ON, 11=bad-state				
+0		XCBR1 position substitution value			UINT16	R/W	
+1		XCBR2 position substitution value			UINT16	R/W	
+2		XSWI1 position substitution value			UINT16	R/W	
...		...					
+15		XSWI14 position substitution value			UINT16	R/W	
+16-47		Reserved					
Switch Status Registers							
44514-44515		Operation Open activation indication (alias): Bit 0: XCBR1_OpOpn Bit 1: XCBR2_OpOpn Bit 2: XSWI1_OpOpn ... Bit 15: XSWI14_OpOpn	0x00000000 - 0x0000FFFF Bit value: 0=not active, 1=activated		UINT32	R	
44516-44517		Operation Close activation indication (alias): Bit 0: XCBR1_OpCls Bit 1: XCBR2_OpCls Bit 2: XSWI1_OpCls ... Bit 15: XSWI14_OpCls	0x00000000 - 0x0000FFFF Bit value: 0=not active, 1=activated		UINT32	R	
44518-44519		Enable Opening status (EnaOpn): Bit 0: XCBR1 Bit 1: XCBR2 Bit 2: XSWI1 ... Bit 15: XSWI14	0x00000000 - 0x0000FFFF Bit value: 0=disabled/blocked, 1=enabled/unblocked		UINT32	R	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
44520-44521		Enable Closing status (EnaCls): Bit 0: XCBR1 Bit 1: XCBR2 Bit 2: XSWI1 ... Bit 15: XSWI14	0x00000000 - 0x0000FFFF Bit value: 0=disabled/blocked, 1=enabled/unblocked		UINT32	R	
44522-44523		Position substitution enable status (subEna): Bit 0: XCBR1 Bit 1: XCBR2 Bit 2: XSWI1 ... Bit 15: XSWI14	0x00000000 - 0x0000FFFF Bit value: 0=actual position, 1=substituted position		UINT32	R	
44524-44525		Fault disconnect alarm status (AlmFlt): Bit 0: XCBR1 Bit 1: XCBR2 Bit 2: XSWI1 ... Bit 15: XSWI14	0x00000000 - 0x0000FFFF Bit value: 0=no alarm, 1=alarm		UINT32	R	
44526-44541		Command termination status	0=Success, 1=Not-supported, 2=Blocked-by-switching-hierarchy, 4=Invalid-position, 5=Position-reached, 8=Blocked-by-Mode, 9=Blocked-by-process, 10=Blocked-by-interlocking, 12=Command-already-in-execution, 13=Blocked-by-health, 16=Time-limit-over		UINT16	R	
+0		XCBR1 command termination status			UINT16	R	
+1		XCBR2 command termination status			UINT16	R	
+2		XSWI1 command termination status			UINT16	R	
...		...					
+15		XSWI14 command termination status			UINT16	R	
Factory Diagnostic Registers							
45952-46079		Factory diagnostic registers			UINT32	R	

3.7 Device Setup Registers

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
Device Identification							
46080-46111							
+0,1		Device serial number	1-999999		UINT32	R	
+2,3		Device model ID	310, 320, 330		UINT32	R	
+4-11		Device model name	"SA310", "SA320", "SA330"		CHAR16	R	Null-terminated string
+12-13		Device options (bitmap)			UINT32	R	
+14-19		Reserved			UINT16	R	
+20		Device firmware version number			UINT16	R	
+21		Device firmware build number			UINT16	R	
+22		DSP firmware version number			UINT16	R	
+23		DSP firmware build number			UINT16	R	
+24		Boot loader version number			UINT16	R	
+25		Boot loader build number			UINT16	R	
+26-31		Reserved			UINT16	R	
Factory Device Settings							
46112-46207							
+0		V1-V3 input range	690	V	UINT16	R	
+1		V1-V3 input overload	120	%	UINT16	R	
+2		V4 input range	690	V	UINT16	R	
+3		V4 input overload	120	%	UINT16	R	
+4		I1-I3 input range	1, 5	A	UINT16	R	
+5		I1-I3 input overload	400 (ANSI), 200 (IEC)	%	UINT16	R	
+6		I4 input range	1, 5	A	UINT16	R	
+7		I4 input overload	400 (ANSI), 200 (IEC)	%	UINT16	R	
+8		I1x-I3x input range	1, 5	A	UINT16	R	
+9		I1x-I3x input overload	3000	%	UINT16	R	
+10		I4x input range	1, 5	A	UINT16	R	
+11		I4x input overload	3000	%	UINT16	R	
+12		VDC input range	300	V	UINT16	R	
+13		VDC input overload	100	%	UINT16	R	
+14-63		Reserved			UINT16	R	
+64		Ethernet MAC address 0-1	0x0500		UINT16	R	
+65		Ethernet MAC address 2-3	0x00F0		UINT16	R	
+66		Ethernet MAC address 4-5	0x0000-0xFFFF		UINT16	R	
+67-95		Reserved			UINT16	R	
Basic Setup							
46208-46271							
+0		Wiring mode	F26		UINT16	R/W	
+1		PT ratio (primary to secondary ratio)	10-65000	×0.1	UINT16	R/W	
+2		PT secondary (Line-to-Line)	10-690	V	UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+3		V4 PT ratio (primary to secondary ratio)	10-65000	×0.1	UINT16	R/W	
+4		V4 PT secondary voltage	10-690	V	UINT16	R/W	
+5		CT primary current	1-10000	A	UINT16	R/W	
+6		CT secondary current	1, 5	A	UINT16	R/W	
+7		I4 CT primary current	1-10000	A	UINT16	R/W	
+8		I4 CT secondary current	1, 5	A	UINT16	R/W	
+9		Ix CT primary current	1-10000	A	UINT16	R/W	
+10		Ix CT secondary current	1, 5	A	UINT16	R/W	
+11		I4x CT primary current	1-10000	A	UINT16	R/W	
+12		I4x CT secondary current	1-10000	A	UINT16	R/W	
+13-15		Reserved			UINT16	R/W	
+16		VDC nominal voltage	10-300	V	UINT16	R/W	
+17		Nominal line frequency	50, 60	Hz	UINT16	R/W	
+18		Phase order	0 = ABC, 1 = CBA		UINT16	R/W	
+19-23		Reserved			UINT16	R/W	
+24		I maximum demand load current	0-10000	A	UINT16	R/W	
+25		I4 maximum demand load current	0-10000	A	UINT16	R/W	
+26		Ix maximum demand load current	0-10000	A	UINT16	R/W	
+27		I4x maximum demand load current	0-10000	A	UINT16	R/W	
+28-31		Reserved			UINT16	R/W	
Demands Setup							
46240-46255							
+0		Power demand period (block interval)	1, 2, 5, 10, 15, 30, 60	min	UINT16	R/W	
+1		Number of demand periods in a sliding window	1-15		UINT16	R/W	
+2		Demand synchronization source input	0 = device clock, 1-96 = DI1-DI96		UINT16	R/W	A DI input is considered a pulse or KYZ input. The pulse edge restarts the power demand accumulation interval.
+3-7		Reserved			UINT16	R/W	
+8		Volt demand period	0-9000	sec	UINT16	R/W	
+9		Ampere demand period	0-9000	sec	UINT16	R/W	
+10		Harmonic demand period	0-9000	sec	UINT16	R/W	
+11-15		Reserved			UINT16	R/W	
Device Options Setup							
46256-46399							
+0		Power calculation mode	0 = using reactive power: $S = f(P, Q)$, 1 = using non-active power: $Q = f(S, P)$		UINT16	R/W	
+1		Energy roll value	0 = 1×10^4 , 1 = 1×10^5 , 2 = 1×10^6 , 3 = 1×10^7 , 4 = 1×10^8 , 5 = 1×10^9		UINT16	R/W	
+2-7		Reserved			UINT16	R/W	
+8		"kWh"/"kvarh" LED pulse rate, Wh/varh per pulse (in	1 - 10000	×0.01Wh	UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
		secondary units)					
+9		"VDC MEASURE LOW" LED alarm threshold, %	10 - 1000	x0.1%	UINT16	R/W	
+12-143		Reserved			UINT16	R/W	
Time/Date Setup							
46400-46415							
+0		Local time offset, min	0- +/--720		INT16	R/W	Offset in minutes from UTC (Universal Coordinated or Greenwich Mean time)
+1		Daylight savings time (DST) option	0 = DST disabled (standard time only), 1 = DST enabled		UINT16	R/W	
+2		DST start month	1-12		UINT16	R/W	
+3		DST start week of the month	1-4 = 1st, 2nd, 3rd and 4th week, 5=the last week of the month		UINT16	R/W	
+4		DST start weekday	1-7 (1=Sun, 7=Sat)		UINT16	R/W	
+5		DST end month	1-12		UINT16	R/W	
+6		DST end week of the month	1-4 = 1st, 2nd, 3 rd and 4th week, 5=last week of the month		UINT16	R/W	
+7		DST end weekday	1-7 (1=Sun, 7=Sat)		UINT16	R/W	
+8		Clock synchronization source	0 = GPS IRIG-B master clock, 0x0001-0x0080 = DI1-DI128 1PPM, 0x1001-0x1080 = DI1-DI128 1PPS, 0xffff = SNTP, 0xffff = none		UINT16	R/W	A DI input is considered a pulse or KYZ input. The pulse edge aligns the clock at the nearest whole minute.
+9-15		Reserved			UINT16	R/W	
Clock Setup and Status							
46416-46447							
+0,1		Local time, in seconds, since Jan 1, 1970	F1	sec	UINT32	R/W	
+2,3		Fractional seconds, μ sec		μ sec	UINT32	R/W	
+4		Fractional seconds, milliseconds	0-999		UINT16	R/W	
+5		Seconds	0-59		UINT16	R/W	
+6		Minutes	0-59		UINT16	R/W	
+7		Hour	0-23		UINT16	R/W	
+8		Day of month	1-31		UINT16	R/W	
+9		Month	1-12		UINT16	R/W	
+10		Year (calendar year minus 2000)	0-99		UINT16	R/W	
+11		Weekday	1-7 (1=Sun, 7=Sat)		UINT16	R	
+12		Daylight savings time status	0 = standard time, 1 = daylight savings time is active		UINT16	R	
+13		IRIG-B status	0, 1 = no signal, 2 = time unlocked, 3 = time locked		UINT16	R	
+14-31		Reserved			UINT16		
Communication Ports Setup							
46448-46575							

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+0		Communication protocol	0 = Modbus RTU, 1 = Modbus ASCII, 2 = DNP3.0		UINT16	R/W	
+1		Interface	0 = RS-232, 1 = RS-422, 2 = RS-485, 3 = Infrared, 4 = Modem		UINT16	R/W	
+2		Device address	1-247		UINT16	R/W	
+3		Baud rate	1 = 300 bps, 2 = 600 bps, 3 = 1200 bps, 4 = 2400 bps, 5 = 4800 bps, 6 = 9600 bps, 7 = 19200 bps, 8 = 38400 bps, 9 = 57600 bps, 10 = 115200 bps		UINT16	R/W	
+4		Data format	0 = 7 bits/even parity, 1 = 8 bits/no parity, 2 = 8 bits/even parity		UINT16	R/W	
+5		CTS mode	0 = not used, 1 = wait for CTS before sending data		UINT16	R/W	N/A for COM2-COM5 (read as 65535)
+6		RTS mode	0 = not used, 1 = RTS is asserted during the transmission		UINT16	R/W	N/A for COM2-COM5 (read as 65535)
+7		Minimum delay before sending data	0-1000 (default = 5)	ms	UINT16	R/W	
+8		Inter-character time-out	0-1000 (default = 4-character time)	ms	UINT16	R/W	
+9-15		Reserved					
46448-46463		COM1 Setup					
46464-46479		COM2 Setup					
46480-46495		COM3 Setup					
46496-46511		COM4 Setup					
46512-46527		COM5 Setup					
46528-46575		Reserved					
Network Setup							
46576-46703							
+0,1		Device IP Address	0x01000000-0xFFFFFFFF		UINT32	R/W	Network byte order
+2,3		Network subnet mask	0x00000001-0xFFFFFFFF		UINT32	R/W	Network byte order
+4,5		Network default gateway	0x00000000-0xFFFFFFFF		UINT32	R/W	Network byte order
+6,7		Use DHCP	0 = NO, 1 = YES		UINT32	R/W	
+8,9		TCP service port	502 = Modbus/TCP, 20000 = DNP3.0/TCP		UINT32	R/W	Only for firmware versions older than 10.2.16
+10-31		Reserved				R/W	
Password Setup							
46704-46707							
+0,1		Communications password (8 digits)	0 - 99999999		UINT32	R/W	Read as 0
+2		Password protection enabled	0 = disabled, 1 = enabled		UINT16	R/W	
+3		Reserved			UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
46708-46761		Reserved					
IEC 61850 License Setup							
46762-46767							
+0,1		License code, first word			UINT32	R/W	
+2,3		License code, second word			UINT32	R/W	
+4,5		Current license type	0=no valid license 1-31=temporary license, remaining time in days -1=permanent license -3=temporary license has expired		UINT32	R	
Expert Power Service Setup							
46768-46783							
+0,1		Expert Power server IP Address	0x01000000-0xFFFFFFFF		UINT32	R/W	Default = 207.232.60.18
+2,3		Expert Power server TCP service port	0-65535		UINT32	R/W	Default = 5001
+4,5		Expert Power client enabled	0=client disabled, 1=client enabled		UINT32	R/W	
+6,7		Time to next session	1-99999	min	UINT32	R/W	
+8,9		Time to next session	1-99999	min	UINT32	R	Same as previous
+10-15		Reserved					
Internet Service Provider (ISP) account							
46784-46879							
+0-15		ISP telephone number			CHAR32	R/W	
+16-31		Login name			CHAR32	R/W	
+32-47		Login password			CHAR32	R/W	
+48-95		Reserved					
SNTP Client Setup							
46880-46895							
+0,1		SNTP client enabled	0=disabled, 1=enabled		UINT32	R/W	
+2,3		Polling interval	60-86400	s	UINT32	R/W	Default = 600 s
+4-7		Reserved	0		UINT32	R/W	
+8,9		Primary SNTP server IP address	0x01000000-0xFFFFFFFF		UINT32	R/W	Default = 192.36.143.151
+10,11		Secondary SNTP server IP address	0x01000000-0xFFFFFFFF		UINT32	R/W	Default = 130.149.17.21
+12-15		Reserved					
TCP Notification Client Setup							
46896-46991							
+0,1		Client enabled	0=disabled, 1=enabled		UINT32	R/W	
+2,3		Server address	0x01000000-0xFFFFFFFF		UINT32	R/W	
+4,5		Server port	0-65535		UINT32	R/W	
+6,7		Message exchange address	0-65535		UINT32	R/W	
+8-15		Reserved					
GOOSE Subscriber Setup							
48726-48833							
+0		Subscription number	0-19		UINT16	R/W	Write subscription number first

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
							before reading following registers
+1		Activate	Write: 1=activate		UINT16	R/W	Write 1 to store and activate setup
+2		Subscription enabled	0=disabled, 1=enabled		UINT16	R/W	Default = 0
+3-35		Data set reference			CHAR66	R/W	
+36,37		Configuration revision	1-0xFFFFFFFF		UINT32	R/W	Default = 1
+38-40		Destination MAC address (multicast)	01:0C:CD:01:00:00 to 01:0C:CD:01:01:FF		CHAR6	R/W	Default = 01:0C:CD:01:01:01-13
+41		Application ID	0-0xFFFF		UINT16	R/W	Default = 3001
+42-43		Not used	0		UINT16	R/W	
		Data Set Entry #1					
+44		Bits 0:7=member type, bits 8:15=GOOSE element number			UINT16	R/W	
+45		Basic member type			UINT16	R/W	
+46		Input variable ID			UINT16	R/W	
+47		Not used			UINT16	R/W	
+48-51		Data Set Entry #2					
...		...					
+104-107		Data Set Entry #16					
+108-171		Reserved			UINT16	R/W	
48898-49045		Reserved					
GOOSE Publisher Setup							
49046-49145							
+0		Publisher number	0		UINT16	R/W	Write number first before reading following registers
+1		Activate	Write: 1=activate		UINT16	R/W	Write 1 to store and activate setup
+2-34		Goose control block reference	"CTRL/LLN0\$GO\$GoCBPub1"		CHAR66	R	
+35		Publisher enabled	0 = disabled, 1 = enabled		UINT16	R/W	
+36-51		GOOSE application identifier	"Pub1"		CHAR34	R	
+53-85		Data set reference	"CTRL/LLN0\$DSetGOOSE1"		CHAR66	R	
+86-87		Configuration revision	1		UINT32	R/W	Default = 1
+88		Needs commissioning	0 = no, 1 = yes		UINT16	R	Default = 0
+89-91		Destination MAC address (multicast)	01:0C:CD:01:00:00 to 01:0C:CD:01:01:FF		CHAR6	R/W	Default = 01:0C:CD:01:01:FF
+92		Destination VLAN priority	4		UINT16	R	Default = 4
+93		Destination VLAN ID	0		UINT16	R	Default = 0
+94		Destination application ID	0-0xFFFF		UINT16	R/W	Default = 3001
+95		Maximum retransmission interval	500-60000	ms	UINT16	R/W	Default = 5000
+96-99		Not used					
IEC 61850 IED Setup							
49146-49209							
+0-11		IED name			CHAR24	R/W	
+12-19		Subnet name			CHAR16	R/W	
+20		Connection idle timeout	1-10 min		UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+21		Voltage units	0=V, 1=kV		UINT16	R/W	
+22		Current units	0=A, 1=kA		UINT16	R/W	
+23		Power units	0=kW, 1=MW		UINT16	R/W	
+24		Maximum instances/clients per RCB	0=non-indexed, 1, 2, 4		UINT16	R/W	
+25-30		Location			CHAR32	R/W	
+31-63		Not used	0		UINT16	R/W	
IEC 61850 Dataset Setup							
49210-49278							
+0		Read: current dataset number Write: number of dataset members	1-16/1-64		UINT16	R/W	Write a dataset number before reading dataset registers
+1		Activate	1=activate		UINT16	R/W	Write to store and activate setup
+2-34		Dataset reference			CHAR66	R/W	
+35		Dataset member number	0-63		UINT16	R/W	Write a dataset member number before reading following registers
+36-68		Dataset member reference			CHAR66	R/W	
IEC 61850 RCB Setup							
49280-49351							
		Command registers					Write 1-2 registers for a command
+0		Read command (moves the list pointer to the first item in a list)	0xF0F0=read RCBs list, 0xE0E0=read dataset references list		UINT16	W	Write a command before reading setup registers
+1		Activate	1=activate		UINT16	W	Write to store and activate setup
		RCB registers (read/write)			UINT16	R/W	Write more than 2 registers to change setup
+0		RCB type: 1=BRCB, 2=URCB			UINT16	R/W	
+1		Not used			UINT16	R/W	
+2-18		RptID			CHAR34	R/W	
+19		RptEna			UINT16	R/W	
+20-52		Dataset reference			CHAR66	R/W	
+53		Not used			UINT16	R/W	
+54,55		ConfRev			UINT32	R/W	
+56,57		OptFlds			UINT32	R/W	
+58,59		BuTm			UINT32	R/W	
+60		SqNum			UINT16	R/W	
+61		TrgOps			UINT16	R/W	
+62,63		IntgPd			UINT32	R/W	
+64		Resv			UINT16	R/W	
+65-71		RCB name (logical_device/rcb_name)	CTRL/rcb_name MET1/rcb_name		CHAR14	R/W	Reading register 71 advances to the next RCB in the list
		Dataset references list (read)					
+19		Dataset number			UINT16	R	
+20-52		Dataset reference			CHAR66	R	Reading register 52 advances to the next dataset in the list

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
IEC 61850 Report Deadbands							
49396-49444							See F27 for measured value indices
+0		Measured value 1 deadband	1-50000	×0.001%	UINT16	R/W	
...		...	1-50000	×0.001%	UINT16	R/W	
+48		Measured value 49 deadband	1-50000	×0.001%	UINT16	R/W	
49445-49459		Reserved					Read as 65535
EN50160 PQ Recorder Triggers Setup (EN50160 voltage characteristics)							
50134-50453							
+0		Threshold, %	0 - 2000	×0.1%	UINT16	R/W	
+1		Hysteresis, % of threshold	0 - 500	×0.1%	UINT16	R/W	
+2		Log options, bitmap	Bit 0 – waveform log on event start: 0 = disabled, 1 = enabled; Bit 1 – waveform log on event end: 0 = disabled, 1 = enabled; Bit 2 – PQ log: 0 = enabled, 1 = disabled.		UINT16	R/W	
+3		Waveform log number	0 - 7 = log #1 - #7		UINT16	R/W	
+4		Data/RMS plot option	0 = disabled, 1 = enabled		UINT16	R/W	
+5		Data log number (factory preset)	13 = log #14		UINT16	R/W	
+6		1/2-cycle RMS plot, cycles before event	0 - 20	cycle	UINT16	R/W	
+7		1/2-cycle RMS plot, cycles after event	0 - 20	cycle	UINT16	R/W	
+8		1/2-cycle RMS plot duration, cycles	0 - 10000	cycle	UINT16	R/W	
+9		0.2-sec envelope RMS plot duration, seconds	0 - 10000	sec	UINT16	R/W	
+10		3-sec envelope RMS plot duration, minutes	0 - 10000	min	UINT16	R/W	
+11		10-min envelope RMS plot duration, hours	0 - 10000	hours	UINT16	R/W	
+12-15		Reserved	0		UINT16	R/W	
50134-50149		Power frequency, dF/Fn					
50150-50165		Voltage variations, dV/Un					
50166-50181		Rapid voltage changes, dV/Un					
50182-50197		Flicker severity, Plt					
50198-50213		Voltage dips, %Un					
50214-50229		Voltage interruptions, %Un					
50230-50245		Temporary overvoltages, %Un					
50246-50261		Transient overvoltages, %Un					
50262-50277		Voltage unbalance, %					
50278-50293		Harmonic THD, %					
50294-50309		Harmonic voltage, %Un					
50310-50325		Interharmonic THD, %					
50326-50341		Interharmonic voltage, %Un					
50342-50357		Mains signaling voltage, %Un					
50358-50453		Reserved					
Advanced EN50160 Setup							
50838-50865							

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
		EN50160 Compliance Statistics					
+0		Evaluation	0=disabled, 1=enabled		UINT16	R/W	
+1		Evaluation period	0=daily, 1=weekly		UINT16	R/W	
+2		First day of the week	1=Sunday, 7=Saturday		UINT16	R/W	
+3		Reserved	0		UINT16	R/W	
		EN50160 Harmonics Survey					
+4		Evaluation	0=disabled, 1=enabled		UINT16	R/W	
+5		Evaluation period	0=daily, 1=weekly		UINT16	R/W	
+6-7		Reserved	0		UINT16	R/W	
		Rapid Voltage Changes					
+8		Repetition rate, per hour, maximum	1-10		UINT16	R/W	
+9		Reserved	0		UINT16	R/W	
		Flicker					
+10		Pst period	1-10	min	UINT16	R/W	
+11		Reserved	0		UINT16	R/W	
		Harmonic Voltage					
+12		THD, up to order	25-50		UINT16	R/W	
+13		Harmonics, up to order	25-50		UINT16	R/W	
+14-15		Reserved	0		UINT16	R/W	
		Interharmonic Voltage					
+16		Evaluation	0=disabled, 1=enabled		UINT16	R/W	
+17		THD, up to order	25-50		UINT16	R/W	
+18		Interharmonics, up to order	25-50		UINT16	R/W	
+19		Reserved	0		UINT16	R/W	
		Mains Signaling Voltage					
+20		Evaluation	0=disabled, 1=enabled		UINT16	R/W	
+21		1st signaling frequency	1100-30000	×0.1Hz	UINT16	R/W	
+22		2nd signaling frequency	1100-30000	×0.1Hz	UINT16	R/W	
+23		3rd signaling frequency	1100-30000	×0.1Hz	UINT16	R/W	
+24		4th signaling frequency	1100-30000	×0.1Hz	UINT16	R/W	
		Transient Overvoltage					
+25		Transient detection and classification method	0=peak voltage, 1=impulsive voltage		UINT16	R/W	
+26-27		Reserved	0		UINT16	R/W	
50866-50901		Reserved	0		UINT16	R/W	
EN50160 Harmonic Voltage Limits							
50902-50965							
+0		H02 limit	1-10000	×0.01%	UINT16	R/W	
+1		H03 limit	1-10000	×0.01%	UINT16	R/W	
+2		H04 limit	1-10000	×0.01%	UINT16	R/W	
		...					
+48		H50 limit	1-10000	×0.01%	UINT16	R/W	
+49-63		Reserved					

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
EN50160 Interharmonic Voltage Limits							
50966-51029							
+0		H02 limit	1-10000	×0.01%	UINT16	R/W	
+1		H03 limit	1-10000	×0.01%	UINT16	R/W	
+2		H04 limit	1-10000	×0.01%	UINT16	R/W	
		...					
+48		H50 limit	1-10000	×0.01%	UINT16	R/W	
+49-63		Reserved					
DNP Options Setup							
51158-51183							
+0		Default Binary Input Static object variation	F24 (default 0)		UINT16	R/W	
+1		Binary Input Change object variation	F24 (default 1)		UINT16	R/W	
+2		Default Binary Counter object variation	F24 (default 3)		UINT16	R/W	
+3		Frozen Binary Counter object variation	F24 (default 4)		UINT16	R/W	
+4		Reserved			UINT16	R/W	
+5		Binary Counter Change Event object variation	F24 (default 2)		UINT16	R/W	
+6		Default Analog Input object variation	F24 (default 3)		UINT16	R/W	
+7		Reserved			UINT16	R/W	
+8		Reserved			UINT16	R/W	
+9		Analog Input Change Event object variation	F24 (default 2)		UINT16	R/W	
+10		Re-mapping static point indices for event objects	0=disabled (default), 1=enabled		UINT16	R/W	
+11		16-bit BC scaling	0=×1 (default), 1=×10, 2=×100, 3=×1000		UINT16	R/W	
+12		16-bit AI scaling	0=disabled, 1=enabled		UINT16	R/W	
+13		Number of Analog Input change event points	0 to 43 (default 43)		UINT16	R/W	
+14		Number of Binary Input change event points	0 to 32 (default 21)		UINT16	R/W	
+15		Number of Binary Counter change event points	0 to 16 (default 0)		UINT16	R/W	
+16		Select/Operate Timeout	2 to 30 seconds (default 10 sec)		UINT16	R/W	
+17		Multi Fragment Interval	50 to 500 ms (default 50 ms)		UINT16	R/W	
+18-21		Reserved	Read as 65535		UINT16	R/W	
+22,23		Time Sync Period	1 to 86400 seconds (default 86400 sec), 0=disable time requests		UINT32	R/W	
+24		Voltage scale, secondary volts	60 to 828V (default 828V)		UINT16	R/W	
+25		Current scale, secondary amps	10 to 200 (default CT secondary × CT overload)	×0.1A	UINT16	R/W	
51184-51189		Reserved					
DNP Events Setup							
51190-51445							
+0,1		Threshold/Deadband	See Section 3.5 for point value limits.		UINT32	R/W	A hysteresis for the point return threshold is 0.05Hz for frequency and 2% of the operating threshold for other points

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
	+2	DNP point number	DNP point number available for the selected object		UINT16	R/W	
	+3	Event scan control field (bitmap)	Bits 0-1 - DNP Object: 0=none, 1=A1, 2=B1, 3=BC Bit 2 - Object change event scan: 0= disabled, 1=enabled Bits 5-6 - DNP event poll class: 0=Class 1, 1=Class 2, 2=Class 3 Bit 7 - unused Bits 8-9 - Threshold/Deadband relation: 0=Delta, 1=more than (over threshold), 2=less than (under threshold)		UINT16	R/W	If Event log is enabled, the source of a DNP event will be recorded to the device Event log file as a general Setpoint #17.
51190-51193		DNP Event #1					
51194-51197		DNP Event #2					
		...					
51442-51445		DNP Event #64					
51446-51701		Reserved					
DNP Class 0 Point Assignment							
51702-51797							
	+0	DNP object and variation	F25		UINT16	R/W	
	+1	Start point number	Start point number for the selected object		UINT16	R/W	
	+2	Number of the points in a range	0-128		UINT16	R/W	
51702-51704		DNP Class 0 Points Range 1					
51705-51707		DNP Class 0 Points Range 2					
		...					
51795-51797		DNP Class 0 Points Range 32					
51798-51893		Reserved					
SOE Log Labels							
51894-52043							
	+0	Event type	0=Setpoints, 2=Faults, 3=DI, 4=RO		UINT16	R/W	Write the event type and point number before reading following registers
	+1	Point number	0-47		UINT16	R/W	
	+2-17	Point ID			CHAR32	R/W	
	+18-33	Status ON label			CHAR32	R/W	
	+34-81	Status ON description			CHAR96	R/W	
	+82	Status ON color	0-15		UINT16	R/W	
	+83	Reserved	0		UINT16	R/W	
	+84-99	Status OFF label			CHAR32	R/W	
	+100-147	Status OFF description			CHAR96	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+148		Status OFF color	0-15		UINT16	R/W	
+149		Reserved	0		UINT16	R/W	
52044-52149		Reserved					
Fault Log Triggers Setup							
52150-52277							
+0		Trigger 1: Threshold, %	0 - 2000	x 0.1%	UINT16	R/W	
+1		Trigger 1: Hysteresis, % of threshold	0 - 500	x 0.1%	UINT16	R/W	
+2		Trigger 1: Trigger enabled	0 = disabled, 1 = enabled		UINT16	R/W	
+3		Trigger 2: Threshold, %	0 - 2000	x 0.1%	UINT16	R/W	
+4		Trigger 2: Hysteresis, % of threshold	0 - 500	x 0.1%	UINT16	R/W	
+5		Trigger 2: Trigger enabled	0 = disabled, 1 = enabled		UINT16	R/W	
+6-7		Reserved			UINT16	R/W	
52150-52157		External trigger					Enabled by default
52158-52165		Zero-sequence current					
52166-52173		Zero-sequence voltage					
52174-52181		Current unbalance					
52182-52189		Voltage unbalance					
52190-52197		Overcurrent and Undervoltage					
52198-52205		Undervoltage					
52206-52213		I4 (neutral) current					
52214-52277		Reserved			UINT16	R/W	
Fault Log Recording Setup							
52278-52341							
+0		Log options, bitmap	Bit 0 – waveform log on event start: 0 = disabled, 1 = enabled; Bit 1 – waveform log on event end: 0 = disabled, 1 = enabled; Bit 2 – recording to PQ log: 0 = enabled, 1 = disabled.		UINT16	R/W	
+1		Waveform log number	0 - 7 = log #1 - #8		UINT16	R/W	
+2		Data/RMS plot option	0 = disabled, 1 = enabled		UINT16	R/W	
+3		Data log number (factory preset)	12 = log #13		UINT16	R/W	
+4		1/2-cycle RMS plot, cycles before event	0 - 20	cycle	UINT16	R/W	
+5		1/2-cycle RMS plot, cycles after event	0 - 20	cycle	UINT16	R/W	
+6		1/2-cycle RMS plot duration, cycles	0 - 10000	cycle	UINT16	R/W	
+7-63		Reserved	0		UINT16	R/W	
IEEE 1159 PQ Log Triggers Setup (IEEE 1159 disturbance categories)							
52342-52597							
+0		Threshold, %	0 - 2000	x 0.1%	UINT16	R/W	
+1		Hysteresis, % of threshold	0 - 500	x 0.1%	UINT16	R/W	
+2		Log options, bitmap	Bit 0 – waveform log on event start: 0 = disabled, 1 = enabled; Bit 1 – waveform log on event end:		UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
			0 = disabled, 1 = enabled.				
+3		Waveform log number	0 - 7 = log #1 - #7		UINT16	R/W	
+4		Data/RMS plot option	0 = disabled, 1 = enabled		UINT16	R/W	
+5		Data log number (factory preset)	13 = log #14		UINT16	R/W	
+6		1/2-cycle RMS plot, cycles before event	0 - 20	cycle	UINT16	R/W	
+7		1/2-cycle RMS plot, cycles after event	0 - 20	cycle	UINT16	R/W	
+8		1/2-cycle RMS plot duration, cycles	0 - 10000	cycle	UINT16	R/W	
+9		0.2-sec envelope RMS plot duration, seconds	0 - 10000	sec	UINT16	R/W	
+10		3-sec envelope RMS plot duration, minutes	0 - 10000	min	UINT16	R/W	
+11		10-min envelope RMS plot duration, hours	0 - 10000	hours	UINT16	R/W	
+12-15		Reserved	0		UINT16	R/W	
52342-52357		Impulsive					
52358-52373		Sag					
52374-52389		Swell					
52390-52405		Interruption					
52406-52421		Volt Unbalance					
52422-52437		Frequency variation					
52438-52453		Harmonics					
52454-52469		Interharmonics					
52470-52597		Reserved					
File Setup							
52598-53877							
+0		File type	0		UINT16	R/W	
+1		File attributes (bitmap)	F3		UINT16	R/W	
+2		Number of records in the file	0-65535 (0 = delete file)		UINT16	R/W	
+3		Number of sections/channels in the file	0-32		UINT16	R/W	0 = non-partitioned file
+4		Number of parameters per section record	1-16		UINT16	R/W	
+5		Not used	0		UINT16	R/W	
+6		Section record size, bytes (for info only)			UINT16	R	
+7		File record size, bytes (for info only)			UINT16	R	
+8,9		Allocated file size, bytes (for info only)			UINT32	R	
52598-52607		Event Log Setup					
52608-52617		Data Log #1 Setup					
52618-52627		Data Log #2 Setup					
52628-52637		Data Log #3 Setup					
52638-52647		Data Log #4 Setup					
52648-52657		Data Log #5 Setup					
52658-52667		Data Log #6 Setup					
52668-52677		Data Log #7 Setup					
52678-52687		Data Log #8 Setup					
52688-52697		Data Log #9 Setup					
52698-52707		Data Log #10 Setup					
52708-52717		Data Log #11 Setup					

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
52718-52727		Data Log #12 Setup					
52728-52737		Data Log #13 Setup					
52738-52747		Data Log #14 Setup					
52748-52757		Data Log #15 Setup					
52758-52767		Data Log #16 Setup					
52768-52777		Waveform Log #1 Setup					
52778-52787		Waveform Log #2 Setup					
52788-52797		Waveform Log #3 Setup					
52798-52807		Waveform Log #4 Setup					
52808-52817		Waveform Log #5 Setup					
52818-52827		Waveform Log #6 Setup					
52828-52837		Waveform Log #7 Setup					
52838-52847		Waveform Log #8 Setup					
52848-52857		SOE Log Setup					
52858-52867		PQ Log Setup					
52868-52877		Fault Log Setup					
52878-53877		Reserved					
Waveform Recorder Setup							
53878-53949							
+0		Sampling rate, samples per cycle	32, 64, 128		UINT16	R/W	
+1		Number of cycles per series	16-10848 (32 samples/cycle), 8-5424 (64 samples/cycle), 4-2712 (128 samples/cycle)		UINT16	R/W	
+3		Not used	0		UINT16	R/W	
+4		Number of cycles before trigger	1-20		UINT16	R/W	
+4,5		File channel mask (channels 1-32), bitmap	F9		UINT32	R/W	
+6,7		File channel mask (channels 33-64), bitmap	F9		UINT32	R/W	
53878-53885		Waveform Log #1 Setup					
53886-53893		Waveform Log #2 Setup					
53894-53901		Waveform Log #3 Setup					
53902-53909		Waveform Log #4 Setup					
53910-53917		Waveform Log #5 Setup					
53918-53925		Waveform Log #6 Setup					
53926-53933		Waveform Log #7 Setup					
53934-53941		Waveform Log #8 Setup					
53942-53949		Reserved					
Data Log Setup							
54006-55541							
+0		Data log parameter #1 ID	0x0000-0xFFFF		UINT16	R/W	
+1		Data log parameter #2 ID	0x0000-0xFFFF		UINT16	R/W	
+2		Data log parameter #3 ID	0x0000-0xFFFF		UINT16	R/W	
+3		Data log parameter #4 ID	0x0000-0xFFFF		UINT16	R/W	
+4		Data log parameter #5 ID	0x0000-0xFFFF		UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+5		Data log parameter #6 ID	0x0000-0xFFFF		UINT16	R/W	
+6		Data log parameter #7 ID	0x0000-0xFFFF		UINT16	R/W	
+7		Data log parameter #8 ID	0x0000-0xFFFF		UINT16	R/W	
+8		Data log parameter #9 ID	0x0000-0xFFFF		UINT16	R/W	
+9		Data log parameter #10 ID	0x0000-0xFFFF		UINT16	R/W	
+10		Data log parameter #11 ID	0x0000-0xFFFF		UINT16	R/W	
+11		Data log parameter #12 ID	0x0000-0xFFFF		UINT16	R/W	
+12		Data log parameter #13 ID	0x0000-0xFFFF		UINT16	R/W	
+13		Data log parameter #14 ID	0x0000-0xFFFF		UINT16	R/W	
+14		Data log parameter #15 ID	0x0000-0xFFFF		UINT16	R/W	
+15		Data log parameter #16 ID	0x0000-0xFFFF		UINT16	R/W	
+16-31		Reserved			UINT16	R/W	
54006-54037		Data log #1 Setup					
54038-54069		Data log #2 Setup					
54070-54101		Data log #3 Setup					
54102-54133		Data log #4 Setup					
54134-54165		Data log #5 Setup					
54166-54197		Data log #6 Setup					
54198-54229		Data log #7 Setup					
54230-54261		Data log #8 Setup					
54262-54293		Data log #9 Setup					Read as NONE for EN50160 Statistics log
54294-54325		Data log #10 Setup					Read as NONE for EN50160 Harmonics Survey log
54326-54357		Data log #11 Setup					
54358-54389		Data log #12 Setup					
54390-54421		Data log #13 Setup					
54422-54453		Data log #14 Setup					
54454-54485		Data log #15 Setup					
54486-54517		Data log #16 Setup					
54518-55541		Reserved			UINT16	R/W	
Programmable Min/Max Log Setup							
55542-55573							
55542		Min/Max log parameter #1 ID	0x0000-0xFFFF		UINT16	R/W	
55543		Min/Max log parameter #2 ID	0x0000-0xFFFF		UINT16	R/W	
55544		Min/Max log parameter #3 ID	0x0000-0xFFFF		UINT16	R/W	
55545		Min/Max log parameter #4 ID	0x0000-0xFFFF		UINT16	R/W	
55546		Min/Max log parameter #5 ID	0x0000-0xFFFF		UINT16	R/W	
55547		Min/Max log parameter #6 ID	0x0000-0xFFFF		UINT16	R/W	
55548		Min/Max log parameter #7 ID	0x0000-0xFFFF		UINT16	R/W	
55549		Min/Max log parameter #8 ID	0x0000-0xFFFF		UINT16	R/W	
55550		Min/Max log parameter #9 ID	0x0000-0xFFFF		UINT16	R/W	
55551		Min/Max log parameter #10 ID	0x0000-0xFFFF		UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
55552		Min/Max log parameter #11 ID	0x0000-0xFFFF		UINT16	R/W	
55553		Min/Max log parameter #12 ID	0x0000-0xFFFF		UINT16	R/W	
55554		Min/Max log parameter #13 ID	0x0000-0xFFFF		UINT16	R/W	
55555		Min/Max log parameter #14 ID	0x0000-0xFFFF		UINT16	R/W	
55556		Min/Max log parameter #15 ID	0x0000-0xFFFF		UINT16	R/W	
55557		Min/Max log parameter #16 ID	0x0000-0xFFFF		UINT16	R/W	
55558-55573		Reserved			UINT16	R/W	
TOU Daily Profile Setup							
55574-55701							
+0		1 st tariff change	F10		UINT16	R/W	
+1		2 nd tariff change	F10		UINT16	R/W	
+2		3 rd tariff change	F10		UINT16	R/W	
+3		4 th tariff change	F10		UINT16	R/W	
+4		5 th tariff change	F10		UINT16	R/W	
+5		6 th tariff change	F10		UINT16	R/W	
+6		7 th tariff change	F10		UINT16	R/W	
+7		8 th tariff change	F10		UINT16	R/W	
55574-55581		TOU daily profile #1					
55582-55589		TOU daily profile #2					
55590-55597		TOU daily profile #3					
55598-55605		TOU daily profile #4					
55606-55613		TOU daily profile #5					
55614-55621		TOU daily profile #6					
55622-55629		TOU daily profile #7					
55630-55637		TOU daily profile #8					
55638-55645		TOU daily profile #9					
55646-55653		TOU daily profile #10					
55654-55661		TOU daily profile #11					
55662-55669		TOU daily profile #12					
55670-55677		TOU daily profile #13					
55678-55685		TOU daily profile #14					
55686-55693		TOU daily profile #15					
55694-55701		TOU daily profile #16					
TOU Calendar Years Setup							
55702-55711							
55702		Calendar #1 year	0-99		UINT16	R/W	
55703		Calendar #2 year	0-99		UINT16	R/W	
55704		Calendar #3 year	0-99		UINT16	R/W	
55705		Calendar #4 year	0-99		UINT16	R/W	
55706		Calendar #5 year	0-99		UINT16	R/W	
55707		Calendar #6 year	0-99		UINT16	R/W	
55708		Calendar #7 year	0-99		UINT16	R/W	
55709		Calendar #8 year	0-99		UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
55710		Calendar #9 year	0-99		UINT16	R/W	
55711		Calendar #10 year	0-99		UINT16	R/W	
TOU Calendar Setup							
55712-56671							
+0-7		January				R/W	
+0		1-4 January day profiles			UINT16	R/W	
+1		5-7 January day profiles			UINT16	R/W	
+2		8-12 January day profiles			UINT16	R/W	
+3		13-16 January day profiles			UINT16	R/W	
+4		17-20 January day profiles			UINT16	R/W	
+5		21-24 January day profiles			UINT16	R/W	
+6		25-28 January day profiles			UINT16	R/W	
+7		29-31 January day profiles			UINT16	R/W	
+8-15		February			UINT16	R/W	
+0		1-4 February day profiles			UINT16	R/W	
+1		5-7 February day profiles			UINT16	R/W	
+2		8-12 February day profiles			UINT16	R/W	
+3		13-16 February day profiles			UINT16	R/W	
+4		17-20 February day profiles			UINT16	R/W	
+5		21-24 February day profiles			UINT16	R/W	
+6		25-28 February day profiles			UINT16	R/W	
+7		29 February day profile			UINT16	R/W	
+16-23		March					
+0		1-4 March day profiles			UINT16	R/W	
+1		5-7 March day profiles			UINT16	R/W	
+2		8-12 March day profiles			UINT16	R/W	
+3		13-16 March day profiles			UINT16	R/W	
+4		17-20 March day profiles			UINT16	R/W	
+5		21-24 March day profiles			UINT16	R/W	
+6		25-28 March day profiles			UINT16	R/W	
+7		29-31 March day profile			UINT16	R/W	
+24-31		April			UINT16	R/W	
+0		1-4 April day profiles			UINT16	R/W	
+1		5-7 April day profiles			UINT16	R/W	
+2		8-12 April day profiles			UINT16	R/W	
+3		13-16 April day profiles			UINT16	R/W	
+4		17-20 April day profiles			UINT16	R/W	
+5		21-24 April day profiles			UINT16	R/W	
+6		25-28 April day profiles			UINT16	R/W	
+7		29-30 April day profile			UINT16	R/W	
+32-39		May			UINT16	R/W	
+0		1-4 May day profiles			UINT16	R/W	
+1		5-7 May day profiles			UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+2		8-12 May day profiles			UINT16	R/W	
+3		13-16 May day profiles			UINT16	R/W	
+4		17-20 May day profiles			UINT16	R/W	
+5		21-24 May day profiles			UINT16	R/W	
+6		25-28 May day profiles			UINT16	R/W	
+7		29-31 May day profile			UINT16	R/W	
+40-23		June			UINT16	R/W	
+0		1-4 June day profiles			UINT16	R/W	
+1		5-7 June day profiles			UINT16	R/W	
+2		8-12 June day profiles			UINT16	R/W	
+3		13-16 June day profiles			UINT16	R/W	
+4		17-20 June day profiles			UINT16	R/W	
+5		21-24 June day profiles			UINT16	R/W	
+6		25-28 June day profiles			UINT16	R/W	
+7		29-30 June day profile			UINT16	R/W	
+48-55		July			UINT16	R/W	
+0		1-4 July day profiles			UINT16	R/W	
+1		5-7 July day profiles			UINT16	R/W	
+2		8-12 July day profiles			UINT16	R/W	
+3		13-16 July day profiles			UINT16	R/W	
+4		17-20 July day profiles			UINT16	R/W	
+5		21-24 July day profiles			UINT16	R/W	
+6		25-28 July day profiles			UINT16	R/W	
+7		29-31 July day profile			UINT16	R/W	
+56-63		August			UINT16	R/W	
+0		1-4 August day profiles			UINT16	R/W	
+1		5-7 August day profiles			UINT16	R/W	
+2		8-12 August day profiles			UINT16	R/W	
+3		13-16 August day profiles			UINT16	R/W	
+4		17-20 August day profiles			UINT16	R/W	
+5		21-24 August day profiles			UINT16	R/W	
+6		25-28 August day profiles			UINT16	R/W	
+7		29-31 August day profile			UINT16	R/W	
+64-71		September			UINT16	R/W	
+0		1-4 September day profiles			UINT16	R/W	
+1		5-7 September day profiles			UINT16	R/W	
+2		8-12 September day profiles			UINT16	R/W	
+3		13-16 September day profiles			UINT16	R/W	
+4		17-20 September day profiles			UINT16	R/W	
+5		21-24 September day profiles			UINT16	R/W	
+6		25-28 September day profiles			UINT16	R/W	
+7		29-30 September day profile			UINT16	R/W	
+72-79		October			UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+0		1-4 October day profiles			UINT16	R/W	
+1		5-7 October day profiles			UINT16	R/W	
+2		8-12 October day profiles			UINT16	R/W	
+3		13-16 October day profiles			UINT16	R/W	
+4		17-20 October day profiles			UINT16	R/W	
+5		21-24 October day profiles			UINT16	R/W	
+6		25-28 October day profiles			UINT16	R/W	
+7		29-31 October day profile			UINT16	R/W	
+80-87		November			UINT16	R/W	
+0		1-4 November day profiles			UINT16	R/W	
+1		5-7 November day profiles			UINT16	R/W	
+2		8-12 November day profiles			UINT16	R/W	
+3		13-16 November day profiles			UINT16	R/W	
+4		17-20 November day profiles			UINT16	R/W	
+5		21-24 November day profiles			UINT16	R/W	
+6		25-28 November day profiles			UINT16	R/W	
+7		29-30 November day profile			UINT16	R/W	
+88-95		December			UINT16	R/W	
+0		1-4 December day profiles			UINT16	R/W	
+1		5-7 December day profiles			UINT16	R/W	
+2		8-12 December day profiles			UINT16	R/W	
+3		13-16 December day profiles			UINT16	R/W	
+4		17-20 December day profiles			UINT16	R/W	
+5		21-24 December day profiles			UINT16	R/W	
+6		25-28 December day profiles			UINT16	R/W	
+7		29-31 December day profile			UINT16	R/W	
55712-55807		TOU Calendar #1 Setup					
55808-55903		TOU Calendar #2 Setup					
55904-55999		TOU Calendar #3 Setup					
56000-56095		TOU Calendar #4 Setup					
56096-56191		TOU Calendar #5 Setup					
56192-56287		TOU Calendar #6 Setup					
56288-56383		TOU Calendar #7 Setup					
56384-56479		TOU Calendar #8 Setup					
56480-56575		TOU Calendar #9 Setup					
56576-56671		TOU Calendar #10 Setup					
Billing/TOU Registers Setup							
56672-56927							
+0,1		Roll over value	1-1,000,000,000		UINT32	R/W	
+2		TOU register enabled	0 = disabled, 1 = enabled		UINT16	R/W	
+3		Setpoint gate	0 = disabled, 1-32 = setpoint No		UINT16	R/W	
56672-56675		Register #1 Setup					
56676-56679		Register #2 Setup					

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
56680-56683		Register #3 Setup					
		...					
56796-56799		Register #32 Setup					
56800-56927		Reserved					
Billing/TOU Registers Source Setup							
56928-57183							
+0		Energy source ID	F11		UINT16	R/W	
+1		Target billing register number	0-31		UINT16	R/W	
+2,3		Multiplier	+/-1-10000		INT32	R/W	
56928-56931		Energy Source #1					
56932-56935		Energy Source #2					
56936-56939		Energy Source #3					
		...					
57180-57183		Energy Source #64					
Control Setpoints Setup (SP1-SP32)							
57184-59103		Setpoints 1-32					
+0		Condition #1: Trigger parameter ID	F12		UINT16	R/W	
+1		Condition #2: Trigger parameter ID	F12		UINT16	R/W	
+2		Condition #3: Trigger parameter ID	F12		UINT16	R/W	
+3		Condition #4: Trigger parameter ID	F12		UINT16	R/W	
+4		Condition #1: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+5		Condition #2: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+6		Condition #3: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+7		Condition #4: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+8		Condition #1: Relational operator	F13		UINT16	R/W	
+9		Condition #2: Relational operator	F13		UINT16	R/W	
+10		Condition #3: Relational operator	F13		UINT16	R/W	
+11		Condition #4: Relational operator	F13		UINT16	R/W	
+12,13		Condition #1: Operate limit			INT32	R/W	
+14,15		Condition #2: Operate limit			INT32	R/W	
+16,17		Condition #3: Operate limit			INT32	R/W	
+18,19		Condition #4: Operate limit			INT32	R/W	
+20,21		Condition #1: Release limit			INT32	R/W	
+22,23		Condition #2: Release limit			INT32	R/W	
+24,25		Condition #3: Release limit			INT32	R/W	
+26,27		Condition #4: Release limit			INT32	R/W	
+28		Action #1: Action ID	F14		UINT16	R/W	
+29		Action #2: Action ID	F14		UINT16	R/W	
+30		Action #3: Action ID	F14		UINT16	R/W	
+31		Action #4: Action ID	F14		UINT16	R/W	
+32,33		Action #1: Parameter value			INT32	R/W	
+34,35		Action #2: Parameter value			INT32	R/W	
+36,37		Action #3: Parameter value			INT32	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+38,39		Action #4: Parameter value			INT32	R/W	
+40,41		Operate delay	0-10000000	0.001 s	UINT32	R/W	
+42,43		Release delay	0-10000000	0.001 s	UINT32	R/W	
+44-59		Not used			UINT16	R/W	
57184-57243		Setpoint #1					
57244-57303		Setpoint #2					
		...					
59044-59103		Setpoint #32					
Control Setpoints Setup (SP1-SP64)							
59104-59177		Setpoints 1-64					
+0		Setpoint number	0-63		UINT16	R/W	Write a setpoint number first before reading following registers
+1		Variation	8		UINT16	R/W	
+2		Condition #1: Trigger parameter ID	F12		UINT16	R/W	
+3		Condition #2: Trigger parameter ID	F12		UINT16	R/W	
+4		Condition #3: Trigger parameter ID	F12		UINT16	R/W	
+5		Condition #4: Trigger parameter ID	F12		UINT16	R/W	
+6		Condition #5: Trigger parameter ID	F12		UINT16	R/W	
+7		Condition #6: Trigger parameter ID	F12		UINT16	R/W	
+8		Condition #7: Trigger parameter ID	F12		UINT16	R/W	
+9		Condition #8: Trigger parameter ID	F12		UINT16	R/W	
+10		Condition #1: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+11		Condition #2: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+12		Condition #3: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+13		Condition #4: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+14		Condition #5: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+15		Condition #6: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+16		Condition #7: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+17		Condition #8: Logical operator	0 = OR, 1 = AND		UINT16	R/W	
+18		Condition #1: Relational operator	F13		UINT16	R/W	
+19		Condition #2: Relational operator	F13		UINT16	R/W	
+20		Condition #3: Relational operator	F13		UINT16	R/W	
+21		Condition #4: Relational operator	F13		UINT16	R/W	
+22		Condition #5: Relational operator	F13		UINT16	R/W	
+23		Condition #6: Relational operator	F13		UINT16	R/W	
+24		Condition #7: Relational operator	F13		UINT16	R/W	
+25		Condition #8: Relational operator	F13		UINT16	R/W	
+26,27		Condition #1: Operate limit			INT32	R/W	
+28,29		Condition #2: Operate limit			INT32	R/W	
+30,31		Condition #3: Operate limit			INT32	R/W	
+32,33		Condition #4: Operate limit			INT32	R/W	
+34,35		Condition #5: Operate limit			INT32	R/W	
+36,37		Condition #6: Operate limit			INT32	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+38,39		Condition #7: Operate limit			INT32	R/W	
+40,41		Condition #8: Operate limit			INT32	R/W	
+42,43		Condition #1: Release limit			INT32	R/W	
+44,45		Condition #2: Release limit			INT32	R/W	
+46,47		Condition #3: Release limit			INT32	R/W	
+48,49		Condition #4: Release limit			INT32	R/W	
+50,51		Condition #5: Release limit			INT32	R/W	
+52,53		Condition #6: Release limit			INT32	R/W	
+54,55		Condition #7: Release limit			INT32	R/W	
+56,57		Condition #8: Release limit			INT32	R/W	
+58		Action #1: Action ID	F14		UINT16	R/W	
+59		Action #2: Action ID	F14		UINT16	R/W	
+60		Action #3: Action ID	F14		UINT16	R/W	
+61		Action #4: Action ID	F14		UINT16	R/W	
+62,63		Action #1: Parameter value			INT32	R/W	
+64,65		Action #2: Parameter value			INT32	R/W	
+66,67		Action #3: Parameter value			INT32	R/W	
+68,69		Action #4: Parameter value			INT32	R/W	
+70,71		Operate delay	0-10000000	0.001 s	UINT32	R/W	
+72,73		Release delay	0-10000000	0.001 s	UINT32	R/W	
59178-59253		Reserved	0		INT16	R/W	
Switching Device Setup							
59255		Switch number	0-15		UINT16	R/W	Write a switch number before accessing following registers
59256-59315		Switch setup data					
		General			UINT16	R/W	
+0		Switch designation	0-1=XCBR1-XCBR2, 2-15=XSWI1-XSWI14		UINT16	R/W	Same as switch number
+1-3		IEC 61850 name prefix	1-5 ASCII characters		CHAR6	R/W	Null-terminated ASCII string
+4		Switch type	1=load break switch, 2=disconnecter, 3=earthing switch, 4=high speed earthing switch, 5=breaker (fixed for XCBR1-XCBR2)		UINT16	R/W	
+5		Switch enabled	0=disabled, 1=enabled		UINT16	R/W	
		Position Indication					
+6		Phase A N.O. contact input	0=none, 0x0080-0x00BF=SP1-SP64, 0x0300-0x033F=FLAG1-FLAG64, 0x0600-0x067F=D11-D1128, 0x8200-0x827F=ExtInd1-ExtInd128		UINT16	R/W	
+7		Phase A N.C. contact input	0=none, 0x0080-0x00BF=SP1-SP64, 0x0300-0x033F=FLAG1-FLAG64,		UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
			0x0600-0x067F=DI1-DI128, 0x8200-0x827F=ExtInd1-ExtInd128				
+8		Phase B N.O. contact input	0=none, 0x0080-0x00BF=SP1-SP64, 0x0300-0x033F=FLAG1-FLAG64, 0x0600-0x067F=DI1-DI128, 0x8200-0x827F=ExtInd1-ExtInd128		UINT16	R/W	
+9		Phase B N.C. contact input	0=none, 0x0080-0x00BF=SP1-SP64, 0x0300-0x033F=FLAG1-FLAG64, 0x0600-0x067F=DI1-DI128, 0x8200-0x827F=ExtInd1-ExtInd128		UINT16	R/W	
+10		Phase C N.O. contact input	0=none, 0x0080-0x00BF=SP1-SP64, 0x0300-0x033F=FLAG1-FLAG64, 0x0600-0x067F=DI1-DI128, 0x8200-0x827F=ExtInd1-ExtInd128		UINT16	R/W	
+11		Phase C N.C. contact input	0=none, 0x0080-0x00BF=SP1-SP64, 0x0300-0x033F=FLAG1-FLAG64, 0x0600-0x067F=DI1-DI128, 0x8200-0x827F=ExtInd1-ExtInd128		UINT16	R/W	
		Control					
+12		Close control output	0=none, 0x0800-0x083F=RO1-RO64		UINT16	R/W	
+13		Open control output	0=none, 0x0800-0x083F=RO1-RO64		UINT16	R/W	
+14		Open-2 control output	0=none, 0x0800-0x083F=RO1-RO64		UINT16	R/W	
+15		Select-Close control output	0=none, 0x0800-0x083F=RO1-RO64		UINT16	R/W	
+16		Select-Open control output	0=none, 0x0800-0x083F=RO1-RO64		UINT16	R/W	
+17		Select-Open-2 control output	0=none, 0x0800-0x083F=RO1-RO64		UINT16	R/W	
+18		Close duration control logic equation	0=none, 0x0080-0x00BF=SP1-SP64		UINT16	R/W	
+19		Open duration control logic equation	0=none, 0x0080-0x00BF=SP1-SP64		UINT16	R/W	
+20,21		Close command duration	100-60000 ms		UINT32	R/W	
+22,23		Open command duration	100-60000 ms		UINT32	R/W	
+24,25		Close start moving timeout	0-60000 ms, 0=not controlled		UINT32	R/W	
+26,27		Open start moving timeout	0-60000 ms, 0=not controlled		UINT32	R/W	
+28,29		Close command termination timeout	1-120000 ms		UINT32	R/W	
+30,31		Open command termination timeout	1-120000 ms		UINT32	R/W	
		Interlocking					

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+32		Enable close logic equation	0=none, 0x0080-0x00BF=SP1-SP64, 0xFFFF=TRUE		UINT16	R/W	
+33		Enable open logic equation	0=none, 0x0080-0x00BF=SP1-SP64, 0xFFFF=TRUE		UINT16	R/W	
+34		Interlocking bypass logic equation	0=none, 0x0080-0x00BF=SP1-SP64		UINT16	R/W	
+35		Interlocking bypass timeout	0-600 s		UINT16	R/W	
+36-59		Reserved			UINT16	R/W	
Periodic Timers Setup							
61024-61087							
+0,1		Time interval (positive in seconds, negative in cycles)	-100000000 -100000000	0.001 s/c	UINT32	R/W	
61024-61025		Timer #1 Setup		0.001 s/c	UINT32	R/W	
61026-61027		Timer #2 Setup		0.001 s/c	UINT32	R/W	
		...					
61040-61041		Timer #9 Setup		0.001s/c	UINT32	R/W	
61042-61043		Timer #10 Setup (factory preset)	-500 (half-cycle)	0.001cyc	UINT32	R	
61044-61045		Timer #11 Setup (factory preset)	-1000 (one cycle)	0.001cyc	UINT32	R	
61046-61047		Timer #12 Setup (factory preset)	200 (200 ms = 10/12 cycles)	0.001 s	UINT32	R	
61048-61049		Timer #13 Setup (factory preset)	3000 (3 sec = 150/180 cycles)	0.001 s	UINT32	R	
61050-61051		Timer #14 Setup (factory preset)	10000 (10 sec)	0.001 s	UINT32	R	
61052-61053		Timer #15 Setup (factory preset)	600000 (10 min)	0.001 s	UINT32	R	
61054-61055		Timer #16 Setup (factory preset)	7200000 (2 hours)	0.001 s	UINT32	R	
61056-61087		Reserved					
Energy Pulse Source Setup							
61088-61215							
+0		Energy pulse source ID	F15		UINT16	R/W	
+1		Not used	0		UINT16	R/W	
+2,3		Units per pulse	1-10000		UINT32	R/W	
61088-61091		Pulse Source #1					
61092-61095		Pulse Source #2					
		...					
61212-61215		Pulse Source #32					
Counters Setup							
61216-61471							
+0,1		Roll over value	1-1,000,000,000		UINT32	R/W	
+2,3		Reset value	0 - +/-999,999,999		INT32	R/W	
61216-61219		Counter #1 Setup					
61220-61223		Counter #2 Setup					
		...					
61340-61343		Counter #32 Setup					
61344-61471		Reserved					

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
Counter Source Setup							
61472-61727							
+0		Pulse source ID	F16		UINT16	R/W	
+1		Target counter number	0-31		UINT16	R/W	
+2,3		Multiplier	+/-1-10000		INT32	R/W	
61472-61475		Counter Source #1					
61476-61479		Counter Source #2					
		...					
61724-61727		Counter Source #64					
Digital Inputs Setup DI1-DI64							
61728-61983							
+0		Pulse mode	0 = pulse, 1 = KYZ		UINT16	R/W	
+1		Polarity	Bit 0 – pulse polarity: 0=normal, 1=inverting Bit 1 – input polarity: 0=normal, 1=inverting		UINT16	R/W	
+2		De-bounce time, ms	1-1000		UINT16	R/W	Note 3
+3		Flags	Bit 0 – SOE Log: 0=disabled, 1=enabled; Bit 1 – Fault Log: 0=disabled, 1=enabled;		UINT16	R/W	
61728-61731		DI1 Setup					
61732-61735		DI2 Setup					
		...					
61980-61983		DI64 Setup					
Digital Inputs Setup DI65-DI128							
62752-63007							
62752-62575		DI65 Setup					
62756-62759		DI66 Setup					
		...					
63003-63007		DI128 Setup					
Relay Outputs Setup							
61984-62367							
+0		Operation Mode	0 = unlatched, 1 = latched, 2 = pulse, 3 = KYZ		UINT16	R/W	
+1		Flags	Bit 0 – polarity: 0 = normal, 1 = inverting Bit 2 – blocking: 0 = unblocked relay, 1= blocked relay		UINT16	R/W	A blocked relay can only be unblocked by the "unblock relay" setpoint command
+2		Pulse width, ms	1-3000		UINT16	R/W	
+3		Pulse source ID	F17		UINT16	R/W	
+4		Retentive mode	0 = disabled, 1 = enabled		UINT16	R/W	
+5		SOE log on output change enabled	0 = disabled, 1 = enabled		UINT16	R/W	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
61984-61989		RO1 Setup					
61990-61995		RO2 Setup					
		...					
62362-62367		RO64 Setup					
Analog Inputs Setup							
62368-62559							
+0		Input parameter ID	0 = input not assigned		UINT16	R/W	
+1		Not used	0		UINT16	R/W	
+2,3		Zero scale value (0/4 mA, 0V)			INT32	R/W	
+4,5		Full scale value (1/20/50 mA, 10V)			INT32	R/W	
62368-62373		AI1 Setup					
62374-62379		AI2 Setup					
		...					
62458-62463		AI16 Setup					
62464-62559		Reserved					
Analog Outputs Setup							
62560-62751							
+0		Output parameter ID	F18		UINT16	R/W	
+1		Not used	0		UINT16	R/W	
+2,3		Zero scale value (0/4 mA)			INT32	R/W	
+4,5		Full scale value (20/1 mA)			INT32	R/W	
62560-62565		AO1 Setup					
62566-62571		AO2 Setup					
		...					
62650-62655		AO16 Setup					
62656-62751		Reserved					

3.8 Expansion I/O Slots Configuration

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
Expansion I/O Slots Configuration Info							
63008-63055		Expansion I/O Slots Configuration Info					
+0		I/O module type	Bitmap		UINT16	R	Note 2
+1		Number of I/Os on the slot	0-32		UINT16	R	
+2		First I/O number on the slot	0-79		UINT16	R	Note 1
+3		Last I/O number on the slot	0-95		UINT16	R	Note 1
63008-63011		I/O Slot #1 Configuration					
63012-63015		I/O Slot #2 Configuration					
63016-63019		I/O Slot #3 Configuration					
63020-63023		I/O Slot #4 Configuration					
63024-63027		I/O Slot #5 Configuration					
63028-63055		Reserved					
Expansion I/O Modules Type Info							
63056-63119		Expansion I/O Modules Type Info					
+0		Number of I/O modules of this type	0-5		UINT16	R	
+1		Total number of I/O's of this type	0-96		UINT16	R	
+2		Not used			UINT16	R	
+3		Not used	0		UINT16	R	
63056-63059		DI Module Type Info					
63060-63063		RO Module Type Info					
63064-63067		AI Module Type Info					
63068-63071		AO Module Type Info					
63072-63075		XM Module Type Info					
63076-63119		Reserved					

NOTES:

1. I/O numbers of expansion I/O modules are automatically assigned in the order of connection. The connection order is counted for each I/O module type separately. If the I/O module position is changed but its order in the chain of the modules of the same type is preserved, then all I/Os on the module will retain their I/O numbers. On the dual AI/AO module, both AI and AO will have same logical I/O range.

2. The type of a module in the corresponding slot position, number of I/Os on the module and their I/O numbers can be read through the I/O Slots Configuration Info registers. I/O module type register contains bit-mapped information on the module type and its options in bits D7:D0 as shown in the Table below.

I/O Module Type

Module	Option	D7	D6	D5	D4	D3	D2	D1	D0
DI (16DI)	DRY	0	0	0	0	0	0	0	0
DI (16DI)	WET 24V	0	0	0	0	0	0	0	1
DI (16DI)	WET 48V	0	0	0	0	0	0	1	0
DI (16DI)	WET 125V	0	0	0	0	0	0	1	1
DI (32DI)	DRY	0	0	0	1	0	0	0	0
DI (32DI)	WET 24V	0	0	0	1	0	0	0	1
DI (32DI)	WET 48V	0	0	0	1	0	0	1	0
DI (32DI)	WET 125V	0	0	0	1	0	0	1	1
DI (32DI)	WET 250V	0	0	0	1	0	1	0	0
RO (8RO)		0	0	1	0	0	0	0	0
RO (16RO)		1	0	1	0	0	0	0	0
RO (8RO)		1	0	1	1	0	0	0	0
AI (4AI/4AO)	±1 mA	0	1	0	0	×	×	0	0
AI (4AI/4AO)	0-20 mA	0	1	0	0	×	×	0	1
AI (4AI/4AO)	4-20 mA	0	1	0	0	×	×	1	0
AI (4AI/4AO)	0-1 mA	0	1	0	0	×	×	1	1
AI (8AI)	0-50 mA	0	1	0	1	0	1	0	0
AI (8AI)	±10 V	0	1	0	1	0	1	0	1
AO (4AI/4AO)	±1 mA	0	1	0	0	0	0	×	×
AO (4AI/4AO)	0-20 mA	0	1	0	0	0	1	×	×
AO (4AI/4AO)	4-20 mA	0	1	0	0	1	0	×	×
AO (4AI/4AO)	0-1 mA	0	1	0	0	1	1	×	×
XM	64MB	1	0	0	0	0	0	0	0
XM	128MB	1	0	0	0	0	0	0	1
Empty slot		1	1	1	1	1	1	1	1

× = don't care

3. The same de-bounce time is used for each group of eight adjacent digital inputs. To assign de-bounce time for a group, write the desired value into the setup register for the first DI in the group, e.g., DI1, DI9, DI17 and so on. The device will assign this value to the following seven inputs automatically. Any attempt to change de-bounce time for an input that is not the first in the group will be ignored. No error will occur.

3.9 File Transfer Blocks

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
File Transfer Control Blocks							
63120-63151		File Request Block					
+0		File function	1 = ACK - acknowledgement 3 = set file position 5 = reset file position 7 = find 11 = read file 127 = erase file		UINT16	R/W	1 - clears the file transfer block 3 - changes the file position 5 - sets the file position at the first (oldest) record 7 - finds a record matching an event or/and time (see Note 3) 11 - opens the file for reading from the present file position
+1		File ID	F2		UINT16	R/W	
+2		Section number (functions 3, 5, 11)	0-31, 0xFFFF = use channel ID		UINT16	R/W	
+3		Section channel ID (functions 3, 5, 11)	F6, F7		UINT16	R/W	
+4		Record sequence number (functions 3, 11)	0-65535		UINT16	R/W	The record sequence number with function 11 does not change the file position (see Note 2).
+5		Request variation (function 11)	0, 4		UINT16	R/W	See file response headings
+6		Find key: Event type	F22		UINT16	R/W	Note 3
+7		Find key: Event number	1 - 65535		UINT16	R/W	Note 3
+8, 9		Find key: Start time, seconds since 1/1/1970	F1	sec	UINT32	R/W	Note 3
+10, 11		Find key: Start time, fractional seconds in µsec		µsec	UINT32	R/W	Note 3
+12, 13		Find key: End time, seconds since 1/1/1970	F1	sec	UINT32	R/W	Note 3
+14, 15		Find key: End time, fractional seconds in µsec		µsec	UINT32	R/W	Note 3
+16-31		Reserved			UINT16	R/W	
63152-64943		File Response Block					
		Data transfer area [0 - 1791]			UINT16	R	
64944-64951		File Info Request Block					
+0		File function	9 = read file info		UINT16	R/W	
+1		File ID	F2		UINT16	R/W	
+2		Section number	0-31, 0xFFFF = use channel ID		UINT16	R/W	
+3		Section channel ID	F6, F7		UINT16	R/W	
+4		Not used	0		UINT16	R/W	
+5		Request variation	0, 1, 2		UINT16	R/W	
+6-7		Reserved			UINT16	R/W	
64952-65151		File Info Response Block					
		Data transfer area [0 - 199]			UINT16	R	

NOTES:

1. File sections for partitioned (multi-section) files, such as TOU profile log files and waveform log files, can be requested either by a section number, or by a section channel ID. If a section number is set to 0xFFFF, the section channel ID will be used to identify the section. The section number will be returned in the response block. If a section number is written, then the corresponding channel ID will be returned in the file response block.
2. The record sequence number with function 11 (Read-File) does not change the file position and is used only as a reference to track the order of records. The file transfer block will continue to hold the same data until it is acknowledged, or until the file position is explicitly moved to another record. For multi-section Waveform files that use a single read pointer for all file sections, the Read-File request, which addresses a different file section, will refill the transfer block with data of the record from the requested file section with the identical sequence number. After acknowledgment, the file position will be moved to the next record.
3. Function 7 (Find) puts into the file request block the sequence number of the first record in the file that matches the event or/and the time. If the file ID is set to 0xFFFF, the device will search for the desired record in the waveform file that is preset by default for the fault and power quality recorders or a setpoint, depending on the event type. The file ID where a record is found is returned in the file response block header. Any one of the find keys can be omitted by setting it to 0. If one or a number of find keys are omitted, the device will use the remaining keys to locate the matching record. If the record could not be found, the device responds to the write request with the exception code 3 (illegal data). The status of the operation can be read through the file status word in the file info block.

File Response Blocks

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
File Info Response Block (Variation 0 – File info)							
64952-64959		Block Heading					
+0		File function	9		UINT16	R	
+1		File ID	F2		UINT16	R	
+2		Section number	0-31		UINT16	R	
+3		Section channel ID	F6, F7		UINT16	R	
+4		Number of records in the block	1		UINT16	R	
+5		Record size, words	36		UINT16	R	
+6		Request variation	0		UINT16	R	
+7		Reserved	0		UINT16	R	
64960-64997		File Info					
+0		File type	0		UINT16	R	
+1		File attributes	F3		UINT16	R	
+2		File (section) status	F4		UINT16	R	
+3		Number of sections in the file	0-32		UINT16	R	0 = non-partitioned file
+4, 5		File channel mask (channels 1-32), bitmap	F8, F9		UINT32	R	
+6, 7		File channel mask (channels 33-64), bitmap	F8, F9		UINT32	R	
+8		Number of records in the file	0-65535		UINT16	R	
+9		Number of records until the end of the file	0-65535		UINT16	R	
+10		Current record (read position) sequence number	0-65535		UINT16	R	
+11		Current write position sequence number	0-65535		UINT16	R	
+12		First (oldest) record sequence number	0-65535		UINT16	R	
+13		Last (newest) record sequence number	0-65535		UINT16	R	
+14, 15		Last record time, seconds since 1/1/1970	F1	sec	UINT32	R	
+16, 17		Last record time, fractional seconds		µsec	UINT32	R	
+18, 19		First record time, seconds since 1/1/1970	F1	sec	UINT32	R	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+20, 21		First record time, fractional seconds		µsec	UINT32	R	
+22, 23		Creation time, seconds since 1/1/1970	F1	sec	UINT32	R	
+24, 25		Creation time, fractional seconds		µsec	UINT32	R	
+26, 27		Reset time, seconds since 1/1/1970	F1	sec	UINT32	R	
+28, 29		Reset time, fractional seconds		µsec	UINT32	R	
+30		Maximum number of records	0-65535		UINT16	R	
+31		Number of parameters per data section record	0-52		UINT16	R	
+32		Section record size, bytes		Byte	UINT16	R	
+33		File record size, bytes		Byte	UINT16	R	
+34, 35		Allocated file size, bytes		Byte	UINT32	R	
File Info Response Block (Variation 1 – Current record info)							
64952-64959		Block Heading					
+0		File function	9		UINT16	R	
+1		File ID	F2		UINT16	R	
+2		Section number	0-31		UINT16	R	
+3		Section channel ID	F6, F7		UINT16	R	
+4		Number of records in the block	1		UINT16	R	
+5		Record size, words	8		UINT16	R	
+6		Request variation	1		UINT16	R	
+7		Reserved	0		UINT16	R	
64960-64997		File Info					
+0		File (section) status	F4		UINT16	R	
+1		Number of records in the file	0-65535		UINT16	R	
+2		Number of records until the end of the file	0-65535		UINT16	R	
+3		Current record (read position) sequence number	0-65535		UINT16	R	
+4, 5		Current record time, seconds since 1/1/1970	F1	sec	UINT32	R	
+6, 7		Current record time, fractional seconds		µsec	UINT32	R	
File Info Response Block (Variation 2 – Data log record structure)							
64952-64959		Block Heading					
+0		File function	9		UINT16	R	
+1		File ID	1-16		UINT16	R	
+2		Section number	0-15		UINT16	R	
+3		Section channel ID	F6, F7		UINT16	R	
+4		Number of records in the block	1		UINT16	R	
+5		Record size, words	2 + Number of parameters		UINT16	R	
+6		Request variation	2		UINT16	R	
+7		Reserved	0		UINT16	R	
64960-64997		File Info					
+0		Not used	0		UINT16	R	
+1		Number of fields in a data record	1-16 (34 for EN50160 Statistics log, 52 for EN50160 Harmonics Survey)		UINT16	R	
+2		Field 1 parameter ID	0-0xFFFF		UINT16	R	
+3		Field 2 parameter ID	0-0xFFFF		UINT16	R	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
...		...					
Event Log Response Block							
63152-63159		Block Heading					
+0		Last file function	1, 3, 5, 11		UINT16	R	
+1		File ID	0		UINT16	R	
+2		Section number	0		UINT16	R	
+3		Section channel ID	0		UINT16	R	
+4		Number of records in the block	1-32		UINT16	R	
+5		Record size, words	12		UINT16	R	
+6		Request variation	0		UINT16	R	
+7		Reserved	0		UINT16	R	
63160-63543		Event Log Records					
+0		Record status	F5		INT16	R	
+1		Record sequence number	0-65535		UINT16	R	
+2, 3		Trigger time, seconds since 1/1/1970	F1	sec	UINT32	R	
+4, 5		Trigger time, fractional seconds in μ sec		μ sec	UINT32	R	
+6		Event number	1-65535		UINT16	R	
+7		Event point/source ID	F19		UINT16	R	
+8		Event effect	F20		UINT16	R	
+9		Reserved	0		UINT16	R	
+10, 11		Value triggered			INT32	R	
63160-63171		Record #1					
		...					
63532-63543		Record #32					
Data Log Response Block							
63152-63159		Block Heading					
+0		Last file function	1, 3, 5, 11		UINT16	R	
+1		File ID	1-16 (F2)		UINT16	R	
+2		Section number	0-31		UINT16	R	
+3		Section channel ID	F6		UINT16	R	
+4		Number of records in the block	1-32		UINT16	R	
+5		Record size, words	8 + 2×Number of parameters		UINT16	R	
+6		Request variation	0 = regular log, 4 = EN50160 online statistics (with file ID = 9, 10)		UINT16	R	
+7		Reserved	0		UINT16	R	
63160-64439		Data Log Records					
+0		Record status	F5		INT16	R	
+1		Record sequence number	0-65535		UINT16	R	
+2, 3		Record time, seconds since 1/1/1970	F1	sec	UINT32	R	
+4, 5		Record time, fractional seconds in μ sec		μ sec	UINT32	R	
+6		Trigger event type	F22		INT16	R	
+7		Trigger event number	1-65535		UINT16	R	
+8, 9		Log value #1			INT32	R	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+10, 11		Log value #2			INT32	R	
...		...				R	
63160-...		Record #1 (variable length)					
...		...					
		Record #32 (variable length)					
Waveform Log Response Block							
63152-63159		Block Heading					
+0		Last file function	1, 3, 5, 11		UINT16	R	
+1		File ID	17-24, 128 (F2)		UINT16	R	
+2		Section number	0-9 (0-25 for V10.6.XX)		UINT16	R	
+3		Section channel ID	F7		UINT16	R	
+4		Number of records in the block	1		UINT16	R	
+5		Record size, words	640		UINT16	R	
+6		Request variation	0		UINT16	R	
+7		Reserved	0		UINT16	R	
63160-63799		Waveform Log Record					
+0		Record status	F5		INT16	R	
+1		Record sequence number	0 - 65535		UINT16	R	
+2, 3		Start time, seconds since 1/1/1970	F1	sec	UINT32	R	
+4, 5		Start time, fractional seconds		µsec	UINT32	R	
+6, 7		Trigger time, seconds since 1/1/1970	F1	sec	UINT32	R	
+8, 9		Trigger time, fractional seconds		µsec	UINT32	R	
+10		Record series number	1-65535		UINT16	R	
+11		Record serial number in a series	0-65535		UINT16	R	
+12		Trigger event type	F22		UINT16	R	
+13		Trigger event number	1-65535		UINT16	R	
+14		Source point ID (generic)	See Generic Data in Section 3.4		UINT16	R	
+15		Trigger reference sample index	0-511		UINT16	R	
+16		Sampling rate, µsec/sample	600-27000	×0.1µsec	UINT16	R	For VDC channel, ×1µsec
+17		Sampling rate, samples/cycle	16, 32, 64, 128		UINT16	R	
+18		Sampling frequency	4500-6500	×0.01Hz	UINT16	R	
+19		Channel offset, sampling units	+/-32767		INT16	R	
+20, 21		Channel multiplier, primary units	See Generic Data in Section 3.4		UINT32	R	
+22		Channel divisor, sampling units	2147-8191		UINT16	R	
+23		Length of a sample series, data points	64-512		UINT16	R	
+24-127		Not used	0		UINT16	R	
+128		Sample Series					
+128-639		Sample data series points [0...511]	+/-8191		INT16	R	¹
Sequence of Events (SOE) Log Response Block							
63152-63159		Block Heading					
+0		Last file function	1, 3, 5, 11		UINT16	R	
+1		File ID	25		UINT16	R	
+2		Section number	0		UINT16	R	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
+3		Section channel ID	0		UINT16	R	
+4		Number of records in the block	1-32		UINT16	R	
+5		Record size, words	10		UINT16	R	
+6		Request variation	0		UINT16	R	
+7		Reserved	0		UINT16	R	
63160-63479		SOE Log Records					
+0		Record status	F5		INT16	R	
+1		Record sequence number	0-65535		UINT16	R	
+2, 3		Trigger time, seconds since 1/1/1970	F1	sec	UINT32	R	
+4, 5		Trigger time, fractional seconds in μ sec		μ sec	UINT32	R	
+6		Fault event type	F22		UINT16	R	
+7		Fault event number	1-65535		UINT16	R	
+8		Fault source point status	0 = Open/Off, 1 = Closed/On		UINT16	R	
+9		GPS clock sync status	0 = time unlocked, 1 = time locked		UINT16	R	
63160-63169		Record #1					
		...					
63470-63479		Record #32					
Power Quality (PQ) Log Response Block							
63152-63159		Block Heading					
+0		Last file function	1, 3, 5, 11		UINT16	R	
+1		File ID	26		UINT16	R	
+2		Section number	0		UINT16	R	
+3		Section channel ID	0		UINT16	R	
+4		Number of records in the block	1 -32		UINT16	R	
+5		Record size, words	18		UINT16	R	
+6		Request variation	0		UINT16	R	
+7		Reserved	0		UINT16	R	
63160-63799		PQ Log Records					
+0		Record status	F5		INT16	R	
+1		Record sequence number	0-65535		UINT16	R	
+2, 3		Start time, seconds since 1/1/1970	F1	sec	UINT32	R	
+4, 5		Start time, fractional seconds in μ sec		μ sec	UINT32	R	
+6, 7		End time, seconds since 1/1/1970	F1	sec	UINT32	R	
+8, 9		End time, fractional seconds in μ sec		μ sec	UINT32	R	
+10		PQ event type	F22		UINT16	R	
+11		PQ event number	1-65535		UINT16	R	
+12		Point ID (generic)	See Generic Data in Section 3.4		UINT16	R	
+13		Reserved	0		UINT16	R	
+14, 15		Value reference (base), primary units	See Generic Data in Section 3.4		INT32	R	
+16, 17		Value magnitude, primary units	See Generic Data in Section 3.4		INT32	R	

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
63160-63179		Record #1					
		...					
63780-63799		Record #32					
Fault Log Response Block							
63152-63159		Block Heading					
+0		Last file function	1, 3, 5, 11		UINT16	R	
+1		File ID	27		UINT16	R	
+2		Section number	0		UINT16	R	
+3		Section channel ID	0		UINT16	R	
+4		Number of records in the block	1-32		UINT16	R	
+5		Record size, words	22		UINT16	R	
+6		Request variation	0		UINT16	R	
+7		Reserved	0		UINT16	R	
63160-64183		Fault Log Records					
+0		Record status	F5		INT16	R	
+1		Record sequence number	0-65535		UINT16	R	
+2, 3		Start time, seconds since 1/1/1970	F1	sec	UINT32	R	
+4, 5		Start time, fractional seconds in μ sec		μ sec	UINT32	R	
+6, 7		End time, seconds since 1/1/1970	F1	sec	UINT32	R	
+8, 9		End time, fractional seconds in μ sec		μ sec	UINT32	R	
+10		Fault event type	F22		UINT16	R	
+11		Fault event number	1-65535		UINT16	R	
+12		Current phase point ID (generic)	0-65535		UINT16	R	
+13		Volts phase point ID (generic)	0-65535		UINT16	R	
+14, 15		Current reference (base), primary units	See Generic Data in Section 3.4	U2	INT32	R	
+16, 17		Current magnitude, primary units	See Generic Data in Section 3.4	U2	INT32	R	
+18, 19		Volts reference (base), primary units	See Generic Data in Section 3.4	U1	INT32	R	
+20, 21		Volts magnitude, primary units	See Generic Data in Section 3.4	U1	INT32	R	
63160-63191		Record #1					
		...					
64152-64183		Record #32					

¹ To restore the original sampled data in the channel units (e.g., Volts, Amps), the following conversion should be applied:

$$\text{Sampled Data [primary units]} = \frac{(\text{Data Sample} - \text{Channel Offset}) \times \text{Channel Multiplier}}{\text{Channel Divisor}}$$

File Response Block Alias

Address	Point ID	Description	Options/Range	Units	Type	R/W	Notes
File Response Block Alias							
3072-3079		Block Heading					
+0		File function	11		UINT16	R	
+1		File ID	0, 25, 26, 27		UINT16	R/W	
+2		Section number	0		UINT16	R	
+3		Section channel ID	0		UINT16	R	
+4		Number of records in the block	1 - 10		UINT16	R/W	Write: sets the block size
+5		Record size, words	18		UINT16	R	
+6		Request variation	0		UINT16	R	
+7		Reserved	0		UINT16	R	
3080-3583		Last 1-10 file records					
Power Quality (PQ) Log Response Block Alias							
3072-3079		Block Heading					
+0		File function	11		UINT16	R	
+1		File ID	26		UINT16	R/W	
+2		Section number	0		UINT16	R	
+3		Section channel ID	0		UINT16	R	
+4		Number of records in the block	1 - 10		UINT16	R/W	Write: sets the block size
+5		Record size, words	18		UINT16	R	
+6		Request variation	0		UINT16	R	
+7		Reserved	0		UINT16	R	
3080-3259		PQ Log Records					
+0		Record status	F5		INT16	R	
+1		Record sequence number	0 - 65535		UINT16	R	
+2, 3		Start time, seconds since 1/1/1970	F1	sec	UINT32	R	
+4, 5		Start time, fractional seconds in μ sec		μ sec	UINT32	R	
+6, 7		End time, seconds since 1/1/1970	F1	sec	UINT32	R	
+8, 9		End time, fractional seconds in μ sec		μ sec	UINT32	R	
+10		PQ event type	F22		UINT16	R	
+11		PQ event number	1 - 65535		UINT16	R	
+12		Point ID (generic)	See Generic Data in Section 3.4		UINT16	R	
+13		Reserved	0		UINT16	R	
+14, 15		Value reference (base), primary units	See Generic Data in Section 3.4		INT32	R	
+16, 17		Value magnitude, primary units	See Generic Data in Section 3.4		INT32	R	
3080-3097		Record #1					
		...					
3242-3259		Record #10					

The block of registers 3072-3583 is the alias for the common file response block. It is intended for continuous polling of the last 1 to 10 records of the event files (Event Log, SOE Log, PQ Log or Fault Log) from SCADA systems. The alias block is preset at factory to provide access to the last ten PQ Log records. You can change factory assignments to point to another log file or change the number of the records in the transfer block by re-writing of the corresponding registers in the block heading. To update records in the alias block, at least one of the block heading registers 3072-3079 must be read first.

NOTES:

1. Registers 3080-3259 share the same data transfer buffer as the common file transfer block registers 63152-64943. Reading data from the common transfer block within the same connection session can destroy data in the alias transfer block. To guarantee that the alias block contains correct data, always read block heading registers 3072-3079 before accessing data records in the alias block.
2. If you read the block through a TCP connection and change a file ID or the number of records in the block, your assignments for the transfer block will be effective only within the current connection socket. Since the device cannot guarantee that your next connection will be made through the same socket, you should not make any assumptions regarding the present block settings. When you open a new connection, always check the block heading before accessing data records.

3.10 EN 50160 Compliance Statistics Data Log

File Section	Record Field No.	Point Label	Point ID	Description ¹	Range ²	Units ²	Type	Notes
0				Power Frequency				
	1	Nnv	0x5A00	Number of non-valid 10-sec intervals			UINT32	
	2	N	0x5A01	Number of valid 10-sec intervals			UINT32	
	3	N1	0x5A02	Number of incidents $\pm 1\%$, N1			UINT32	
	4	N2	0x5A03	Number of incidents $+4\%/-6\%$, N2			UINT32	
	5	N1/N, %	0x5A04	EN50160 compliance ratio, N1/N		0.01%	UINT32	
	6	N2/N, %	0x5A05	EN50160 compliance ratio, N2/N		0.01%	UINT32	
	7	Freq Min	0x5A06	Minimum frequency		0.01Hz	UINT32	
1	8	Freq Max	0x5A07	Maximum frequency		0.01Hz	UINT32	
				Supply Voltage Variations				
	1	Nnv	0x5A80	Number of non-valid 10-min intervals			UINT32	
	2	N	0x5A81	Number of valid 10-min intervals			UINT32	
	3	N1	0x5A82	Number of polyphase incidents $\pm 10\%$, N1			UINT32	
	4	N2	0x5A83	Number of polyphase incidents $+10\%/-15\%$, N2			UINT32	
	5	N1/N, %	0x5A84	EN50160 compliance ratio, N1/N		0.01%	UINT32	
	6	N2/N, %	0x5A85	EN50160 compliance ratio, N2/N		0.01%	UINT32	
	7	V1 N1	0x5A86	Number of incidents $\pm 10\%$ on phase V1			UINT32	
	8	V1 Min	0x5A87	Minimum voltage on phase V1		U1	UINT32	
	9	V1 Max	0x5A88	Maximum voltage on phase V1		U1	UINT32	
	10	V2 N1	0x5A89	Number of incidents $\pm 10\%$ on phase V2			UINT32	
	11	V2 Min	0x5A8A	Minimum voltage on phase V2		U1	UINT32	
	12	V2 Max	0x5A8B	Maximum voltage on phase V2		U1	UINT32	
	13	V3 N1	0x5A8C	Number of incidents $\pm 10\%$ on phase V3			UINT32	
14	V3 Min	0x5A8D	Minimum voltage on phase V3		U1	UINT32		
15	V3 Max	0x5A8E	Maximum voltage on phase V3		U1	UINT32		
2				Rapid Voltage Changes				
	1	N1	0x5B00	Number of polyphase incidents			UINT32	
	2	V1 N1	0x5B01	Number of incidents on phase V1			UINT32	
	3	V1 dV%	0x5B02	Maximum voltage variation on phase V1, dV/Un%		0.01%	UINT32	
	4	V2 N1	0x5B03	Number of incidents on phase V2			UINT32	
	5	V2 dV%	0x5B04	Maximum voltage variation on phase V2, dV/Un%		0.01%	UINT32	
	6	V3 N1	0x5B05	Number of incidents on phase V3			UINT32	
7	V3 dV%	0x5B06	Maximum voltage variation on phase V3, dV/Un%		0.01%	UINT32		
3				Flicker				
	1	Nnv	0x5B80	Number of non-valid 2-hour intervals			UINT32	
	2	N	0x5B81	Number of valid 2-hour intervals			UINT32	
	3	N1	0x5B82	Number of polyphase incidents PIt $> 1\%$, N1			UINT32	

File Section	Record Field No.	Point Label	Point ID	Description ¹	Range ²	Units ²	Type	Notes
	4	N1/N, %	0x5B83	EN50160 compliance ratio, N1/N		0.01%	UINT32	
	5	V1 N1	0x5B84	Number of incidents Plt > 1% on phase V1			UINT32	
	6	V1 Plt Max	0x5B85	Maximum Plt on phase V2		0.01	UINT32	
	7	V2 N1	0x5B86	Number of incidents Plt > 1% on phase V2			UINT32	
	8	V2 Plt Max	0x5B87	Maximum Plt on phase V2		0.01	UINT32	
	9	V3 N1	0x5B88	Number of incidents Plt > 1% on phase V3			UINT32	
	10	V3 Plt Max	0x5B89	Maximum Plt on phase V3		0.01	UINT32	
4				Voltage Dips (indicative statistics)				
	1	N11 90%/100ms	0x5C00	Number of polyphase incidents u<90%/t<100ms			UINT32	
	2	N12 85%/100ms	0x5C01	Number of polyphase incidents u<85%/t<100ms			UINT32	
	3	N13 70%/100ms	0x5C02	Number of polyphase incidents u<70%/t<100ms			UINT32	
	4	N14 40%/100ms	0x5C03	Number of polyphase incidents u<40%/t<100ms			UINT32	
	5	N11 90%/500ms	0x5C04	Number of polyphase incidents u<90%/t<500ms			UINT32	
	6	N12 85%/500ms	0x5C05	Number of polyphase incidents u<85%/t<500ms			UINT32	
	7	N13 70%/500ms	0x5C06	Number of polyphase incidents u<70%/t<500ms			UINT32	
	8	N14 40%/500ms	0x5C07	Number of polyphase incidents u<40%/t<500ms			UINT32	
	9	N11 90%/1s	0x5C08	Number of polyphase incidents u<90%/t<1s			UINT32	
	10	N12 85%/1s	0x5C09	Number of polyphase incidents u<85%/t<1s			UINT32	
	11	N13 70%/1s	0x5C0A	Number of polyphase incidents u<70%/t<1s			UINT32	
	12	N14 40%/1s	0x5C0B	Number of polyphase incidents u<40%/t<1s			UINT32	
	13	N11 90%/3s	0x5C0C	Number of polyphase incidents u<90%/t<3s			UINT32	
	14	N12 85%/3s	0x5C0D	Number of polyphase incidents u<85%/t<3s			UINT32	
	15	N13 70%/3s	0x5C0E	Number of polyphase incidents u<70%/t<3s			UINT32	
	16	N14 40%/3s	0x5C0F	Number of polyphase incidents u<40%/t<3s			UINT32	
	17	N11 90%/20s	0x5C10	Number of polyphase incidents u<90%/t<20s			UINT32	
	18	N12 85%/20s	0x5C11	Number of polyphase incidents u<85%/t<20s			UINT32	
	19	N13 70%/20s	0x5C12	Number of polyphase incidents u<70%/t<20s			UINT32	
	20	N14 40%/20s	0x5C13	Number of polyphase incidents u<40%/t<20s			UINT32	
	21	N11 90%/60s	0x5C14	Number of polyphase incidents u<90%/t<60s			UINT32	
	22	N12 85%/60s	0x5C15	Number of polyphase incidents u<85%/t<60s			UINT32	
	23	N13 70%/60s	0x5C16	Number of polyphase incidents u<70%/t<60s			UINT32	
	24	N14 40%/60s	0x5C17	Number of polyphase incidents u<40%/t<60s			UINT32	
	25	N11 90%/180s	0x5C18	Number of polyphase incidents u<90%/t<180s			UINT32	
	26	N12 85%/180s	0x5C19	Number of polyphase incidents u<85%/t<180s			UINT32	
	27	N13 70%/180s	0x5C1A	Number of polyphase incidents u<70%/t<180s			UINT32	
	28	N14 40%/180s	0x5C1B	Number of polyphase incidents u<40%/t<180s			UINT32	
	29	V1 N1	0x5C1C	Total number of incidents on phase V1			UINT32	
	30	V1 Min	0x5C1D	Minimum residual voltage on phase V1		U1	UINT32	
	31	V2 N1	0x5C1E	Total number of incidents on phase V2			UINT32	
	32	V2 Min	0x5C1F	Minimum residual voltage on phase V2		U1	UINT32	
	33	V3 N1	0x5C20	Total number of incidents on phase V3			UINT32	
	34	V3 Min	0x5C21	Minimum residual voltage on phase V3		U1	UINT32	

File Section	Record Field No.	Point Label	Point ID	Description ¹	Range ²	Units ²	Type	Notes
5				Voltage Interruptions (indicative statistics)				
	1	N1 1s	0x5D00	Number of polyphase incidents <1s			UINT32	
	2	N2 180s	0x5D01	Number of polyphase incidents <180s			UINT32	
	3	N3 >180s	0x5D02	Number of polyphase incidents >180s			UINT32	
	4	V1 Min	0x5D03	Minimum residual voltage on phase V1		U1	UINT32	
	5	V2 Min	0x5D04	Minimum residual voltage on phase V2		U1	UINT32	
	6	V3 Min	0x5D05	Minimum residual voltage on phase V3		U1	UINT32	
6				Temporary Overvoltages (indicative statistics)				
	1	N11 110%/1s	0x5D80	Number of polyphase incidents u>110%/t<1s			UINT32	
	2	N12 120%/1s	0x5D81	Number of polyphase incidents u>120%/t<1s			UINT32	
	3	N13 140%/1s	0x5D82	Number of polyphase incidents u>140%/t<1s			UINT32	
	4	N14 160%/1s	0x5D83	Number of polyphase incidents u>160%/t<1s			UINT32	
	5	N15 200%/1s	0x5D84	Number of polyphase incidents u>200%/t<1s			UINT32	
	6	N21 110%/60s	0x5D85	Number of polyphase incidents u>110%/t<60s			UINT32	
	7	N22 120%/60s	0x5D86	Number of polyphase incidents u>120%/t<60s			UINT32	
	8	N23 140%/60s	0x5D87	Number of polyphase incidents u>140%/t<60s			UINT32	
	9	N24 160%/60s	0x5D88	Number of polyphase incidents u>160%/t<60s			UINT32	
	10	N25 200%/60s	0x5D89	Number of polyphase incidents u>200%/t<60s			UINT32	
	11	N31 110%/>60s	0x5D8A	Number of polyphase incidents u>110%/t>60s			UINT32	
	12	N32 120%/>60s	0x5D8B	Number of polyphase incidents u>120%/t>60s			UINT32	
	13	N33 140%/>60s	0x5D8C	Number of polyphase incidents u>140%/t>60s			UINT32	
	14	N34 160%/>60s	0x5D8D	Number of polyphase incidents u>160%/t>60s			UINT32	
	15	N35 200%/>60s	0x5D8E	Number of polyphase incidents u>200%/t>60s			UINT32	
	16	V1 N1	0x5D8F	Total number of incidents on phase V1			UINT32	
	17	V1 Max	0x5D90	Maximum voltage magnitude on phase V1		U1	UINT32	
	18	V2 N1	0x5D91	Total number of incidents on phase V2			UINT32	
	19	V2 Max	0x5D92	Maximum voltage magnitude on phase V2		U1	UINT32	
	20	V3 N1	0x5D93	Total number of incidents on phase V3			UINT32	
	21	V3 Max	0x5D94	Maximum voltage magnitude on phase V3		U1	UINT32	
7				Transient Overvoltages (peak voltage, indicative statistics)				
	1	N1 110%	0x5E00	Number of polyphase incidents u>120%			UINT32	
	2	N2 150%	0x5E01	Number of polyphase incidents u>150%			UINT32	
	3	N3 200%	0x5E02	Number of polyphase incidents u>200%			UINT32	
	4	N4 250%	0x5E03	Number of polyphase incidents u>250%			UINT32	
	5	N5 300%	0x5E04	Number of polyphase incidents u>300%			UINT32	
	6	V1 N1 110%	0x5E05	Number of incidents u>120% on phase V1			UINT32	
	7	V1 N2 150%	0x5E06	Number of incidents u>150% on phase V1			UINT32	
	8	V1 N3 200%	0x5E07	Number of incidents u>200% on phase V1			UINT32	
	9	V1 N4 250%	0x5E08	Number of incidents u>250% on phase V1			UINT32	
	10	V1 N5 300%	0x5E09	Number of incidents u>300% on phase V1			UINT32	
	11	V2 N1 110%	0x5E0A	Number of incidents u>120% on phase V2			UINT32	
	12	V2 N2 150%	0x5E0B	Number of incidents u>150% on phase V2			UINT32	

File Section	Record Field No.	Point Label	Point ID	Description ¹	Range ²	Units ²	Type	Notes
	13	V2 N3 200%	0x5E0C	Number of incidents u>200% on phase V2			UINT32	
	14	V2 N4 250%	0x5E0D	Number of incidents u>250% on phase V2			UINT32	
	15	V2 N5 300%	0x5E0E	Number of incidents u>300% on phase V2			UINT32	
	16	V3 N1 110%	0x5E0F	Number of incidents u>120% on phase V3			UINT32	
	17	V3 N2 150%	0x5E10	Number of incidents u>150% on phase V3			UINT32	
	18	V3 N3 200%	0x5E11	Number of incidents u>200% on phase V3			UINT32	
	19	V3 N4 250%	0x5E12	Number of incidents u>250% on phase V3			UINT32	
	20	V3 N5 300%	0x5E13	Number of incidents u>300% on phase V3			UINT32	
	21	V1 Peak Max	0x5E14	Maximum peak voltage on phase V1		U1	UINT32	
	22	V2 Peak Max	0x5E15	Maximum peak voltage on phase V2		U1	UINT32	
	23	V3 Peak Max	0x5E16	Maximum peak voltage on phase V3		U1	UINT32	
7				Transient Overvoltages (impulsive voltage, indicative statistics)				
	1	N1 110%	0x5E00	Number of polyphase incidents u>120%			UINT32	
	2	N2 150%	0x5E01	Number of polyphase incidents u>150%			UINT32	
	3	N3 200%	0x5E02	Number of polyphase incidents u>200%			UINT32	
	4	N4 250%	0x5E03	Number of polyphase incidents u>250%			UINT32	
	5	N5 300%	0x5E04	Number of polyphase incidents u>300%			UINT32	
	6	V1 N1 110%	0x5E05	Number of incidents u>120% on phase V1			UINT32	
	7	V1 N2 150%	0x5E06	Number of incidents u>150% on phase V1			UINT32	
	8	V1 N3 200%	0x5E07	Number of incidents u>200% on phase V1			UINT32	
	9	V1 N4 250%	0x5E08	Number of incidents u>250% on phase V1			UINT32	
	10	V1 N5 300%	0x5E09	Number of incidents u>300% on phase V1			UINT32	
	11	V2 N1 110%	0x5E0A	Number of incidents u>120% on phase V2			UINT32	
	12	V2 N2 150%	0x5E0B	Number of incidents u>150% on phase V2			UINT32	
	13	V2 N3 200%	0x5E0C	Number of incidents u>200% on phase V2			UINT32	
	14	V2 N4 250%	0x5E0D	Number of incidents u>250% on phase V2			UINT32	
	15	V2 N5 300%	0x5E0E	Number of incidents u>300% on phase V2			UINT32	
	16	V3 N1 110%	0x5E0F	Number of incidents u>120% on phase V3			UINT32	
	17	V3 N2 150%	0x5E10	Number of incidents u>150% on phase V3			UINT32	
	18	V3 N3 200%	0x5E11	Number of incidents u>200% on phase V3			UINT32	
	19	V3 N4 250%	0x5E12	Number of incidents u>250% on phase V3			UINT32	
	20	V3 N5 300%	0x5E13	Number of incidents u>300% on phase V3			UINT32	
	21	V1 imp max	0x5E14	Maximum impulsive voltage on phase V1		U1	UINT32	
	22	V2 imp max	0x5E15	Maximum impulsive voltage on phase V2		U1	UINT32	
	23	V3 imp max	0x5E16	Maximum impulsive voltage on phase V3		U1	UINT32	
8				Supply Voltage Unbalance				
	1	Nnv	0x5E80	Number of non-valid 10-min intervals			UINT32	
	2	N	0x5E81	Number of valid 10-min intervals			UINT32	
	3	N1	0x5E82	Number of incidents V Unb > 2%, N1			UINT32	
	4	N1/N, %	0x5E83	EN50160 compliance ratio, N1/N		0.01%	UINT32	
	5	V Unb% Max	0x5E84	Maximum voltage unbalance		0.1%	UINT32	

File Section	Record Field No.	Point Label	Point ID	Description ¹	Range ²	Units ²	Type	Notes
9				Harmonic Voltage				
	1	Nnv	0x5F00	Number of non-valid 10-min intervals			UINT32	
	2	N	0x5F01	Number of valid 10-min intervals			UINT32	
	3	N1	0x5F02	Number of polyphase harmonic voltage incidents, N1			UINT32	
	4	N2	0x5F03	Number of polyphase voltage THD incidents, N2			UINT32	
	5	N1/N, %	0x5F04	EN50160 harmonic voltage compliance ratio, N1/N		0.01%	UINT32	
	6	N2/N, %	0x5F05	EN50160 voltage THD compliance ratio, N2/N		0.01%	UINT32	
	7	V1 N1	0x5F06	Number of harmonic voltage incidents on phase V1			UINT32	
	8	V1 HD% Max	0x5F07	Worst-case harmonic magnitude on phase V1, %Un		0.01%	UINT32	
	9	V1 H#	0x5F08	Worst-case harmonic component number on phase V1	2-50		UINT32	
	10	V1 N2	0x5F09	Number of voltage THD incidents on phase V1			UINT32	
	11	V1 THD Max	0x5F0A	Worst-case voltage THD on phase V1		0.1%	UINT32	
	12	V2 N1	0x5F0B	Number of harmonic voltage incidents on phase V2			UINT32	
	13	V2 HD% Max	0x5F0C	Worst-case harmonic magnitude on phase V2, %Un		0.01%	UINT32	
	14	V2 H#	0x5F0D	Worst-case harmonic component number on phase V2	2-50		UINT32	
	15	V2 N2	0x5F0E	Number of voltage THD incidents on phase V2			UINT32	
	16	V2 THD Max	0x5F0F	Worst-case voltage THD on phase V2		0.1%	UINT32	
	17	V3 N1	0x5F10	Number of harmonic voltage incidents on phase V3			UINT32	
	18	V3 HD% Max	0x5F11	Worst-case harmonic magnitude on phase V3, %Un		0.01%	UINT32	
	19	V3 H#	0x5F12	Worst-case harmonic component number on phase V3	2-50		UINT32	
	20	V3 N2	0x5F13	Number of voltage THD incidents on phase V3			UINT32	
	21	V3 THD Max	0x5F14	Worst-case voltage THD on phase V3		0.1%	UINT32	
10				Interharmonic Voltage				
	1	Nnv	0x5F80	Number of non-valid 10-min intervals			UINT32	
	2	N	0x5F81	Number of valid 10-min intervals			UINT32	
	3	N1	0x5F82	Number of polyphase interharmonic voltage incidents, N1			UINT32	
	4	N2	0x5F83	Number of polyphase interharmonic THD incidents, N2			UINT32	
	5	N1/N, %	0x5F84	EN50160 interharmonic voltage compliance ratio, N1/N		0.01%	UINT32	
	6	N2/N, %	0x5F85	EN50160 interharmonic voltage THD compliance ratio, N2/N		0.01%	UINT32	
	7	V1 N1	0x5F86	Number of interharmonic voltage incidents on phase V1			UINT32	
	8	V1 HD% Max	0x5F87	Worst-case interharmonic magnitude on phase V1, %Un		0.01%	UINT32	
	9	V1 H#	0x5F88	Worst-case interharmonic component number on phase V1	2-50		UINT32	
	10	V1 N2	0x5F89	Number of interharmonic voltage THD incidents on phase V1			UINT32	
	11	V1 THD Max	0x5F8A	Worst-case interharmonic voltage THD on phase V1		0.1%	UINT32	
	12	V2 N1	0x5F8B	Number of interharmonic voltage incidents on phase V2			UINT32	
	13	V2 HD% Max	0x5F8C	Worst-case interharmonic magnitude on phase V2, %Un		0.01%	UINT32	
	14	V2 H#	0x5F8D	Worst-case interharmonic component number on phase V2	2-50		UINT32	
	15	V2 N2	0x5F8E	Number of interharmonic voltage THD incidents on phase V2			UINT32	
	16	V2 THD Max	0x5F8F	Worst-case interharmonic voltage THD on phase V2		0.1%	UINT32	
	17	V3 N1	0x5F90	Number of interharmonic voltage incidents on phase V3			UINT32	
	18	V3 HD% Max	0x5F91	Worst-case interharmonic magnitude on phase V3, %Un		0.01%	UINT32	
	19	V3 H#	0x5F92	Worst-case interharmonic component number on phase V3	2-50		UINT32	

File Section	Record Field No.	Point Label	Point ID	Description ¹	Range ²	Units ²	Type	Notes
	20	V3 N2	0x5F93	Number of interharmonic voltage THD incidents on phase V3			UINT32	
	21	V3 THD Max	0x5F94	Worst-case interharmonic THD on phase V3		0.1%	UINT32	
11				Mains Signaling Voltage				
	1	Nnv	0x6000	Number of non-valid 3-sec intervals			UINT32	
	2	N	0x6001	Number of valid 3-sec intervals			UINT32	
	3	N1	0x6002	Number of polyphase incidents, N1			UINT32	
	4	N1/N, %	0x6003	EN50160 compliance ratio, N1/N		0.01%	UINT32	
	5	V1 N1	0x6004	Number of incidents on phase V1			UINT32	
	6	V1 Frq1 %Un	0x6005	Maximum 1st signaling voltage magnitude on phase V1, %Un		0.01%	UINT32	
	7	V1 Frq2 %Un	0x6006	Maximum 2nd signaling voltage magnitude on phase V1, %Un		0.01%	UINT32	
	8	V1 Frq3 %Un	0x6007	Maximum 3rd signaling voltage magnitude on phase V1, %Un		0.01%	UINT32	
	9	V1 Frq4 %Un	0x6008	Maximum 4th signaling voltage magnitude on phase V1, %Un		0.01%	UINT32	
	10	V2 N1	0x6009	Number of incidents on phase V2			UINT32	
	11	V2 Frq1 %Un	0x600A	Maximum 1st signaling voltage magnitude on phase V2, %Un		0.01%	UINT32	
	12	V2 Frq2 %Un	0x600B	Maximum 2nd signaling voltage magnitude on phase V2, %Un		0.01%	UINT32	
	13	V2 Frq3 %Un	0x600C	Maximum 3rd signaling voltage magnitude on phase V2, %Un		0.01%	UINT32	
	14	V2 Frq4 %Un	0x600D	Maximum 4th signaling voltage magnitude on phase V2, %Un		0.01%	UINT32	
	15	V3 N1	0x600E	Number of incidents on phase V3			UINT32	
	16	V3 Frq1 %Un	0x600F	Maximum 1st signaling voltage magnitude on phase V3, %Un		0.01%	UINT32	
	17	V3 Frq2 %Un	0x6010	Maximum 2nd signaling voltage magnitude on phase V3, %Un		0.01%	UINT32	
	18	V3 Frq3 %Un	0x6011	Maximum 3rd signaling voltage magnitude on phase V3, %Un		0.01%	UINT32	
	19	V3 Frq4 %Un	0x6012	Maximum 4th signaling voltage magnitude on phase V3, %Un		0.01%	UINT32	
	20	Frq1	0x6013	1st signaling voltage frequency		0.01Hz	UINT32	
	21	Frq2	0x6014	2nd signaling voltage frequency		0.01Hz	UINT32	
	22	Frq3	0x6015	3rd signaling voltage frequency		0.01Hz	UINT32	
	23	Frq4	0x6016	4th signaling voltage frequency		0.01Hz	UINT32	

¹ When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

² For volts, amps, power and frequency scales and units, refer to Section 4 "Data Scales and Units".

3.11 EN 50160 Harmonics Survey Statistics Data Log

File Section	Record Field No.	Point Label	Point ID	Description ¹	Range	Units	Type	Notes
0				V1 Harmonic Voltage			UINT32	
	1	THD MAX	0x8000	Maximum THD on phase		0.1%	UINT32	
	2	THDO MAX	0x8001	Maximum odd harmonics THD		0.1%	UINT32	
	3	THDE MAX	0x8002	Maximum even harmonics THD		0.1%	UINT32	
	4	%HD02 MAX	0x8003	Maximum HD02 harmonic voltage magnitude, %Un		0.01%	UINT32	
	5	%HD03 MAX	0x8004	Maximum HD03 harmonic voltage magnitude, %Un		0.01%	UINT32	
		...					UINT32	
	52	%HD50 MAX	0x8032	Maximum HD50 harmonic voltage magnitude, %Un		0.01%	UINT32	
1				V2 Harmonic Voltage			UINT32	
	1	THD MAX	0x8000	Maximum THD on phase		0.1%	UINT32	
	2	THDO MAX	0x8001	Maximum odd harmonics THD		0.1%	UINT32	
	3	THDE MAX	0x8002	Maximum even harmonics THD		0.1%	UINT32	
	4	%HD02 MAX	0x8003	Maximum HD02 harmonic voltage magnitude, %Un		0.01%	UINT32	
	5	%HD03 MAX	0x8004	Maximum HD03 harmonic voltage magnitude, %Un		0.01%	UINT32	
		...					UINT32	
	52	%HD50 MAX	0x8032	Maximum HD50 harmonic voltage magnitude, %Un		0.01%	UINT32	
2				V3 Harmonic Voltage			UINT32	
	1	THD MAX	0x8000	Maximum THD on phase		0.1%	UINT32	
	2	THDO MAX	0x8001	Maximum odd harmonics THD		0.1%	UINT32	
	3	THDE MAX	0x8002	Maximum even harmonics THD		0.1%	UINT32	
	4	%HD02 MAX	0x8003	Maximum HD02 harmonic voltage magnitude, %Un		0.01%	UINT32	
	5	%HD03 MAX	0x8004	Maximum HD03 harmonic voltage magnitude, %Un		0.01%	UINT32	
		...					UINT32	
	52	%HD50 MAX	0x8032	Maximum HD50 harmonic voltage magnitude, %Un		0.01%	UINT32	

¹ When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

3.12 Billing/TOU Daily and Monthly Profile Data Logs

File Channel/ Section ¹	Record Field No. ²	Point Label	Point ID	Description	Range	Units ³	Type	Notes
0/0				Energy Register #1				
	1	TRF1	0x7000	Tariff #1 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	2	TRF2	0x7001	Tariff #2 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	3	TRF3	0x7002	Tariff #3 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	4	TRF4	0x7003	Tariff #4 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	5	TRF5	0x7004	Tariff #5 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	6	TRF6	0x7005	Tariff #6 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	7	TRF7	0x7006	Tariff #7 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	8	TRF8	0x7007	Tariff #8 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	9	TRF9	0x7008	Tariff #9 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	10	TRF10	0x7009	Tariff #10 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	11	TRF11	0x700A	Tariff #11 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	12	TRF12	0x700B	Tariff #12 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	13	TRF13	0x700C	Tariff #13 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	14	TRF14	0x700D	Tariff #14 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	15	TRF15	0x700E	Tariff #15 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	16	TRF16	0x700F	Tariff #16 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
...				...				
15/15				Energy Register #16				
	1	TRF1	0x7000	Tariff #1 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	2	TRF2	0x7001	Tariff #2 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	3	TRF3	0x7002	Tariff #3 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	4	TRF4	0x7003	Tariff #4 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	5	TRF5	0x7004	Tariff #5 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	6	TRF6	0x7005	Tariff #6 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	7	TRF7	0x7006	Tariff #7 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	8	TRF8	0x7007	Tariff #8 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	9	TRF9	0x7008	Tariff #9 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	10	TRF10	0x7009	Tariff #10 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	11	TRF11	0x700A	Tariff #11 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	12	TRF12	0x700B	Tariff #12 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	13	TRF13	0x700C	Tariff #13 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	14	TRF14	0x700D	Tariff #14 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	15	TRF15	0x700E	Tariff #15 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
	16	TRF16	0x700F	Tariff #16 energy reading	-999,999,999-999,999,999	1 kWh	UINT32	
16/16				Maximum Demand Register #1				
	1	TRF1 MD	0x7100	Tariff #1 max. demand reading	0-Pmax	U3	UINT32	
	2	TRF2 MD	0x7101	Tariff #2 max. demand reading	0-Pmax	U3	UINT32	

File Channel/ Section ¹	Record Field No. ²	Point Label	Point ID	Description	Range	Units ³	Type	Notes
	3	TRF3 MD	0x7102	Tariff #3 max. demand reading	0-Pmax	U3	UINT32	
	4	TRF4 MD	0x7103	Tariff #4 max. demand reading	0-Pmax	U3	UINT32	
	5	TRF5 MD	0x7104	Tariff #5 max. demand reading	0-Pmax	U3	UINT32	
	6	TRF6 MD	0x7105	Tariff #6 max. demand reading	0-Pmax	U3	UINT32	
	7	TRF7 MD	0x7106	Tariff #7 max. demand reading	0-Pmax	U3	UINT32	
	8	TRF8 MD	0x7107	Tariff #8 max. demand reading	0-Pmax	U3	UINT32	
	9	TRF9 MD	0x7108	Tariff #9 max. demand reading	0-Pmax	U3	UINT32	
	10	TRF10 MD	0x7109	Tariff #10 max. demand reading	0-Pmax	U3	UINT32	
	11	TRF11 MD	0x710A	Tariff #11 max. demand reading	0-Pmax	U3	UINT32	
	12	TRF12 MD	0x710B	Tariff #12 max. demand reading	0-Pmax	U3	UINT32	
	13	TRF13 MD	0x710C	Tariff #13 max. demand reading	0-Pmax	U3	UINT32	
	14	TRF14 MD	0x710D	Tariff #14 max. demand reading	0-Pmax	U3	UINT32	
	15	TRF15 MD	0x710E	Tariff #15 max. demand reading	0-Pmax	U3	UINT32	
	16	TRF16 MD	0x710F	Tariff #16 max. demand reading	0-Pmax	U3	UINT32	
...				...				
32/32				Maximum Demand Register #16				
	1	TRF1 MD	0x7100	Tariff #1 max. demand reading	0-Pmax	U3	UINT32	
	2	TRF2 MD	0x7101	Tariff #2 max. demand reading	0-Pmax	U3	UINT32	
	3	TRF3 MD	0x7102	Tariff #3 max. demand reading	0-Pmax	U3	UINT32	
	4	TRF4 MD	0x7103	Tariff #4 max. demand reading	0-Pmax	U3	UINT32	
	5	TRF5 MD	0x7104	Tariff #5 max. demand reading	0-Pmax	U3	UINT32	
	6	TRF6 MD	0x7105	Tariff #6 max. demand reading	0-Pmax	U3	UINT32	
	7	TRF7 MD	0x7106	Tariff #7 max. demand reading	0-Pmax	U3	UINT32	
	8	TRF8 MD	0x7107	Tariff #8 max. demand reading	0-Pmax	U3	UINT32	
	9	TRF9 MD	0x7108	Tariff #9 max. demand reading	0-Pmax	U3	UINT32	
	10	TRF10 MD	0x7109	Tariff #10 max. demand reading	0-Pmax	U3	UINT32	
	11	TRF11 MD	0x710A	Tariff #11 max. demand reading	0-Pmax	U3	UINT32	
	12	TRF12 MD	0x710B	Tariff #12 max. demand reading	0-Pmax	U3	UINT32	
	13	TRF13 MD	0x710C	Tariff #13 max. demand reading	0-Pmax	U3	UINT32	
	14	TRF14 MD	0x710D	Tariff #14 max. demand reading	0-Pmax	U3	UINT32	
	15	TRF15 MD	0x710E	Tariff #15 max. demand reading	0-Pmax	U3	UINT32	
	16	TRF16 MD	0x710F	Tariff #16 max. demand reading	0-Pmax	U3	UINT32	

¹ An energy use profile section and a maximum demand profile section are allocated for registers for which a source input is selected in the Billing/TOU Register setup and for which TOU profile is enabled. Not configured sections/channels are not available for download. Refer to the file channel mask in the file info for configured channels.

² The number of parameters in a section is automatically configured depending on the number of actually used tariffs selected in the TOU Daily Profiles.

³ For power scale and units, refer to Section 4 "Data Scales and Units".

4 Data Scales and Units

Code	Condition	Value/Range	Notes
Data Scales			
Vmax		Voltage Scale × PT Ratio, V	2
V4max		Voltage Scale × V4 PT Ratio, V	2
I _{max}		Current Scale × CT Ratio ¹ , A,	3
I _{4max}		Current Scale × I4 CT Ratio ¹ , A,	3
I _{xmax}	1A secondary	30 × CT _x Ratio ¹ , A	
	5A secondary	150 × CT _x Ratio ¹ , A	
I _{4xmax}	1A secondary	30 × I4 _x CT _x Ratio ¹ , A	
	5A secondary	150 × I4 _x CT _x Ratio ¹ , A	
P _{max}	PT Ratio = 1	V _{max} × I _{max} × 2, W	4
	PT Ratio > 1	(V _{max} × I _{max} × 2)/1000, kW	
AI _{min} AI _{max}	+/-1mA	AI _{min} = -AI full scale × 2 AI _{max} = AI full scale × 2	
	0-20mA	AI _{min} = AI zero scale AI _{max} = AI full scale	
	4-20mA	AI _{min} = AI zero scale AI _{max} = AI full scale	
	0-1mA	AI _{min} = AI zero scale AI _{max} = AI full scale	
	0-50mA	AI _{min} = AI zero scale AI _{max} = AI full scale × 2	
	+/-10V	AI _{min} = -AI full scale AI _{max} = AI full scale	
Data Units			
U1	PT Ratio = 1	0.1V	
	PT Ratio > 1	1V	
U2		0.01A	
U3	PT Ratio = 1	1W/Var/VA	
	PT Ratio > 1	1kW/kvar/kVA	
U4	V4 PT Ratio = 1	0.1V	
	V4 PT Ratio > 1	1V	

¹ CT Ratio = CT primary current/CT secondary current

² The default Voltage Scale is 828V. You can change it via the Modbus Setup registers (see Section 3.1) or via the Device Options setup in PAS.

³ The default Current Scale is 4 × CT secondary current for devices with a 400% overload (ANSI) or 2 × CT secondary current for devices with a 200% overload (IEC). You can change it via the Modbus Setup registers (see Section 3.1) or via the Device Options setup in PAS.

⁴ P_{max} is rounded to whole kilowatts. If P_{max} is greater than 9,999,000 W, it is truncated to 9,999,000 W.

5 Data Formats

Format Code	Value	Description	Notes
Timestamp			
F1		Local time in a UNIX-style format. Represents the number of seconds since midnight (00:00:00), January 1, 1970. The time is valid after January 1, 2000.	
File ID			
F2	0	Event log	
	1-16	Data log #1-#16	
	17-24	Waveform log #1-#8	
	25	Sequence-of-events (SOE) log	
	26	Power quality (PQ) log	
	27	Fault log	
	128	Real time waveform capture	
File Attributes			
F3	Bit 0 = 0	Non-wrap file (stop when full)	
	Bit 0 = 1	Wrap-around (circular) file	
	Bit 1 = 1	Fixed (non-changeable) file attributes	
	Bits 4:6 =	Multi-section data log file attributes:	
	0	Regular file	
	1	TOU monthly profile log	Multi-section file
	2	TOU daily profile log	Multi-section file
3	EN50160 Compliance Statistics	Multi-section file	
4	EN50160 Survey Statistics - Voltage Harmonics	Multi-section file	
File Status Word (bitmap)			
F4	Bit 0 = 1	The last record of the file is being read	
	Bit 8 = 1	File is empty	
	Bit 9 = 1	Reading after EOF	
	Bit 10 = 1	Corrupted record (CRC error)	
	Bit 11 = 1	No file section found for the requested channel	
	Bit 12 = 1	Reading after the end of a data block	
	Bit 13 = 1	File is not accessible	
	Bit 14 = 1	Record not found	
Bit 15 = 1	Generic read error (with one of the bits 8-14)		
File Record Status Word (bitmap)			
F5	Bit 0 = 1	The last record of the file is being read	
	Bit 8 = 1	File is empty	
	Bit 9 = 1	Reading after EOF	
	Bit 10 = 1	Corrupted record (CRC error)	
	Bit 11 = 1	No file section found for the requested channel	
	Bit 12 = 1	Reading after the end of a data block	
	Bit 13 = 1	File is not accessible	
	Bit 14 = 1	Record not found	
Bit 15 = 1	Generic read error (with one of the bits 8-14)		
Billing/TOU Profile Log Channel ID			
F6	0-15	Billing/TOU energy registers #1-#16	
	16-31	Billing/TOU maximum demand registers #1-#16	
Waveform Log Channel ID			
F7	0	V1	1
	1	V2	1
	2	V3	1
	3	V4	
	4	I1	
	5	I2	
	6	I3	
	7	I4	
	8	I1x	
	9	I2x	
	10	I3x	
	11	I4x	
	12	VDC	
	13	DI1-16	
	14	DI17-32	V10.3.20 and higher
	15	DI33-48	V10.3.20 and higher
	16	AI1	V10.6.XX
17	AI2		

Format Code	Value	Description	Notes
	18	AI3	
	19	AI4	
	20	AI5	
	21	AI6	
	22	AI7	
	23	AI8	
	24	AI9	
	25	AI10	
	26	AI11	
	27	AI12	
	28	AI13	
	29	AI14	
	30	AI15	
	31	AI16	
Billing/TOU Profile Log Channel Mask (bitmap)			
F8	Bit 0:15 = 1	Billing/TOU energy registers #1-#16	
	Bit 16:31 = 1	Billing/TOU maximum demand registers #1-#16	
Waveform Log Channel Mask (bitmap)			
F9	Bit 0	Channel V1	1
	Bit 1	Channel V2	1
	Bit 2	Channel V3	1
	Bit 3	Channel V4	
	Bit 4	Channel I1	
	Bit 5	Channel I2	
	Bit 6	Channel I3	
	Bit 7	Channel I4	
	Bit 8	Channel I1x	
	Bit 9	Channel I2x	
	Bit 10	Channel I3x	
	Bit 11	Channel I4x	
	Bit 12	Channel VDC	
	Bit 13	Channels DI1-16	
	Bit 14	Channels DI17-32	V10.3.20 and higher
	Bit 15	Channels DI33-48	V10.3.20 and higher
	Bit 16	Channel AI1	V10.6.XX
	Bit 17	Channel AI2	
	Bit 18	Channel AI3	
	Bit 19	Channel AI4	
	Bit 20	Channel AI5	
	Bit 21	Channel AI6	
	Bit 22	Channel AI7	
	Bit 23	Channel AI8	
	Bit 24	Channel AI9	
	Bit 25	Channel AI10	
	Bit 26	Channel AI11	
	Bit 27	Channel AI12	
	Bit 28	Channel AI13	
	Bit 29	Channel AI14	
	Bit 30	Channel AI15	
	Bit 31	Channel AI16	
TOU Tariff Change Time			
F10	Bits 8:15 = 0-15	Tariff number #1-#16	
	Bits 2:7 = 0-23	Tariff start hour	
	Bits 0:1 = 0-3	Tariff start quarter of an hour	
Billing Register Source ID			
F11	0x0000	None	
	0x0700-0x077F	Pulse input DI1-DI128	
	0x1700	kWh import	
	0x1701	kWh export	
	0x1702	kWh net	
	0x1703	kWh total	
	0x1704	kvarh import	
	0x1705	kvarh export	
	0x1706	kvarh net	
	0x1707	kvarh total	
	0x1708	kVAh total	
	0x1780-0x178F	Billing/TOU register #1-#16	

Format Code	Value	Description	Notes	
Setpoint Trigger Parameters ID				
F12	0x0000-0xFFFF	Any data point ID excluding energy counters	See Section 3.4	
	0x0480-0x048F	External trigger #1-#16 (UDP broadcast trigger message)		
Setpoint Relational Operator				
F13	0 = NONE	No relation (used with pulsed events)		
	1 = GREATER OR EQUAL	Analog value or counter is over the operate limit		
	2 = LESS OR EQUAL	Analog value or counter is under the operate limit		
	3 = EQUAL	Analog value or counter is equal to the operate limit		
	4 = NOT EQUAL	Analog value or counter is not equal to the operate limit		
	5 = ON	Binary status is 1/ON		
	6 = OFF	Binary status is 0/OFF		
	7 = NEW	New Min/Max value logged for the point		
	8 = Delta	The absolute value of the difference between the last reported value and the current value exceeds the specified threshold		
	12 = Delta+	Incremental delta - the positive difference between the current value and the last reported value exceeds the specified threshold		
	13 = Delta-	Decremental delta - the positive difference between the last reported value and the current value exceeds the specified threshold		
	14 = rDelta	Relative delta - the absolute value of the difference between the last tested value and the current value exceeds the specified threshold		
	15 = rDelta+	Incremental relative delta - the positive difference between the current value and the last tested value exceeds the specified threshold		
16 = rDelta-	Decremental relative delta - the positive difference between the last tested value and the current value exceeds the specified threshold			
Setpoint Action ID				
F14	0x0000	No action		
	0x2000-0x203F	Set user event flag #1-#64		
	0x2100-0x213F	Clear user event flag #1-#64		
	0x3000-0x303F	Operate relay RO1-RO64		
	0x3100-0x313F	Release latched relay RO1-RO64		
	0x3700-0x373F	Unblock relay RO1-RO64		
	0x3800-0x3807	Unblock direct control port. Lower byte 0-7: 0=all ports, 1=COM1, 2=COM2, 3=COM3, 4=COM4, 5=COM5, 6=USB, 7=Ethernet		
	0x3900-0x3901	Close breaker XCBR1-XCBR2		
	0x3902-0x390F	Close switch XSWI1-XSWI14		
	0x3A00-0x3A01	Open breaker XCBR1-XCBR2		
	0x3A02-0x3A0F	Open switch XSWI1-XSWI14		
	0x4000-0x401F	Increment counter #1-#32		
	0x4100-0x411F	Decrement counter #1-#32		
	0x4200-0x421F	Clear counter #1-#32		
	0x5100	Send event notification		
	0x5300	Remote control		
	0x6000	Reset total energy registers		
	0x6100	Reset total maximum demand registers		
	0x6200	Reset Billing/TOU energy		
	0x6300	Reset Billing/TOU maximum demands		
	0x6400	Clear all counters		
	0x6500	Clear Min/Max log registers		
	0x7000	Event log on setpoint operated		
	0x7001	Event log on setpoint released		
	0x7002	Event log on any setpoint transition		
	0x7100-0x710F	Data log 1-16		
	0x7200-0x7207	Waveform Log 1-8		
	0x7400	SOE (Sequence of Events) Log		
	0x8000-0x800F	External trigger #1-#16 (UDP broadcast trigger message)		
	Energy Pulse Source ID			
	F15	0x0000	None	
		0x0400	kWh Import pulse	
		0x0401	kWh Export pulse	
0x0402		kWh Total pulse		

Format Code	Value	Description	Notes
	0x0403	kvarh Import pulse	
	0x0404	kvarh Export pulse	
	0x0405	kvarh Total pulse	
	0x0406	kVAh pulse	
Counter Source ID			
F16	0x0000	None	
	0x0700-0x077F	Pulse input DI1-DI128	
Relay Output Pulse Source ID			
F17	0x0000	None	
	0x0400	kWh Import pulse	
	0x0401	kWh Export pulse	
	0x0402	kWh Total pulse	
	0x0403	kvarh Import pulse	
	0x0404	kvarh Export pulse	
	0x0405	kvarh Total pulse	
	0x0406	kVAh pulse	
	0x0407	Start of power demand interval pulse	
	0x0408	Start of tariff interval pulse	
AO Parameters ID (see Section 3.4 for data scales)			
F18	0x0000	None (output disabled)	2
		1-Cycle Phase Values	
	0x0C00	V1 Voltage	
	0x0C01	V2 Voltage	
	0x0C02	V3 Voltage	
	0x0C03	I1 Current	
	0x0C04	I2 Current	
	0x0C05	I3 Current	
	0x0C12	V1 Voltage THD	
	0x0C13	V2 Voltage THD	
	0x0C14	V3 Voltage THD	
	0x0C15	I1 Current THD	
	0x0C16	I2 Current THD	
	0x0C17	I3 Current THD	
	0x0C18	I1 K-Factor	
	0x0C19	I2 K-Factor	
	0x0C1A	I3 K-Factor	
	0x0C1B	I1 Current TDD	
	0x0C1C	I2 Current TDD	
	0x0C1D	I3 Current TDD	
	0x0C1E	V12 Voltage	
	0x0C1F	V23 Voltage	
	0x0C20	V31 Voltage	
		1-Cycle Total Value	
	0x0F00	Total kW	
	0x0F01	Total kvar	
	0x0F02	Total kVA	
	0x0F03	Total PF	
	0x0F04	Total PF Lag	
	0x0F05	Total PF Lead	
		1-Cycle Auxiliary Values	
	0x1000	I4 Current	
	0x1001	In Current	
	0x1002	Frequency	
	0x1005	DC voltage	
		1-Sec Phase Values	
	0x1100	V1 Voltage	
	0x1101	V2 Voltage	
	0x1102	V3 Voltage	
	0x1103	I1 Current	
	0x1104	I2 Current	
	0x1105	I3 Current	
	0x111E	V12 Voltage	
	0x111F	V23 Voltage	
	0x1120	V31 Voltage	
		1-Sec Total Values	
	0x1400	Total kW	
	0x1401	Total kvar	

Format Code	Value	Description	Notes
	0x1402	Total kVA	
	0x1403	Total PF	
	0x1404	Total PF Lag	
	0x1405	Total PF Lead	
	0x140A	3-phase average L-N voltage	
	0x140B	3-phase average L-L voltage	
	0x140C	3-phase average current	
		1-Sec Auxiliary Values	
	0x1500	I4 Current	
	0x1501	In Current	
	0x1502	Frequency	
		Present Demands	
	0x160F	Accumulated kW import demand	
	0x1610	Accumulated kvar import demand	
	0x1611	Accumulated kVA demand	
	0x161A	Accumulated kW export demand	
	0x161B	Accumulated kvar export demand	
Event Source/Point ID			
F19		Setpoint Operation Events	
	0x0000-0x59FF	Trigger parameter ID	
	0x6400-0xFFFF	Trigger parameter ID	
		Setpoint Action Events	
	0x5A00-0x5A3F	Setpoint #1-#64	
		Communications Events	
	0x5B00-0x5BFF	Data/Function point ID (low byte, see F21)	
		Self-Check Diagnostics Events	
	0x5D00-0x5DFF	Data/Function point ID (low byte, see F21)	
		Self-Update Events	
	0x5E08	RTC DST/Standard time update	3
		Run-time Error	
	0x6014	Library error	
	0x6015	RTOS Kernel error	
	0x6016	Task error	
		Control Events	
	0x6100	XSWIn_OpOpn = operation "Open" (n=see F20 Control Events)	
	0x6101	XSWIn_OpCls = operation "Close" (n=see F20 Control Events)	
	0x6102	XSWIn_Pos = switch position change (n=see F20 Control Events, Value = position)	
	0x6103	Remote control (Value: 0=OFF, 1=ON)	
		Hardware Diagnostics Events	
	0x6201	Permanent fault	
	0x6202	RAM/Data error	
	0x6203	CPU watchdog reset	
	0x6204	DSP/Sampling fault	
	0x6205	CPU exception	
	0x6206	Reserved	
	0x6207	Software watchdog reset	
	0x620E	Expanded memory fault (Event effect = File ID + 1)	
	0x620F	CPU EEPROM fault	
	0x6210	AC board EEPROM fault	
	0x6211	I/O board EEPROM fault	
		External Events	
	0x6300	Power down	
	0x6308	Power up	
	0x6309	External reset	
	0x6318	IRIG-B signal lost	
	0x6319	IRIG-B time unlocked	
	0x631A	IRIG-B time locked	
	0x6320	SNTP server failed	4
	0x6321	SNTP server reconnected	4
Event Effect ID			
F20		Communications/Self-check/Self-update Events	
	0x0000	None	
	0x6000	Total energy registers cleared	
	0x6100	All total maximum demands cleared	
	0x6101	Power maximum demands cleared	

Format Code	Value	Description	Notes
	0x6102	Volt/Ampere maximum demands cleared	
	0x6103	Volt maximum demands cleared	
	0x6104	Ampere maximum demands cleared	
	0x6105	Harmonic maximum demands cleared	
	0x6200	Billing/TOU energy registers cleared	
	0x6300	Billing/TOU demand registers cleared	
	0x6400	All counters cleared	
	0x6401-0x641F	Counter cleared (low byte = counter ID)	
	0x6500	Min/Max log cleared	
	0x6A00-0x6A1B	Log file cleared (low byte = File ID)	
	0x6B00	EN50160 statistics cleared	
	0x6B06	Communication counters cleared	
	0x6B07	Switch operation counters cleared	
	0xF100-0xF11F	Setpoint cleared (low byte = setpoint ID)	
	0xF200	Setup/Data cleared	
	0xF300	Setup reset (set by default)	
	0xF400	Setup changed	
	0xF500	RTC set	3
	0xF600	Device function/option enabled	
	0xF700	Device function/option disabled	
	0xF800	Device function restarted	
	0xF900	Device function stopped	
		Control Events	
	0xA0XX	Position change (bits 0:7=switch number)	
	0xA1XX	Operation activated (bits 0:7=switch number)	
	0xA2XX	Operation terminated (bits 0:7=switch number)	
	0xA3XX	Operation terminated by timeout (bits 0:7=switch number)	
		Setpoint Operation Events	
	0xE100-0xE13F	Setpoint operated (low byte = setpoint ID)	
	0xE200-0xE23F	Setpoint released (low byte = setpoint ID)	
		Setpoint Action Events	
	See F14	Setpoint action ID	
Data/Function Point ID			
F21		Data Location	
	0x03	Data memory	
	0x04	Factory setup	
	0x05	Access/Password setup	
	0x06	Basic setup	
	0x07	Communications setup	
	0x08	Real-time clock	
	0x09	Digital inputs setup	
	0x0A	Pulse counters setup	
	0x0B	AO setup	
	0x0E	Timers setup	
	0x10	Event/alarm setpoints	
	0x11	Pulsing setup	
	0x12	User assignable register map	
	0x13	Programmable Min/Max log setup	
	0x14	Data log setup	
	0x15	File/Memory setup	
	0x16	Billing/TOU registers setup	
	0x18	TOU daily profiles	
	0x19	TOU calendar	
	0x1A	TOU calendar years	
	0x1D	RO Setup	
	0x1C	User selectable options	
	0x1F	DNP 3.0 class 0 map	
	0x20	DNP 3.0 options setup	
	0x21	DNP 3.0 events setup	
	0x22	DNP 3.0 event setpoints	
	0x23	Calibration registers	
	0x24	Date/Time Setup	
	0x25	Net setup	
	0x26	AI setup	
	0x27	Waveform log setup	
	0x28	PQ log setup	

Format Code	Value	Description	Notes
	0x29	Fault log setup	
	0x2A	Device mode control	
	0x2B-0x3F	Reserved	
		Device Mode/Option	
	0x40	General device operations	
	0x41	Energy test mode	
	0x42	Setpoints mode	
	0x43	PQ recorder	
	0x44	Fault recorder	
		Device Diagnostics	
	0x80	Device diagnostics	
	0x81	Critical error	
Event Type ID			
F22		Setpoint Events	
	0x0000	SP: Generic setpoint event	
	0x0001-0x0040	SP1-SP64: Setpoint #1-#64 event	
		IEEE 1159 PQ Events (IEEE 1159 categories)	
	0x0100	PQE: Generic IEEE1159 PQ event	
	0x0102	PQE11: Impulsive transient	
	0x010C	PQE211: Sag, instantaneous	
	0x010D	PQE212: Swell, instantaneous	
	0x010F	PQE221: Interruption, momentary	
	0x0110	PQE222: Sag, momentary	
	0x0111	PQE223: Swell, momentary	
	0x0113	PQE231: Interruption, temporary	
	0x0114	PQE232: Sag, temporary	
	0x0115	PQE233: Swell, temporary	
	0x0117	PQE31: Interruption, sustained	
	0x0118	PQE32: Undervoltage	
	0x0119	PQE33: Overvoltage	
	0x011A	PQE4: Voltage imbalance	
	0x011D	PQE52: Harmonics	
	0x011E	PQE53: Interharmonics	
	0x0121	PQE6: Voltage fluctuations (flicker)	
	0x0122	PQE7: Frequency variation	
		Fault Events	
	0x0200	FE: Generic fault event	
	0x0201	FE1: Zero-sequence current	
	0x0202	FE2: Zero-sequence voltage	
	0x0203	FE3: Current unbalance	
	0x0204	FE4: Voltage unbalance	
	0x0205	FE5: Overcurrent and undervoltage	
	0x0206	FE6: Undervoltage	
	0x0207	FE7: Neutral current (I4)	
		DI Events	
	0x0300	DI: Generic DI event	
	0x0301-0x0380	DI1-DI128: DI1-DI128 event	
		RO Events	
	0x0400	RO: Generic RO event	
	0x0401-0x0440	RO1-RO64: RO1-RO64 event	
		EN 50160 PQ Events (EN 50160 categories)	
	0x0500	PQE: Generic EN50160 PQ event	
	0x0501	PQE1: Frequency variations	
	0x0502	PQE2: Voltage variations	
	0x0503	PQE3: Rapid voltage changes	
	0x0504	PQE4: Flicker	
	0x0505	PQE5: Voltage dips	
	0x0506	PQE6: Voltage interruptions	
	0x0507	PQE7: Temporary overvoltages	
	0x0508	PQE8: Transient overvoltages	
	0x0509	PQE9: Voltage unbalance	
	0x050A	PQE10: Harmonic voltage	
	0x050B	PQE11: Interharmonic voltage	
	0x050C	PQE12: Mains signaling voltage	
Device Diagnostics (bitmap)			
F23	Bit 0 = 1	Critical error - device operations stop	
	Bit 1 = 1	Permanent fault (critical error)	

Format Code	Value	Description	Notes	
	Bit 2 = 1	RAM/Data error		
	Bit 3 = 1	CPU watchdog reset		
	Bit 4 = 1	DSP/Sampling fault		
	Bit 5 = 1	CPU exception		
	Bit 6	Reserved		
	Bit 7 = 1	Software watchdog reset		
	Bit 8 = 1	Power down		
	Bit 9 = 1	Device reset		
	Bit 10 = 1	Configuration reset		
	Bit 11 = 1	RTC fault (critical error)		
	Bit 12 = 1	Configuration fault (critical error)		
	Bit 13	Reserved		
	Bit 14 = 1	Expanded memory fault		
	Bit 15 = 1	CPU EEPROM fault		
	Bit 16 = 1	AC board EEPROM fault		
	Bit 17 = 1	I/O board EEPROM fault		
	Bit 18	Reserved		
	Bit 19	Reserved		
	Bit 20 = 1	C Library error		
	Bit 21 = 1	RTOS Kernel error		
	Bit 22 = 1	Task error		
	Bit 23	Reserved		
	Bit 24 = 1	IRIG-B signal lost		
	Bit 25 = 1	IRIG-B time unlocked		
DNP Object Types				
F24		Binary Input Static Object		
	0	Single-Bit Binary Input		
	1	Binary Input With Status		
		Binary Input Change Event Object		
	0	Binary Input Change Without Time		
	1	Binary Input Change With Time		
		Binary Counter		
	0	32-bit Binary Counter		
	1	32-bit Binary Counter Without Flag		
	2	16-bit Binary Counter		
	3	16-bit Binary Counter Without Flag		
		Binary Counter Change Event		
	0	32-bit Counter Change Event Without Time		
	1	32-bit Counter Change Event With Time		
	2	16-bit Counter Change Event Without Time		
	3	16-bit Counter Change Event With Time		
		Frozen Binary Counter		
	0	32-bit Frozen Counter		
	1	32-bit Frozen Counter Without Flag		
	2	32-bit Frozen Counter With Time of Freeze		
	3	16-bit Frozen Counter		
	4	16-bit Frozen Counter Without Flag		
	5	16-bit Frozen Counter With Time of Freeze		
		Analog Input		
	0	32-bit Analog Input		
	1	32-bit Analog Input Without Flag		
	2	16-bit Analog Input		
	3	16-bit Analog Input Without Flag		
		Analog Input Change Event		
	0	32-bit Analog Change Event Without Time		
	1	32-bit Analog Change Event With Time		
	2	16-bit Analog Change Event Without Time		
	3	16-bit Analog Change Event With Time		
	DNP Class 0 Objects			
	F25	0x1E01	Analog Input 30:01	
		0x1E02	Analog Input 30:02	
0x1E03		Analog Input 30:03		
0x1E04		Analog Input 30:04		
0x2801		Analog Output 40:01		
0x2802		Analog Output 40:02		
0x0101		Binary Input 01:01		
0x0102		Binary Input 01:02		

Format Code	Value	Description	Notes
	0x1401	Binary Counter 20:01	
	0x1402	Binary Counter 20:02	
	0x1405	Binary Counter 20:05	
	0x1406	Binary Counter 20:06	
	0x1501	Frozen Counter 21:01	
	0x1502	Frozen Counter 21:02	
	0x1505	Frozen Counter 21:05	
	0x1506	Frozen Counter 21:06	
	0x1509	Frozen Counter 21:09	
	0x150A	Frozen Counter 21:10	
Wiring Mode			
F26	0	3OP2 - 3-wire open delta using 2 CTs (2 element)	
	1	4LN3 - 4-wire WYE using 3 PTs (3 element), line-to-neutral voltage readings	
	2	3DIR2 - 3-wire direct connection using 2 CTs (2 element)	
	3	4LL3 - 4-wire WYE using 3 PTs (3 element), line-to-line voltage readings	
	4	3OP3 - 3-wire open delta using 3 CTs (2 1/2 element)	
	5	3LN3 - 4-wire WYE using 2 PTs (2 1/2 element), line-to-neutral voltage readings	
	6	3LL3 - 4-wire WYE using 2 PTs (2 1/2 element), line-to-line voltage readings	
	8	3BLN3 - 3-wire broken delta using 2 PTs (2 1/2 element), line-to-neutral voltage readings	
	9	3BLL3 - 3-wire broken delta using 2 PTs (2 1/2 element), line-to-line voltage readings	
IEC 61850 Measured Value Indices			
F27	0	Phase voltage	
	1	Auxiliary voltage V4	
	2	DC voltage	
	3	Phase currents	
	4	Neutral current	
	5	Auxiliary current I4	
	6	Phase currents (extended inputs)	
	7	Neutral current (extended inputs)	
	8	Auxiliary current I4 (extended inputs)	
	9	Voltage sequence	
	10	Current sequence	
	11	Current sequence (extended inputs)	
	12	Voltage unbalance	
	13	Current unbalance	
	14	Active power	
	15	Reactive power	
	16	Active power import/export	
	17	Reactive power import/export	
	18	Apparent power	
	19	Active power demand	
	20	Reactive power demand	
	21	Apparent power demand	
	22	Power factor	
	23	Power factor lag/lead	
	24	Frequency	
	25	Voltage THD	
	26	Current THD	
	27	Voltage interharmonic THD	
	28	Current interharmonic THD	
	29	Current TDD	
	30	Current K-factor	
	31	Not used	
	32	Not used	
	33	Analog input #1	
	34	Analog input #2	
	35	Analog input #3	
	36	Analog input #4	
	37	Analog input #5	
	38	Analog input #6	
	39	Analog input #7	
	40	Analog input #8	

Format Code	Value	Description	Notes
	41	Analog input #9	
	42	Analog input #10	
	43	Analog input #11	
	44	Analog input #12	
	45	Analog input #13	
	46	Analog input #14	
	47	Analog input #15	
	48	Analog input #16	

NOTES:

- ¹ When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.
- ² 1) For bi-directional analog output (± 1 mA), the zero scale setup corresponds to the center (0 mA) of the scale range, and the direction of the current matches the sign of the output parameter. Unsigned parameters are output within the current range 0 to +1 mA and can be scaled as in the case of single-ended analog output (0-1 mA).
For signed values, such as powers and signed power factor, the scale is always symmetrical with regard to 0 mA, and the full scale corresponds to +1 mA output for positive readings and to -1 mA output for negative readings. The zero scale (0 mA output) is permanently set in the instrument to zero for all parameters except the signed power factor for which it is set to 1.000 (see Note 2). In write requests, the zero scale is ignored.
- 2) Except for the signed power factor, the setup scale is continuous within the entire value range. For signed power factor, the setup scale is broken at +1.000 in order to provide continuous output current when the power factor changes close to ± 1.000 . The setup scale is symmetrical in the range of -0 to +0 with a center at 1.000 (-1.000 is assumed to be equal to +1.000). Negative power factor is output as -1.000 minus measured value, and non-negative power factor is output as +1.000 minus measured value. To set the entire range for power factor from -0 to +0, the scales would be specified as -0 to 0. Because of the fact that negative zero may not be transmitted through communications, the value of -0.001 is used to specify the scale of -0, and both +0.001 and 0.000 are used to specify the scale of +0.
- ³ The event value field shows the present device time in the F1 format (starting with V10.4.12).
- ⁴ The event value field shows the server IP address in a network byte order.